


# DIGI PLEX™



## Digiplex Control Panel (DGP-848) - V4.0



DGP-848

## Reference and Installation Manual



# TABLE OF CONTENTS

---

INTRODUCTION .....	4
1.1 Features .....	4
1.2 Specifications .....	4
INSTALLATION .....	5
2.1 Location & Mounting .....	5
2.2 Earth Ground .....	5
2.3 AC Power .....	5
2.4 Backup Battery .....	5
2.5 Auxiliary Power Terminals .....	5
2.6 Telephone Line Connection .....	5
2.7 Bell/siren Output .....	5
2.8 Calculating Power Requirements .....	7
2.9 Programmable Outputs .....	9
2.10 Combus Connections .....	9
2.11 Single Zone Connections .....	9
2.12 Double Zone Connections .....	10
2.13 Keypad Zone Connections .....	10
2.14 Keyswitch Connections .....	10
2.15 Fire Circuits .....	10
PROGRAMMING METHODS .....	12
3.1 Panel Programming Mode .....	12
3.2 Module Programming Mode .....	12
3.3 Feature Select Programming .....	12
3.4 Decimal Programming .....	12
3.5 Hexadecimal Programming .....	12
3.6 Level Programming .....	13
3.7 Paradox Memory Key .....	13
ZONE PROGRAMMING .....	14
4.1 Zone Numbering .....	15
4.2 Zone Definitions .....	15
4.3 Zone Partition Assignment .....	16
4.4 Zone Options .....	16
4.5 Zone Labels .....	17
4.6 Input Speed .....	19
4.7 EOL Zones .....	19
4.8 Zone Doubling (ATZ) .....	19
KEYSWITCH PROGRAMMING .....	20
5.1 Keyswitch Numbering .....	20
5.2 Keyswitch Definitions .....	21
5.3 Keyswitch Partition Assignment .....	21
5.4 Keyswitch Options .....	21
ARMING & DISARMING OPTIONS .....	22
6.1 Arming Follows Partition .....	22
6.2 Restrict Arming On Battery/AC Failure .....	22
6.3 No Arming On Tamper .....	22
6.4 No Arming On Supervision Loss .....	22
6.5 Timed Auto-Arming .....	22
6.6 No Movement Auto-Arming .....	22
6.7 Auto-Arming Options .....	23
6.8 One-Touch Features .....	23
6.9 Exit Delay .....	23
6.10 Keypad Lock-out Feature .....	23
6.11 Maximum Bypass Entries .....	24
6.12 Display "Bypass" If Armed .....	24

6.13 Bell Squawk .....	24
6.14 Ring-back .....	24
6.15 Switch To Stay Arming .....	24
6.16 Always Force Arm When Regular Arming .....	24
<b>ALARM OPTIONS .....</b>	<b>25</b>
7.1 Bell/alarm Output .....	25
7.2 Bell Cut-off Timer .....	25
7.3 Wireless Transmitter Supervision Options .....	25
7.4 Tamper Recognition Options .....	25
7.5 Keypad Panic Options .....	26
<b>EVENT REPORTING .....</b>	<b>27</b>
8.1 Reporting Enabled .....	28
8.2 Report Codes .....	28
8.3 Central Station Phone # .....	30
8.4 Partition Account # .....	30
8.5 Reporting Formats .....	30
8.6 Event Call Direction .....	31
8.7 Recent Close Delay .....	31
8.8 Auto Test Report .....	31
8.9 Power Fail Report Delay .....	31
8.10 Disarm Reporting Options .....	31
8.11 Zone Restore Report Options .....	31
8.12 Pager Delay .....	31
8.13 Auto Report Code Programming .....	31
<b>DIALER OPTIONS.....</b>	<b>33</b>
9.1 Telephone Line Monitoring .....	33
9.2 Tone/pulse Dialing .....	33
9.3 Pulse Ratio .....	33
9.4 Busy Tone Detection .....	33
9.5 Switch To Pulse .....	33
9.6 Bell On Communication Fail .....	33
9.7 Dial Tone Delay .....	33
<b>PROGRAMMABLE OUTPUTS.....</b>	<b>34</b>
10.1 PGM Activation Event .....	34
10.2 PGM Deactivation Event .....	34
10.3 PGM Deactivation Option .....	35
10.4 PGM1 Is Smoke Input .....	35
<b>PGM PROGRAMMING TABLE .....</b>	<b>36</b>
<b>SYSTEM SETTINGS &amp; COMMANDS .....</b>	<b>39</b>
12.1 Hardware Reset .....	39
12.2 Software Reset .....	39
12.3 Battery Charge Current .....	39
12.4 Installer Code Lock .....	39
12.5 Partitioning .....	39
12.6 Installer Function Keys .....	39
12.7 System Date & Time .....	40
12.8 Shabbat Feature .....	40
12.9 Module Reset .....	40
12.10 Locate Module .....	40
12.11 Module Programming .....	40
12.12 Module Broadcast .....	40
12.13 Remove Module .....	41
12.14 Serial Number Viewing .....	41
12.15 Power Save Mode .....	41
12.16 Auto Trouble Shutdown .....	41
12.17 No AC Fail Display .....	41

ACCESS CODES .....	42
13.1 Installer Code .....	42
13.2 Access Code Length .....	42
13.3 System Master Code .....	42
13.4 Programming Access Codes .....	42
13.5 User Options .....	43
13.6 User Partition Assignment .....	43
13.7 Access Control .....	43
13.8 Multiple Action Feature .....	44
ACCESS CONTROL .....	45
14.1 Programming Access Control Overview .....	45
14.2 Common Access Control Terms .....	45
14.3 Enable Access Control .....	45
14.4 Assigning The Module To A Door .....	45
14.5 Door Access Mode .....	45
14.6 Access Levels .....	46
14.7 Schedules .....	46
14.8 Holiday Programming .....	46
14.9 Logging Access Control Events .....	46
14.10 Global Access Door Features .....	47
WINLOAD SOFTWARE .....	48
15.1 Answering Machine Override .....	48
15.2 Ring Counter .....	48
15.3 Panel Identifier .....	48
15.4 PC Password .....	48
15.5 PC Telephone Number .....	48
15.6 Call WinLoad .....	48
15.7 Answer WinLoad .....	48
15.8 Event Buffer Transmission .....	48
15.9 Call Back Feature .....	49
USER FEATURES .....	49
16.1 Arming and Disarming Features .....	49
16.2 Bypass Programming .....	50
16.3 Chime Zones .....	50
16.4 Access Codes .....	51
16.5 Normal and Confidential Modes .....	51
16.6 Keypad Settings .....	51
16.7 Trouble Display .....	51
16.8 Trouble Latch .....	52
16.9 Clear Bell Limit Trouble .....	52
16.10 Event Record Display .....	53
INDEX.....	54
WARNINGS.....	59
WARRANTY .....	60

# INTRODUCTION

Paradox Security Systems has once again redefined the boundaries of the security industry and is proud to introduce the Digiplex Control Panel. A new generation in control panel technology, the Digiplex Control Panel uses a quad-wire combus that provides power and two-way communication for up to 95 modules (keypads, motion detectors, expansion modules, etc.). This, combined with four true partitions, event call direction and the zone numbering feature, simplifies the task of installing or making changes to your security system. The innovative new programming method makes programming the control panel logical and much simpler to execute. This new generation of control panels offers increased capabilities with countless new features without compromising its user-friendliness. If anything, these new control panels are easier to use and easier to install, making the Digiplex Control Panel the ultimate in reliable security protection.

## CTR-21 APPROVAL

The Digiplex DGP-848 control panel meets the European Union Common Technical Requirement CTR-21. The CTR-21 requirement is an electrical standard that defines the analogue interface for all two-wire telecommunications equipment (i.e. DECT, PABXs, etc.) intended for connection to the Public Switched Telephone Network. This allows the Digiplex control panel to be used in as many as 19 countries such as Belgium, Germany, Greece, Portugal, Sweden and Switzerland. Uploading or downloading with the WinLoad Security System Management Software is up to 30% faster due to some of the changes required for CTR-21 approval.

## 1.1 FEATURES

- Digital multiplexed system
- Digital, four-wire combus:
  - ◆ Provides power and two-way communication to all modules connected to the combus.
  - ◆ one combus for up to 95 modules
  - ◆ All modules have Plug and Play capability
  - ◆ Connect modules up to 3000ft (914m) from the panel.
  - ◆ Full supervision and sabotage-proof technology without additional wiring
- Up to 48 addressable zones
- 8 independent keyswitch zones (does not use any of the 48 zones)
- 8 on-board hardwired input terminals
- 4 True Partitions:  
Most features and options in the Digiplex System can be independently set for each partition such as event reporting, entry/

exit delay, bell squawk, quick arming, panics and many more. All zones, keyswitches, user codes and keypads are assigned to specific partitions, making this a true partitioned system.

- 95 User Codes, 1 Installer and 1 System Master
- Up to 5 fully programmable outputs (PGMs) are available. (PGM1 can be set as a two-wire smoke detector input. PGM5 is an optional 5A relay.)
- Simple, direct and logical programming
- Event Call Direction:  
The Digiplex Control Panel events are divided into three event groups for each partition and two system event groups. Each event group can be programmed with a separate dialing sequence for each partition.
- 4 Central Station Telephone Numbers
- SIA, Contact ID, Pager Format and many more Communicator Formats
- Remote and local programming of all modules
- Upload/download capability using new WinLoad Security System Management software for Windows®.
- Addressable PIRs and door contacts
- And much, much, more...

## 1.2 SPECIFICATIONS

### CONTROL PANEL

- AC Power: 16VAC, 20/40VA, 50-60Hz
- Battery: 12VDC, 4Ah minimum
- Aux. Power: 12VDC 600mA typical, 700mA maximum, fuseless shutdown at 1.1A
- Bell Output: 1A, fuseless shutdown @ 3A
- PGM Output: PGM1 (100mA), PGM2 - PGM4 (50mA) and PGM5 (5A optional relay)
- Event Buffer: 1024 events
- All control panel outputs are rated to operate between 10.8Vdc and 12.1Vdc

### GENERAL NOTE

When programming with the Grafica keypad (DNE-K07), the steps may differ. If not indicated, please refer to Grafica's complete user manual available on our Web site at [www.paradox.ca](http://www.paradox.ca).

# INSTALLATION

## 2.1 LOCATION & MOUNTING

Before mounting the cabinet, push the five white nylon mounting studs into the back of the cabinet. Pull all cables into the cabinet and prepare them for connection before mounting the circuit board into the back of the cabinet. Select an installation site that is not easily accessible to intruders and leave at least 2" around the panel box to permit adequate ventilation and heat dissipation. The installation site should be dry and close to an AC source, ground connection and telephone line connection.

## 2.2 EARTH GROUND

Connect the zone and dialer ground terminals from the control panel to the cabinet and cold water pipe or grounding rod as per local electrical codes.

 **For maximum lightning protection, use separate earth grounds for the zone and dialer grounds as shown in Figure 2-3 on page 6.**

## 2.3 AC POWER

Use a 16.5VAC (50/60Hz) transformer with a minimum 20VA rating to provide sufficient AC power. For increased power you can use a transformer with a 40VA rating. *For UL Listed systems, you can use model #BE156240CAA. For CSA listed systems, use model #BE116240AAA.* Do not use any switch-controlled outlets to power the transformer. Connect the transformer as shown in Figure 2-3 on page 6.

 **During power up, the control panel will begin a module scan (see section 12.6) that will last between 30 and 120 seconds.**

 **Do not connect the transformer or the backup battery until all wiring is completed.**

## 2.4 BACKUP BATTERY

In order to provide power during power loss, connect a 12VDC 4Ah/7Ah rechargeable acid/lead or gel cell backup battery (YUASA model #NP7-12 recommended) as shown in Figure 2-3 on page 6. Connect the backup battery after applying AC power. When installing, verify proper polarity, as reversed connections will blow the battery fuse. For information on how to set the Battery Charge Current to either 350mA or 700mA, please refer to section 12.3 of this manual.

### 2.4.1 Battery Test

The control panel conducts a dynamic battery test under load every 64 seconds. If the battery is disconnected, if its capacity is too low or if the battery voltage drops to 10.5 volts or less when there is no AC, the "Battery Trouble" message will appear in the Trouble Display. At 8.5 volts, the panel shuts down and all outputs close.


## 2.5 AUXILIARY POWER TERMINALS

You can use the auxiliary power supply to power the motion detectors, keypads and other accessories in your security system. A fuseless circuit protects the auxiliary output against current overload and automatically shuts down if the current exceeds 1.1A. Auxiliary power will resume once the overload condition has been restored. For details on available output power, please refer to Figure 2-3 on page 6. For more information on how to calculate system consumption, refer to "Calculating Power Requirements" on page 7.

## 2.6 TELEPHONE LINE CONNECTION

Connect the incoming telephone company wires into the TIP and RING connections of the control panel. Then run the wires from T1 and R1 to the telephone system as shown in Figure 2-1.

Figure 2-1: Telephone Line Connections




## 2.7 BELL/SIREN OUTPUT


The BELL+ and BELL- terminals power bells and/or other warning devices that require a steady voltage output during an alarm. The bell output supplies 12VDC upon alarm and can support two 20-watt sirens or one 30-watt siren. The bell output uses a fuseless circuit and will automatically shut down if the current exceeds 3A. If the load on the BELL terminals returns to normal ( $\leq 3A$ ), the control panel will re-instate power to the BELL terminals. When connecting sirens, please verify correct polarity as shown in Figure 2-2. Please note that PGM5 is rated at 5A and can be used to power bells and/or other warning devices (see Figure 2-2: Bell/Siren) by programming it as a bell/siren output. Please refer to Programmable Outputs in section 10.

 **When the bell/siren output is not used, the "Bell Absent" message will appear in the Trouble Display. To avoid this, connect a 1k $\Omega$  resistor across the bell output.**

Figure 2-2: Bell/Siren



**Figure 2-3: Digiplex Control Panel PCB Layout**



For UL/C-UL warnings and requirements, see "WARNINGS" on page 59.

## 2.8 CALCULATING POWER REQUIREMENTS

Table 1: Power Unit Consumption Table


Description	QTY.	PU used by each	Total PU
Grafica Graphic LCD Keypads (DNE-K07):	_____	X 130PU =	_____ PU
LCD Keypads (DGP2-641):	_____	X 80PU =	_____ PU
LED Keypads (DGP2-648):	_____	X 45PU =	_____ PU
Motion Detector Modules (DGP2-50/60/70):	_____	X 25PU =	_____ PU
Door Contact Modules (DGP2-ZC1):	_____	X 14PU =	_____ PU
1-Zone Expansion Modules (DGP2-ZX1):	_____	X 25PU =	_____ PU
4-Zone Expansion Modules (APR3-ZX4):	_____	X 20PU =	_____ PU
8-Zone Expansion Modules (APR3-ZX8):	_____	X 40PU =	_____ PU
Omnia Wireless Expansion Modules (OMN-RCV3):	_____	X 50PU =	_____ PU
1-PGM Expansion Modules (APR3-PGM1):	_____	X 25PU =	_____ PU
4-PGM Expansion Modules (APR3-PGM4):	_____	X 150PU =	_____ PU
Printer Modules (APR3-PRT1):	_____	X 40PU =	_____ PU
InTouch Voice-Assisted Arm/Disarm Modules (APR3-ADM2):	_____	X 70PU =	_____ PU
<b>Note:</b> The DGP2-ACM1P consumes 165PU from its own power supply.			
Other devices such as hardwired motion detectors (1mA = 1PU)			_____ PU
<b>Maximum available power units = 700PU</b>		<b>GRAND TOTAL</b>	_____ PU

- STEP 1:** Using Table 1, calculate the total number of power units (PU) required by each device, module, and accessory in the system. Please take into account devices connected to the control panel's PGM outputs. Since the BELL output has its own power supply, do not include the sirens connected to it in the calculation.
- STEP 2:** If the Grand Total is less than 700PU, go to step 3. If the value is greater, you will require an external power supply (see Figure 2-5 on page 8) to provide the additional power needed. Proceed with step 3 and refer to the example in Figure 2-4 on page 8.
- STEP 3:** Due to the degradation of a power signal over long distances, **EACH** length or run of wire in the system can support only a specific number of power units (PU). Using Table 2: *Power Unit (PU) Limitations For Each Run of Wire*, determine how many power units each length of wire can support. Please note that the total number of power units (PU) can never surpass 700PU.

Table 2: Power Unit (PU) Limitations For Each Run of Wire

Gauge: 18AWG, Surface: 0.823mm <sup>2</sup>		Gauge: 22AWG, Surface: 0.326mm <sup>2</sup>		Gauge: 24AWG, Surface: 0.205mm <sup>2</sup>	
Length of each run of wire	Available Power Units (PU)	Length of each run of wire	Available Power Units (PU)	Length of each run of wire	Available Power Units (PU)
100ft. (30m)	700	100ft. (30m)	700	100ft. (30m)	700
200ft. (61m)	700	200ft. (61m)	682	200ft. (61m)	429
300ft. (91m)	700	300ft. (91m)	454	300ft. (91m)	286
400ft. (122m)	700	400ft. (122m)	341	400ft. (122m)	214
500ft. (152m)	690	500ft. (152m)	273	500ft. (152m)	171
600ft. (183m)	575	600ft. (183m)	227	600ft. (183m)	143
700ft. (213m)	493	700ft. (213m)	195		
800ft. (244m)	431	800ft. (244m)	170		
900ft. (274m)	383	900ft. (274m)	151		
1000ft. (305m)	345	1000ft. (305m)	136		
1500ft. (457m)	230				
2000ft. (610m)	172				
2500ft. (762m)	138				
3000ft. (914m)	115				


**Figure 2-4: Sample Power Requirement Calculations**



If in the above example you were to add an LCD Keypad (80PU) to the 100 foot or 300 foot wire, you would not exceed the wire's limit. Although, adding the LCD Keypad to the 1,000 foot wire would exceed the wire's limits, thereby causing devices to function at decreased capacity.

**Figure 2-5: External Power Supply Connections**

Power units required by devices connected to a power supply do not draw power from the control panel's auxiliary output.




**Do not use the same transformer for the control panel and the external power supplies. Modules should never be installed more than 3,000 feet (914m) from the control panel.**

## 2.9 PROGRAMMABLE OUTPUTS

The DigiPlex Control Panel comes standard with PGM1 and PGM2. PGM3 to PGM5 are optional. When a specific event or condition occurs in the system, a PGM can be programmed to reset smoke detectors, activate strobe lights, open/close garage doors and much more. For details on how to program the PGMs, refer to section 10.

PGM1 provides a maximum 100mA output, PGM2 to PGM4 provide a maximum 50mA output and PGM5 is a relay output that provides a maximum of 5A. If the current draw on the PGM is to exceed the current output, we recommend the use of a relay as shown in Figure 2-6. PGM1 to PGM4 are normally open outputs and PGM5 is a normally open or normally closed 5A relay. Also, note that PGM1 can be programmed as a 2-wire smoke detector input. For more information, refer to section 2.15.1 and section 10.4 of this manual.

Figure 2-6: PGM Relay Output



## 2.10 COMBUS CONNECTIONS

The combus is a 4-wire combus that provides power and two-way communication between the control panel and all modules connected to it. All addressable detection devices, keypads and DigiPlex modules are connected to the combus, which can support up to 95 modules. Connect the four terminals labeled RED, BLK, GRN and YEL of each detector, keypad or module to the corresponding terminals of the control panel as shown in Figure 2-3 on page 6. Please note that all modules can be connected in a star and/or daisy chain configuration. The final device on the combus should not be more than 3000ft (914m) from the control panel. The total run of every wire in the system must not exceed 3000ft (914m). For example, if 10 runs of wire are each 1000ft (305m), the total would exceed the system's capacity. For information on how to assign a detection device to a zone in the control panel, please refer to "Zone Programming" on page 14.

**Before connecting a module to the control panel, shutdown the control panel by removing AC and battery power.**

### 2.10.1 Connecting the Combus in Noisy Environments

When installing the combus wires in proximity to high electrical interference such as neon lights, motors, high-voltage wiring, transformers, or when connecting the combus across separate buildings, you must use shielded cables. Connect the shielded cable as detailed below:


**Within the Same Building:** Strip the outer jacket at one end of the shielded cable to expose the shield and connect the shield to the control panel ground (not the dialer ground), while leaving the shield at the other end of the cable open (floating).

**Across Separate Buildings:** Strip the outer jacket at one end of the shielded cable to expose the shield. In the same building that houses the control panel, connect the exposed shield to a cold water pipe or any other earth ground available, while leaving the shield at the other end of the cable open (floating). The same configuration applies for any subsequent building.

## 2.11 SINGLE ZONE CONNECTIONS

In addition to the combus, the DigiPlex Control Panel includes eight hardwired input terminals for use with traditional hardwired door contacts, smoke detectors and/or motion detectors. One to eight-Zone Expansion Modules that connect to the combus are also available. Devices connected to hardwired input terminals must be assigned to a zone and the zone's parameters must be defined. Please refer to "Zone Programming" on page 14, for more information. Figure 2-7 demonstrates single zone (ATZ disabled) hardwire input terminal connections recognized by the DigiPlex system. For UL listed installations, use EOL resistor part #2011002000.

Figure 2-7: Single Zone Input Connections




\*for installations without EOL, remove 1KΩ


## 2.12 DOUBLE ZONE CONNECTIONS

Enabling the ATZ feature (see section 4.8) allows you to install two detection devices per input terminal. The ATZ feature is a software oriented feature. Simply connect the devices as shown in Figure 2-8. Devices connected to input terminals must be assigned to a zone and the zone's parameters must be defined. Please refer to "Zone Programming" on page 14. for more information. For UL listed installations, use EOL resistor part #2011002000.


**Figure 2-8: Double Zone Connections**



**N.C. Contact, No EOL, With Tamper Recognition**



**N.C. Contacts, With EOL, With Tamper & Wire Fault Recognition (UL/ULC)**



## 2.13 KEYPAD ZONE CONNECTIONS

Each LED and LCD keypad has one hardwired input terminal allowing you to connect a detector or door contact directly to the keypad. For example, a door contact located at the entry point of an establishment can be wired directly to the input terminal of the entry point keypad instead of all the way to the control panel.




**Even with the ATZ feature enabled in the control panel, only one device can be connected to the keypad's hardwired input terminal. Tamper is not recognized on keypad zones. The keypad zone follows the control panel's EOL definition.**

A device connected to the keypad's input terminal must be assigned to a zone in the control panel and the zone's parameters must be defined (see "Zone Programming" on page 14.). The keypad will communicate the status of the zone to the control panel via the combus. The detection device is connected as shown in Figure 2-3 on page 6.

## 2.14 KEYSWITCH CONNECTIONS

Connect the keyswitches to the keypad, control panel, or Zone Expansion Module's hardwired input terminals as shown in Figure 2-9. Once a keyswitch is connected, it must be assigned a keyswitch zone and its parameters must be defined as described in "Keyswitch Programming" on page 20.

**Figure 2-9: Keyswitch Connections**



## 2.15 FIRE CIRCUITS

Connect the smoke detectors used in the security system using any of the following methods. Smoke detectors connected to the control panel or zone expansion input terminals must be assigned to a zone in the control panel and the zone's parameters must be defined as a Fire Zone. For more details, refer to "Zone Programming" on page 14.

### 2.15.1 Smoke Detector Installation (2-Wire)


PGM1 can be defined as a 2-wire smoke detector input (see section 10.4) enabling smoke detectors to be connected as shown in Figure 2-10 on page 11. Fire Zones must use a 1kΩ EOL resistor. If there is a line short or if the smoke detector becomes active, whether the system is armed or disarmed, the control panel will generate an alarm. If the line is open, the "Zone Fault" trouble indication will appear in the Trouble Display and will transmit the appropriate report code to the central station (if programmed).

### 2.15.2 ESL CleanMe™ Installation

The Digiplex control panel supports the use of ESL smoke detectors that have the CleanMe™ feature. The ESL smoke detectors are connected exactly like standard smoke detectors as

shown in Figure 2-10. Please note that you should avoid connecting more than 20 ESL smoke detectors. When an ESL smoke detector sends a CleanMe™ signal, the control panel will generate a Zone Fault trouble and if programmed will transmit the Fire Loop report code to the central station. The trouble will be cleared if there is no CleanMe™ signal for 255 seconds. If an alarm occurs, the trouble will be cleared until it is detected again.

**Figure 2-10: PGM1 2-wire Smoke Detector Input**




When using ESL smoke detectors with the CleanME™ feature, do not connect more than 20 detectors in parallel.

### 2.15.3 Smoke Detector Installation (4-Wire)

Connect the 4-wire smoke detectors and a relay as shown in Figure 2-11. Recommended: The System Sensor model 2112/24D smoke detectors. To comply with UL955, the 4-wire smoke detectors must be installed using 18 gauge wire. In the event power is interrupted, the relay will cause the control panel to transmit the Fire Loop Trouble report if programmed in section [707]. To reset (unlatch) the smoke detector after an alarm, verify that the negative (-) of the smoke detector is connected to a PGM as shown in Figure 2-11. Then program the PGM with the “Smoke Reset” activation event (see section 10.1 of this manual) to

interrupt power to the smoke detector for four seconds when the [CLEAR] and [ENTER] (LCD keypads) or [\*] and [#] (Grafica keypads) keys are pressed and held for two seconds.

**Figure 2-11: Fire Zones  
UL/ULC INSTALLATION**



#### SINGLE FIRE ZONE CONNECTIONS ONLY

If the ATZ feature is enabled, do not use the extra input (i.e. in the above example, input 009 cannot be used as a zone).



***It is recommended that all 2-wire and 4-wire smoke detectors be connected in a daisy chain configuration.***

# PROGRAMMING METHODS

The Digiplex Control Panel can be programmed using the WinLoad software, the Paradox Memory Key, or manually by using an LCD (DGP2-641) or Grafica (DNE-K07) keypad. We highly recommend programming the control panel with WinLoad as it greatly simplifies the process and reduces potential data errors. Please refer to "WINLOAD SOFTWARE" on page 48. for details on how to set up the control panel to function with WinLoad.

You can also copy the programmed contents of one Digiplex control panel into as many Digiplex control panels as you need by using the Paradox Memory Key (see section 3.7). Each control panel is programmed in less than 5 seconds.

Keypads and other modules can also be programmed easily by using Module Broadcast (see section 12.12). Once a module is programmed, its sections can be sent to other similar modules through the combus.

## 3.1 PANEL PROGRAMMING MODE

Use the *Programming Guide* to keep track of which sections were programmed and how. In order to program anything in the Digiplex Control Panel you must enter panel programming mode.

### TO PROGRAM IN PANEL PROGRAMMING MODE:

- 1) Press and hold the **[0]** key.
- 2) Enter the **[INSTALLER CODE]** (Default is 000000).
- 3) Enter the 3-digit **[SECTION]**.  
Every feature and or option is programmed in a three-digit section starting at **[001]**.
- 4) Enter the required **[DATA]**.  
The type of data required will be detailed in the *Programming Guide* and/or explained in the appropriate sections of this manual.

#### For LCD keypads:

After entering the required data, either the control panel will automatically save the data and advance to the next section, or you must press the **[ENTER]** key to save the data and advance to the next section. Press the **[CLEAR]** key to revert to the preceding step or to erase the current data.

#### For Grafica keypads:

After entering the required data, press Grafica's center action key (**Save**) to save the data and advance to the next section. Press the right action key (**Exit**) to revert to the preceding step or press the left action key (**Clear**) to erase the current data.

## 3.2 MODULE PROGRAMMING MODE

All modules connected to the combus are programmed through an LCD (DGP2-641) or Grafica (DNE-K07) keypad in the system. To do so, simply enter *Module Programming Mode* as shown below.

### TO PROGRAM IN MODULE PROGRAMMING MODE:

- 1) Press & hold the **[0]** key.
- 2) Enter the **[INSTALLER CODE]** (Default is 000000).
- 3) Enter section **[953]**.
- 4) Enter the 8-digit **[SERIAL NUMBER]** of the module you wish to program.
- 5) Enter the 3-digit **[SECTION]** and required **[DATA]**.  
Refer to the *Module's Programming Guide* or the module's Installation manual for details.

The control panel will redirect all programming to the selected module. To exit Module Programming Mode, press the **[CLEAR]** key on LCD keypads, or the right action key (**Exit**) on Grafica keypads, as many times as needed to return to the desired screen. Please note that a module's serial number can be located on the module's PC board or it may already be recorded in the module's Installation Guide.

## 3.3 FEATURE SELECT PROGRAMMING

Most of the Digiplex Control Panel options are programmed using the Feature Select Method.

#### For LCD keypads:

Each number from 1 to 8 corresponds to a specific feature or option. Set these options by turning the number corresponding to the feature ON or OFF. The option is considered ON when the number appears within the brackets. Turn options ON and OFF by pressing the corresponding keys on the keypad. Press the keys as many times as you need to select the desired options and then press **[ENTER]** to save.

#### For Grafica keypads:

Select or clear the check boxes pertaining to the options or features that you wish to enable or disable. You can also set the options by pressing the corresponding keys on the keypad. The feature is considered ON when its check box is selected. To save the settings, press Grafica's center action key (**Save**).

## 3.4 DECIMAL PROGRAMMING

Certain sections may require the entry of a 3-digit decimal value from 000 to 255.

## 3.5 HEXADECIMAL PROGRAMMING

Certain sections may require the entry of one or more Hexadecimal values from 0 to F.

#### For LCD keypads:

<b>[0]</b> to <b>[9]</b>	= values 0 to 9 respectively	<b>[DISARM]</b>	= D
<b>[STAY]</b>	= A	<b>[BYP]</b>	= E
<b>[FORCE]</b>	= B	<b>[MEM]</b>	= F
<b>[ARM]</b>	= C		

### For Grafica keypads:

[0] to [9] = values 0 to 9 respectively

[#] = A to F (press the key until the desired letter appears)

## 3.6 LEVEL PROGRAMMING

In the sections requiring Level Programming, only one option can be selected.

### For LCD keypads:

To select the option, use the [▲] and [▼] keys until the desired option is visible and then press [ENTER] to save.

### For Grafica keypads:

To select the option, use Grafica's scroll keys until the desired option is visible and then press Grafica's center action key (**Save**) to save.


## 3.7 PARADOX MEMORY KEY



**The Paradox Memory Key is not verified by UL.**


Copy the programmed contents of one Digiplex Control Panel into the Paradox Memory Key. Then copy the contents of the Paradox Memory Key into as many Digiplex Control Panels as you need. This saves you a lot of time. All you have to do is program one Digiplex Control Panel, then download the programmed contents to other control panels in less than 5 seconds.

**Figure 3-1: Using the Memory Key**



### Copy to Memory Key from SOURCE Control Panel:


- 1) Remove the AC and battery power from the control panel.
- 2) Place Memory Key on the connector labeled MEM KEY of the control panel that you want to copy. Make sure that the write protect jumper is on.



- 3) Enter section: **[965]** to copy the contents of the panel **except sections [001] to [048] (device serial numbers) and [049] to [056] (keyswitch serial numbers)** to the key. **[966]** to copy all of the contents including **sections [001] to [048] and [049] to [056]** from the panel to the key.
- 4) When the keypad emits a Confirmation Beep, wait 10 seconds before removing the Memory Key. Remove the jumper if you do not wish to accidentally overwrite the contents of the Memory Key.

### Download to DESTINATION Control Panel:

- 1) Remove the AC and battery power from the control panel.
- 2) Place the Memory Key on the connector labeled MEM KEY of the control panel that is to receive the contents of the Memory Key.



- 3) Enter section: **[961]** to download the contents **except sections [001] to [048] (device serial numbers) and [049] to [056] (keyswitch serial numbers)** from the key to the panel. **[962]** to download all of the contents including **sections [001] to [048] and [049] to [056]** from the key to the panel.
- 4) When the keypad emits a Confirmation Beep, wait 10 seconds before removing the Memory Key.

# ZONE PROGRAMMING

All detection devices connected to the control panel, keypads and zone expansion modules must be assigned to a zone and that zone must be defined as described in this section:

**Zone Numbering [001] to [048]:**


- Serial number of the device/module
- Input number of the device/module

**Zone Parameters [101] to [148]:**

- Zone Definition
- Zone Partition Assignment
- Zone Options

The Zone Numbering feature is used to individually assign each detection device to any desired zone in the Digiplex system (see section 4.1). The Zone Parameters define the type of zone, the zone's partition assignment and how the control panel will react when an alarm condition occurs on that zone (see section 4.2 to section 4.4). For more information on the installation of devices and modules, please refer to Figure 2-3 on page 6 or to their respective Installation Guides.

**Figure 4-1: Zone Programming**



## 4.1 ZONE NUMBERING

### SECTIONS [001] TO [048]


The Zone Numbering feature allows you to assign any detection device in the system to any of the 48 zones. This feature tells the control panel where the device is connected and which of the 48 zones is assigned to that device (see *Figure 4-2: Zone Numbering*).

- To assign an addressable detection device connected to the combus, program the detector's serial number into the section corresponding to the desired zone (i.e. program zone 34 in section [034]).
- To assign a detection device connected to a module or control panel's hardwired input terminal, program the module's or control panel's serial number and the input number where the device is connected into the section corresponding to the desired zone. Refer to the appropriate module's Installation Guide for details of its input numbers. Note: An input number is not required for motion detectors, keypad zones, and the Access Control Module (DGP2-ACM1P).



**If PGM1 is defined as a smoke detector input (see section 10.4), the control panel will recognize it as input # 255.**

**Figure 4-2: Zone Numbering**



	Zone#	Section#	Serial#	Input#
Addressable Detector A:	1 =	[001]	21000033	N/A
Hardwired Device A:	2 =	[002]	1B000252	N/A
Hardwired Device B:	3 =	[003]	010000A2	002
Hardwired Device C:	4 =	[004]	34000041	005

### 4.1.1 Clearing a Zone's Numbering

**For LCD keypads:**

- Enter a section number between [001] and [048].
- Press [0] and then [ENTER] to save and exit.

**For Grafica keypads:**

- Enter a section number between [001] and [048].
- Press [0] to clear the serial number.
- Using Grafica's scroll keys, highlight the input number and then press [0] to clear the data.
- Press Grafica's center action key (**Save**) to save and exit.

## 4.2 ZONE DEFINITIONS

Select one of the 15 available zone definitions described below (also refer to Figure 4-1 on page 14).

### 4.2.1 Zone Disabled

#### SECTIONS [101] TO [148]: FIRST DIGIT = 0

Disables the corresponding zone. All zones are disabled by default.

### 4.2.2 Entry Delays 1 to 4

#### SECTIONS [101] TO [148]: FIRST DIGIT = 1 TO 4

When an armed zone defined as an Entry Delay opens, the control panel will not generate an alarm until the programmed Entry Delay Timer has elapsed. A zone can be defined with one of four Entry Delays. Each Entry Delay is associated with an Entry Delay Timer. To program the Entry Delay Timer, key in the desired 3-digit delay value (000 to 255 seconds) into the corresponding section:

- Entry Delay 1 Timer: [230]
- Entry Delay 2 Timer: [231]
- Entry Delay 3 Timer: [232]
- Entry Delay 4 Timer: [233]

Please note these are the same timers used for Stay Delay zones (see section 4.2.9). Entry Delay zones are commonly used at the entry/exit points of the protected area (i.e. front/back door or garage). Using different Entry Delays is useful when, for example, one entry point requires a longer delay than the other entry point or in a partitioned system where each partition may require a different Entry Delay.

### 4.2.3 Follow Zones

#### SECTIONS [101] TO [148]: FIRST DIGIT = 5

If an armed Follow zone opens, the control panel will immediately generate an alarm. If an armed Entry Delay zone (see section 4.2.2) opens before the Follow zone, the control panel will wait until the end of the Entry Delay before generating an alarm. If more than one Entry Delay zone opens before the Follow zone, the control panel will wait until the end of the first Entry Delay before generating an alarm.

### 4.2.4 Instant Zones

#### SECTIONS [101] TO [148]: FIRST DIGIT = 6

When an armed Instant zone opens, the control panel immediately generates an alarm. Instant zones are commonly used for windows, patio doors, skylights and other perimeter type zones.

### 4.2.5 24Hr Buzzer Zones

#### SECTIONS [101] TO [148]: FIRST DIGIT = 7

Whenever a 24Hr Buzzer zone opens, whether the zone is armed or disarmed, the control panel will activate the keypad buzzer to indicate that the zone was breached. The control panel will report the alarm, but will not enable the bell/siren output. Enter any valid access code on the keypad to stop the buzzer.



**The keypads must be assigned to the same partition as the 24Hr Buzzer zone. Otherwise, the buzzer will not activate.**

### 4.2.6 24Hr Burglary Zones

#### SECTIONS [101] TO [148]: FIRST DIGIT = 8

Whenever a 24Hr Burglary zone opens, whether the system is armed or disarmed, the control panel will immediately generate an alarm.

### 4.2.7 Delayed 24Hr Fire Zone

#### SECTIONS [101] TO [148]: FIRST DIGIT = 9


The Delayed 24Hr Fire Zone definition described in Figure 4-3 on page 16 is commonly used in residential homes where a smoke

detector often generates false alarms (i.e. cigarette smoke, burning bread, etc.). When a zone is programmed as a Fire zone, the zone becomes normally open and requires an EOL resistor. The zone will not function as normally closed.



**The keypads must be assigned to the same partition as the Delayed 24Hr Fire zone for the buzzer to activate.**

**Figure 4-3: Delayed 24-hr. Fire Zone**




#### 4.2.8 Standard 24Hr Fire Zone

SECTIONS [101] TO [148]: FIRST DIGIT = A

For details how to connect smoke detectors to the control panel, refer to Fire Circuits in section 2.15. When a zone is programmed as a Fire zone, the zone becomes normally open and requires an EOL resistor. The zone will not function as normally closed. Whenever a Standard 24Hr Fire Zone is triggered, whether it is armed or disarmed, the control panel can:

- send a *Zone Alarm* report code (see section 8.2.5).
- send a *Fire Loop Trouble Report* (see section 8.2.11) if a tamper/wiring fault occurs on a Fire Zone. A “Zone Fault Trouble” will also appear in the keypad’s Trouble Display.
- generate a Fire alarm, which is always audible, regardless of other settings. Fire alarms will generate an intermittent bell/siren output signal as demonstrated in Figure 4-4.

**Figure 4-4: Bell/Siren Output During Fire Alarm**



#### 4.2.9 Stay Delay Zone

SECTIONS [101] TO [148]: FIRST DIGIT = B TO E

When a Stay Delay zone is armed using the Regular or Force arming methods, the control panel will process the zone as an Instant zone (see section 4.2.4). When a Stay Delay zone is armed using the Stay or Instant arming methods and the zone is triggered, the control panel will not generate an alarm until the programmed Stay Delay has elapsed. A zone can be defined with one of four Stay Delays. Each Stay Delay is associated with an Entry Delay Timer. To program the Entry Delay Timer, key in the desired 3-digit delay value (000 to 255 seconds) into the corresponding section:  
 Stay Delay 1 = Entry Delay 1 Timer in section [230]  
 Stay Delay 2 = Entry Delay 2 Timer in section [231]  
 Stay Delay 3 = Entry Delay 3 Timer in section [232]  
 Stay Delay 4 = Entry Delay 4 Timer in section [233]  
 Please note that the Entry Delay Timers are the same timers used for Entry Delay zones.

#### 4.3 ZONE PARTITION ASSIGNMENT

SECTIONS [101] TO [148]: SECOND DIGIT = 1 TO 4

The control panel provides the option of partitioning the security system into two, three, or four completely independent systems. Therefore, each zone must be assigned to one partition as described in Figure 4-1 on page 14. For more information on Partitioning, refer to section 12.5.

#### 4.4 ZONE OPTIONS

Each zone can be programmed with one or more of the options described below. Program the zone options as described in Figure 4-1 on page 14.

##### 4.4.1 Auto Zone Shutdown

SECTIONS [101] TO [148]: OPTION [1]

When option [1] is disabled and an armed zone is breached, the control panel generates an alarm: it may send an alarm report (see section 8.11), activate the bell output, etc.. If the same zone re-opens during the same alarm, another alarm report may be sent, the bell output may re-activate and so on. When option [1] is enabled on a zone, the control panel will stop generating an alarm when the Auto Zone Shutdown Limit is reached during one armed period. The control panel will ignore zones with the Auto Zone Shutdown option that have surpassed the programmed limit. To program the Auto Zone Shutdown Limit, key in the desired 3-digit counter (000 to 015) into section [217]. Entering 000 disables this feature. The Auto Zone Shutdown counter resets every time the system is armed.

#### 4.4.2 Bypass Zones

SECTIONS [101] TO [148]: OPTION [2]

Only zones with option [2] enabled can be Manually Bypassed (see section 13.5.3). Fire Zones cannot be bypassed. All zones are set as Bypass Zones by default.

#### 4.4.3 Stay Zones

SECTIONS [101] TO [148]: OPTION [3]

Only zones with option [3] enabled will be bypassed when the system is Stay or Instant Armed (see section 16.1.2). All other zones will remain activated. Fire Zones cannot be set as Stay Zones.

#### 4.4.4 Force Zones

SECTIONS [101] TO [148]: OPTION [4]

Only zones with option [4] enabled can be bypassed when the system is Force armed (see section 16.1.6). Fire Zones cannot be set as Force Zones.

#### 4.4.5 Alarm Types

SECTIONS [101] TO [148]: OPTIONS [5] & [6]

[5]	[6]	Zone Alarm Type
Off	Off	Steady Audible Alarm
Off	On	Pulsed Audible Alarm
On	Off	Silent Alarm
On	On	Generates a report only

- A *Steady Audible Alarm* transmits the appropriate report code (if programmed) and generates an alarm providing a steady output for any bells or sirens connected to the control panel.
- A *Pulsed Audible Alarm* transmits the appropriate report code and generates an alarm providing a pulsed output (see Figure 4-4 on page 16) for any bells or sirens connected to the panel.
- A *Silent Alarm* transmits the appropriate report code and generates an alarm without activating any bells or sirens (e.g. keypad indicates an alarm and the system must be disarmed).
- A *Report Only* sends the report code to the central station. Unlike a silent alarm, no access codes are required to cancel the alarm. Fire Zones cannot be set to *Report Only*.

#### 4.4.6 Intellizone

SECTIONS [101] TO [148]: OPTION [7]

If an alarm condition occurs on a zone with option [7] enabled, the control panel will trigger the Intellizone Delay and will seek confirmation of the alarm before generating an alarm. An alarm will only be generated if one of the following conditions occurs during the Intellizone Delay:

- 1) An alarm condition occurs on any other Intellizone during the Intellizone Delay.
- 2) The zone in alarm has restored and re-occurred during the Intellizone Delay.
- 3) The zone in alarm remains in alarm for the entire Intellizone Delay.

To program the Intellizone Delay, key in the desired 3-digit delay value (010 to 255 seconds) into section [200]. Fire Zones cannot be set as Intellizones.

#### 4.4.7 Delay Alarm Transmission

SECTIONS [101] TO [148]: OPTION [8]

When an alarm condition occurs on a zone with option [8] enabled, the control panel will generate an alarm, but will not report the alarm to the central station until the end of the Alarm Transmission Delay. During this period, disarming the system will cancel any report originating from this zone. To program the Alarm

Transmission Delay, key in the desired 3-digit delay value (001 to 255 seconds, 000 = instant) into section [256]. This feature is commonly used with Entry Delay zones in order to reduce the occurrence of false alarms created by new users who may not disarm the system in time.

### 4.5 ZONE LABELS

SECTIONS [451] TO [498]

The existing zone labels that are displayed on an LCD (DGP2-641) or Grafica (DNE-K07) keypad's screen can be modified to suit the installation's needs. When zone labels are modified, the label is changed throughout the system. Each label can contain a maximum of 16 characters. To modify the zone labels, enter the desired section and then enter the label. For instructions on how to enter letters and special characters, refer to Tables 3 to 9 for LCD keypads, or Grafica's Online Manual for Grafica keypads. A complete Grafica user manual is available on our Web site at [www.paradox.ca](http://www.paradox.ca).

**Zone Labels:** Sections [451] to [498] represent Zones 01 to 48.

Table 3: Keys

Press	Feature	Description
[STAY]	Insert Space	Inserts a blank space in the cursor's position
[FORCE]	Delete	Deletes the character or blank space found at the cursor's position
[ARM]	Delete Until the End	Deletes all characters and spaces to the right of the cursor and at the cursor's position
[DISARM]	Numeric or Alphanumeric	Toggles from numeric keys to alphanumeric keys and vice versa (see Table 4 on page 17, Table 5 on page 18 or Table 6 on page 18)
[BYP]	Lower or Upper Case	Toggles the case setting from lower to upper case and vice versa
[MEM]	Special Characters	The cursor will turn into a flashing black square. Enter the 3-digit number that represents the desired symbol (see Table 7 on page 18, Table 8 on page 18 or Table 9 on page 18)

Table 4: Numeric and Alphanumeric Keys

Key	Numeric	Alphanumeric		
	Press key one time	Press key one time	Press key two times	Press key three times
[0]	0	---	---	---
[1]	1	A	B	C
[2]	2	D	E	F
[3]	3	G	H	I
[4]	4	J	K	L
[5]	5	M	N	O
[6]	6	P	Q	R
[7]	7	S	T	U
[8]	8	V	W	X
[9]	9	Y	Z	

**Table 5: Hebrew Keypad Letter Assignment**

Key	Press key once	Press key twice	Press key three times
[1]	א	ב	ג
[2]	ד	ה	ו
[3]	ז	ח	ט
[4]	י	כ	ל
[5]	מ	נ	ס
[6]	ע	פ	צ
[7]	ק	ר	ש
[8]	ת		
[9]			

**Table 6: Russian Keypad Letter Assignment**

Key	Press key once	Press key twice	Press key three times	Press key four times
[1]	А	Б	В	Г
[2]	Д	Е	Ё	Ж
[3]	З	И	Й	К
[4]	Л	М	Н	О
[5]	П	Р	С	Т
[6]	У	Ф	Х	Ц
[7]	Ч	Ш	Щ	Ъ
[8]	Ы	Ь	Э	Ю
[9]	Я			

**Table 7: Special Characters Catalogue**

032	048	064	080	096	112	128	144	160	176	192	208
	0	ð	Р	`	p	Û	É	-	s	Ø	.
033	049	065	081	097	113	129	145	161	177	193	209
!	1	A	Q	a	q	Û	È	î		Ł	
034	050	066	082	098	114	130	146	162	178	194	210
"	2	B	R	b	r	Ü	É	ï	ij	U	210
035	051	067	083	099	115	131	147	163	179	195	211
#	3	C	S	c	s	Ü	È	í	↑	ı	
036	052	068	084	100	116	132	148	164	180	196	212
\$	4	D	T	d	t	û	è	ï	↓	v	
037	053	069	085	101	117	133	149	165	181	197	213
%	5	E	U	e	u	ù	è	i	↶	∞	
038	054	070	086	102	118	134	150	166	182	198	214
&	6	F	V	f	v	ú	é	ñ	↷	÷	
039	055	071	087	103	119	135	151	167	183	199	215
'	7	G	W	g	w	ô	ë	ñ	ˆ	ı	
040	056	072	088	104	120	136	152	168	184	200	216
(	8	H	X	h	x	ó	ä	ñ	→	ı	
041	057	073	089	105	121	137	153	169	185	201	217
)	9	I	Y	i	y	ó	ä	-	↵	ı	
042	058	074	090	106	122	138	154	170	186	202	218
*	:	J	Z	j	z	-	â	↶	↑	ı	
043	059	075	091	107	123	139	155	171	187	203	219
+	;	K	[	k	{	â	â	↷	↓	ı	
044	060	076	092	108	124	140	156	172	188	204	220
,	<	L	*	l		â	â	-	ı	©	
045	061	077	093	109	125	141	157	173	189	205	221
-	=	M	]	m	}	â	â	-	ı	©	
046	062	078	094	110	126	142	158	174	190	206	222
.	>	N	^	n	→	â	â	↶	ı	©	
047	063	079	095	111	127	143	159	175	191	207	223
/	?	O	_	o	←	â	â	↷	ı	©	

**Table 8: Hebrew Special Characters Catalogue**

032	048	064	080	096	112	128	144	160	176	192	208
	0	Й	Р	y	p			א	נ		
033	049	065	081	097	113	129	145	161	177	193	209
!	1	A	Q	a	q			ב	ו		
034	050	066	082	098	114	130	146	162	178	194	210
"	2	B	R	b	r			ג	ט		
035	051	067	083	099	115	131	147	163	179	195	211
#	3	C	S	c	s			ד	ך		
036	052	068	084	100	116	132	148	164	180	196	212
Φ	4	D	T	d	t			ה	פ		
037	053	069	085	101	117	133	149	165	181	197	213
%	5	E	U	e	u			ו	ץ		
038	054	070	086	102	118	134	150	166	182	198	214
&	6	F	V	f	v			ז	צ		
039	055	071	087	103	119	135	151	167	183	199	215
'	7	G	W	g	w			ח	ק		
040	056	072	088	104	120	136	152	168	184	200	216
(	8	H	X	h	x			ט	ך		
041	057	073	089	105	121	137	153	169	185	201	217
)	9	I	Y	i	y			י	ש		
042	058	074	090	106	122	138	154	170	186	202	218
*	:	J	Z	j	z			כ	ת		
043	059	075	091	107	123	139	155	171	187	203	219
+	;	K	Ш	k	И			ל			
044	060	076	092	108	124	140	156	172	188	204	220
,	<	L	Π	l				מ			
045	061	077	093	109	125	141	157	173	189	205	221
-	=	M	Ж	m				נ			
046	062	078	094	110	126	142	158	174	190	206	222
.	>	N	^	n	→			ס			
047	063	079	095	111	127	143	159	175	191	207	223
/	?	O	Ш	o	←			ע			

**Table 9: Russian Special Characters Catalogue**

032	048	064	080	096	112	128	144	160	176	192	208	224	240
	0	ð	Р	`	p			Б	Ю	ч		Д	¼
033	049	065	081	097	113	129	145	161	177	193	209	225	241
!	1	A	Q	a	q			Г	Я	ш		Ц	1/3
034	050	066	082	098	114	130	146	162	178	194	210	226	242
"	2	B	R	b	r			Ё	б	ь		Щ	1/2
035	051	067	083	099	115	131	147	163	179	195	211	227	243
#	3	C	S	c	s			Ж	В	ы	!!	л	
036	052	068	084	100	116	132	148	164	180	196	212	228	244
\$	4	D	T	d	t			З	Г	ь		Ф	
037	053	069	085	101	117	133	149	165	181	197	213	229	245
%	5	E	U	e	u			И	ё	э		ш	
038	054	070	086	102	118	134	150	166	182	198	214	230	246
&	6	F	V	f	v			Й	ж	ю		щ	
039	055	071	087	103	119	135	151	167	183	199	215	231	247
'	7	G	W	g	w			Л	з	я	ı	ı	
040	056	072	088	104	120	136	152	168	184	200	216	232	248
(	8	H	X	h	x			П	и	«	ı	ı	
041	057	073	089	105	121	137	153	169	185	201	217	233	249
)	9	I	Y	i	y			У	й	»	↑	~	
042	058	074	090	106	122	138	154	170	186	202	218	234	250
*	:	J	Z	j	z			Ф	к	„	↓	é	
043	059	075	091	107	123	139	155	171	187	203	219	235	251
+	;	K	[	k	{			Ч	л	“		ç	
044	060	076	092	108	124	140	156	172	188	204	220	236	252
,	<	L	*	l				Ш	м			ıj	
045	061	077	093	109	125	141	157	173	189	205	221	237	253
-	=	M	]	m	}			Ъ	п	ı		ı	§
046	062	078	094	110	126	142	158	174	190	206	222	238	254
.	>	N	^	n	→			Ы	п	f		ı	
047	063	079	095	111	127	143	159	175	191	207	223	239	255
/	?	O	_	o	←			Э	т	£	ı	ı	

## 4.6 INPUT SPEED

### SECTIONS [201] TO [216]

(000 to 255 X 20msec, default: 600ms) The Input Speed defines how quickly the control panel will respond to an open zone detected on any hardwired input terminal. The control panel will not display and/or respond to an open zone until the programmed Input Speed elapses to prevent glitches from causing an alarm or unnecessary reporting. All other zone definitions and options do not come into effect until the Input Speed has elapsed. The Input Speed does not apply to addressable detection devices. The Input Speed for each input terminal can be set from 20ms to 5.1s, by programming the desired value (001 to 255 X 20ms) into the appropriate section.

#### Example:

The system is armed and the zone speed is set for 600ms. A zone opens and closes in less than 600ms, the control panel will not respond (i.e. no reporting, no alarm and no display on the keypad).

- [201] Panel Terminal 1 / Input 001 speed
- [202] Panel Terminal 2 / Input 002 speed
- [203] Panel Terminal 3 / Input 003 speed
- [204] Panel Terminal 4 / Input 004 speed
- [205] Panel Terminal 5 / Input 005 speed
- [206] Panel Terminal 6 / Input 006 speed
- [207] Panel Terminal 7 / Input 007 speed
- [208] Panel Terminal 8 / Input 008 speed
- [209] Panel Doubler 1 / Input 009 speed
- [210] Panel Doubler 2 / Input 010 speed
- [211] Panel Doubler 3 / Input 011 speed
- [212] Panel Doubler 4 / Input 012 speed
- [213] Panel Doubler 5 / Input 013 speed
- [214] Panel Doubler 6 / Input 014 speed
- [215] Panel Doubler 7 / Input 015 speed
- [216] Panel Doubler 8 / Input 016 speed

## 4.7 EOL ZONES

### SECTION [504]: OPTION [7]

If detection devices connected to hardwired input terminals use 1kΩ end of line resistors, enable option [7] in section [504]. For


more information on the use of EOL resistors, refer to Zone Connections in section 2.11 & section 2.12.

## 4.8 ZONE DOUBLING (ATZ)

### SECTION [504]: OPTION [8]

Enabling the ATZ feature allows you to install two detection devices per hardwired input terminal. Each detection device will have its own zone, display its zone status on the keypad and send separate alarm codes for each zone. The extra zones are recognized as described in Figure 4-5. For information on how to connect the detection devices, please refer to Double Zone Connections in section 2.12. Fire Zones cannot be doubled.

Figure 4-5: ATZ Input Terminal Recognition



# KEYSWITCH PROGRAMMING

The Digiplex Control Panel can support up to 8 keyswitch zones in addition to the 48 standard zones. A keyswitch allows a user to arm or disarm a system by pressing a key or by toggling a keyswitch. The keyswitches are connected to the hardwired input terminals of either the Digiplex control panel, zone expansion modules or the keypad. For more information on the installation of keyswitches, please refer to section 2.14. Keyswitches must be assigned to a keyswitch zone and that zone must be defined as described in this section:

Keyswitch Parameters [149] to [156]:


- Keyswitch Definitions
- Keyswitch Partition Assignment
- Keyswitch Options

The Keyswitch Numbering feature enables you to individually assign each input to any keyswitch zone in the Digiplex system. Please refer to section 5.1 for details. The Keyswitch Parameters define the keyswitch's partition assignment and its arming method (see section 5.2 to section 5.4).

Keyswitch Numbering [049] to [056]:

- Serial # of the Module
- Input # of the Module

Figure 5-1: Keyswitch Programming




## 5.1 KEYSWITCH NUMBERING

### SECTIONS [049] TO [056]

The Keyswitch Numbering feature allows you to assign any hardwired input in the system to any of the 8 keyswitch zones in the Digiplex Control Panel. This feature tells the control panel where the keyswitch is connected and which of the 8 keyswitch zones is assigned to that keyswitch. To assign a keyswitch

connected to a hardwired input terminal, program the module's serial number and the number of the input where the keyswitch is connected into the section corresponding to the desired keyswitch zone (see Figure 5.2 on page 21).

**Figure 5-2: Example of Keyswitch Numbering**



Keyswitch				
	Zone #	Section	Serial#	Input#
Keyswitch A:	1 =	[049]	010000A2	001
Keyswitch B:	2 =	[050]	34000041	002
Keyswitch C:	3 =	[051]	34000041	006

## 5.2 KEYSWITCH DEFINITIONS

Select one of the keyswitch definitions (also see Figure 5-1 on page 20):

### 5.2.1 Keyswitch Disabled

SECTIONS [149] TO [156]: FIRST DIGIT = 0  
Disables keyswitch input.

### 5.2.2 Momentary Keyswitch

SECTIONS [149] TO [156]: FIRST DIGIT = 1  
To arm a partition using the Momentary Keyswitch, turn on the keyswitch for approximately three seconds then turn it off. Repeating this sequence will disarm the system. The selected Keyswitch Option (see section 5.4) determines the type of arming.

### 5.2.3 Maintained Keyswitch

SECTIONS [149] TO [156]: FIRST DIGIT = 2  
To arm a partition using the Maintained Keyswitch, turn the switch from the ON to the OFF position. To disarm a partition set the keyswitch in the ON position. In the case of an *Arm Only* option, the control panel will not perform any action when the switch is in the ON position. The selected Keyswitch Option (see section 5.4) determines the type of arming.

## 5.3 KEYSWITCH PARTITION ASSIGNMENT

SECTIONS [149] TO [156]: SECOND DIGIT = 1 TO 4  
The control panel provides the option of partitioning the security system into two, three, or four completely independent systems.

Therefore, each keyswitch must be assigned to one partition as described in Figure 5-1 on page 20. For more information on Partitioning, refer to section 12.5.

## 5.4 KEYSWITCH OPTIONS

Each keyswitch zone can be programmed with one or more of the options (also see Figure 5-1 on page 20):

### 5.4.1 Stay/Instant Disarm (Keyswitch)

SECTIONS [149] TO [156]: OPTION [4]  
When option [4] is enabled, the keyswitch can only disarm assigned Stay or Instant Armed partitions. The Arm Only Option (see section 5.4.2) must be disabled for this feature to function. When option [4] is disabled, the keyswitch can disarm partitions armed using any arming method.

### 5.4.2 Arm/Disarm (Keyswitch)

SECTIONS [149] TO [156]:  
Option [5] ON = Arm Only  
Option [5] OFF = Arm & Disarm



Only one of the arming options (Stay, Force, Instant and Regular) can be selected.

### 5.4.3 Stay Arming (Keyswitch)

SECTIONS [149] TO [156]: OPTION [6]  
Activating the keyswitch will bypass any zones defined as Stay Zones (see section 4.4.3) in the selected partition. All other zones will remain activated. For more information on Stay Arming, refer to section 16.1.2.

### 5.4.4 Force Arming (Keyswitch)

SECTIONS [149] TO [156]: OPTION [7]  
Activating the keyswitch will arm the selected partition bypassing any open zones defined as Force Zones (see section 4.4.4) at the time of arming. For more information on Force Arming, refer to section 16.1.6.

### 5.4.5 Instant Arming (Keyswitch)

SECTIONS [149] TO [156]: OPTION [8]  
This option is identical to Stay Arming except that all armed zones will become Instant Zones (see section 4.2.4). For more information on Instant Arming, refer to section 16.1.4.

### 5.4.6 Regular Arming (Keyswitch)

SECTIONS [149] TO [156]: OPTION [6] TO [8]  
When options [6] to [8] are off, the keyswitch arming option will default to Regular Arming (see section 16.1.1).

# ARMING & DISARMING OPTIONS

## 6.1 ARMING FOLLOWS PARTITION

### SECTIONS [505], [509], [513], [517]: OPTIONS [1] TO [4]

A partition can be set to follow the arming and disarming status of one or more partitions. If a partition is set to follow more than one partition, the partition will arm when all selected partitions are armed. However, the partition will disarm as soon as one of the selected partitions is disarmed. For more details on how these options are programmed, please refer to the *Programming Guide*.

#### Example:

If options [2] and [3] are on in section [505], Partition 1 will automatically arm whenever partitions 2 and 3 are armed. Partition 1 will disarm when either partition 2 or partition 3 is disarmed.

#### [505] Partition 1:

Option [2] = Partition 1 arms and disarms with Partition 2  
Option [3] = Partition 1 arms and disarms with Partition 3  
Option [4] = Partition 1 arms and disarms with Partition 4

#### [509] Partition 2:

Option [1] = Partition 2 arms and disarms with Partition 1  
Option [3] = Partition 2 arms and disarms with Partition 3  
Option [4] = Partition 2 arms and disarms with Partition 4

#### [513] Partition 3:

Option [1] = Partition 3 arms and disarms with Partition 1  
Option [2] = Partition 3 arms and disarms with Partition 2  
Option [4] = Partition 3 arms and disarms with Partition 4

#### [517] Partition 4:

Option [1] = Partition 4 arms and disarms with Partition 1  
Option [2] = Partition 4 arms and disarms with Partition 2  
Option [3] = Partition 4 arms and disarms with Partition 3

## 6.2 RESTRICT ARMING ON BATTERY/AC FAILURE

### SECTION [503]: OPTION [8]

With option [8] on in section [503], the control panel can restrict arming if the control panel detects an AC failure, battery loss or if the battery voltage is less than 10.5V. The control panel will not arm any partition until all battery/AC trouble conditions are rectified.

## 6.3 NO ARMING ON TAMPER

### SECTION [501]: OPTION [8]

With option [8] on in section [501], the control panel can restrict arming if the control panel detects a tamper on a zone or module (see section 7.4). The control panel will not arm any partition until all tamper trouble conditions are rectified and the Installer Code has been entered to clear the troubles.

## 6.4 NO ARMING ON SUPERVISION LOSS

### SECTION [501]: OPTION [4]

With option [4] on in section [501], the control panel can restrict arming if the control panel receives a supervision loss signal from a

wireless module (see section 7.3). The control panel will not arm any partition until all supervision loss trouble conditions are rectified.

## 6.5 TIMED AUTO-ARMING

### SECTIONS [505], [509], [513], [517]: OPTION [5]

With this option enabled, the control panel will arm the selected partition every day at the time specified by the Auto-Arm Timer (see section 6.5.1). When the partition is automatically armed, the control panel will transmit the *Auto-Arming* report code programmed in section [626]. Any open zones detected when a partition is Auto-Armed will be bypassed regardless of their definition. The type of arming is determined by the *Auto-Arming Option* (see section 6.7). Regardless whether the partition was successfully armed or not, the control panel will always transmit the *Late to Close* report code programmed in section [626]. Please note that the control panel will enter a 60-second Exit Delay period before arming the system. At this point, Auto-Arming can be cancelled by entering a valid access code. Since the control panel can enable this feature for each individual partition, select the section that corresponds to the desired partition and turn on option [5].

[505] = Partition 1            [513] = Partition 3  
[509] = Partition 2            [517] = Partition 4

### 6.5.1 Auto-Arm Timer

#### SECTIONS [271] TO [274]

If Timed Auto-Arming is enabled (see section 6.5), the control panel will send the *Late to Close* report code and attempt to arm the system at the time specified by the Auto-Arm Timer.

Sections [271] to [274] represent timers for partitions 1 through 4 respectively. Select the section corresponding to the partition and program the time you wish the control panel to arm the selected partition and/or send the *Late to Close* report code. Please note that the control panel will enter a 60-second Exit Delay period before arming the system. At this point, Auto-Arming can be cancelled by entering a valid access code.

#### Example:

A user would like to automatically arm partition 2 everyday at 6:15PM. To do so, enable "Timed Auto-Arming" for partition 2 by turning on option [5] in section [509]. Then enter 18:15 in section [272].

## 6.6 NO MOVEMENT AUTO-ARMING

### SECTIONS [505], [509], [513], [517]: OPTION [6]

If no movement occurs in a partition's protected area for the period specified by the No Movement Timer (see section 6.6.1), the control panel will automatically arm that partition. The control panel will transmit the *No Movement* report code programmed in section [626] upon arming. The type of arming is determined by the *Auto-Arming Option* (see section 6.7). Regardless whether the partition was successfully armed or not, the control panel will always transmit the *Late to Close* report code (see section 8.2.2).

As the control panel can enable this feature for each individual partition, select the section that corresponds to the desired partition and turn on option [6].

[505] = Partition 1            [513] = Partition 3  
[509] = Partition 2            [517] = Partition 4

### 6.6.1 No Movement Timer

SECTIONS [222] TO [225]

(001 to 255 X 15min.) If *No Movement Auto-Arming* is enabled (see section 6.6), the control panel can send the *No Movement* report code and attempt to arm the system if no movement has occurred for the period specified by the *No Movement Timer*.

If *No Movement Auto-Arming* is disabled, the control panel can still send the *No Movement* report code.

Sections [222] to [225] represent timers for partitions 1 through 4 respectively. Select the section corresponding to the desired partition and program the time (001 to 255 x15 minutes, 000 = disabled) without movement you wish the control panel to wait before arming and/or sending the *No Movement* report code.

*Example:*

*A user would like to arm partition 1 whenever there is no movement for a period of 4 hours. First, enable the Auto-Arm on No Movement feature for partition 1 by turning on option [6] in section [505]. Then in section [222] enter 016 (16x15min. = 240min. = 4 hours).*

## 6.7 AUTO-ARMING OPTIONS

SECTION [505], [509], [513], [517]: OPTION [7]

When using the Auto-Arming Features (see section 6.5 and section 6.6), the control panel can Force Arm or Stay Arm the selected partition. In the section corresponding to the desired partition set option [7]:

Option [7] ON = Stay Arming (see section 16.1.2)

Option [7] OFF = Force Arming (see section 16.1.6)

## 6.8 ONE-TOUCH FEATURES

[508], [512], [516], [520]: OPTIONS [1] TO [7]

The instructions that follow pertain to LCD and LED keypads. For instructions regarding the Grafica keypad, a complete Grafica user manual is available on our Web site at [www.paradox.ca](http://www.paradox.ca). One-touch Features allow users to perform actions without having to enter access codes. If the keypad is assigned to more than one partition, the option must be enabled in all the corresponding partitions.

Select the section that corresponds to the desired partition and turn the desired one-touch options on or off.

**Regular Arm:** Option [1]

Press and hold the [ARM] key for 2 seconds to Regular Arm (see section 16.1.1).

**Stay Arm:** Option [2]

Press and hold the [STAY] key for 2 seconds to Stay Arm (see section 16.1.2).

**Instant Arm:** Option [3]

Press and hold the [5] key for 2 seconds to Instant Arm (see section 16.1.4).

**Force Arm:** Option [4]

Press and hold the [FORCE] key for 2 seconds to Force Arm (see section 16.1.6).

**Disarm:** Option [5]

Press and hold the [DISARM] key for 2 seconds to Disarm a Stay or Instant armed partition (see section 16.1.8).

**Bypass Programming:** Option [6]

Press and hold the [BYP] key for 2 seconds to perform Bypass Programming (see section 16.2).

**Event Record Display:** Option [7]

Press and hold the [7] key for 2 seconds to access the Event Record Display (see section 16.8).

## 6.9 EXIT DELAY

SECTIONS [226] TO [229]: 001-255 SECONDS

The Exit Delay determines the amount of time a user has to leave the protected area before the control panel arms the partition. Program the Exit Delay from 001 to 255 seconds, where sections [226] to [229] represent partitions 1 through 4 respectively. The Exit Delay applies to all zones in the selected partition except 24Hr. Zones.

### 6.9.1 Exit Delay Termination

SECTIONS [505], [509], [513], [517]: OPTION [8]

The control panel can reduce the Exit Delay to 5 seconds when an Entry Delay zone (see section 4.2.2) is opened and closed during the Exit Delay. Since the control panel can enable this feature for each individual partition, select the section that corresponds to the desired partition and turn on option [8].

*Example:*

*A user arms a partition with an Exit Delay of 45 seconds. After 15 seconds, the user leaves the protected area through the front door (Entry Delay zone). When the door closes, the control panel reduces the remaining Exit Delay from 30 seconds to 5 seconds.*

### 6.9.2 No Exit Delay on Remote Arm

SECTIONS [508], [512], [516], [520]: OPTION [8]

When a user arms by using a remote control from a wireless module (OMN-RCV3), the control panel will cancel the Exit Delay and immediately arm the system.

### 6.9.3 Skip Exit Delay when Arming with Access Card

See section 14.10.2.

## 6.10 KEYPAD LOCK-OUT FEATURE

SECTIONS [220] AND [221]

If a consecutive number of invalid codes are entered into the keypad, the control panel can be set to lockout access from that keypad for a specified period. Program the number of consecutive invalid codes from 001 to 255 (000 = disabled) into section [220]. Program the duration of the keypad lockout from 001 to 255 minutes into section [221]. Although programming 000 into section [221] will not lockout the keypad, the control panel will transmit the *Keypad Lockout* report code programmed in section [705].

## 6.11 MAXIMUM BYPASS ENTRIES

---

### SECTIONS [238] TO [241]

Sections [238] to [241] represent Maximum Bypass Entries for partitions 1 through 4 respectively. Select the section corresponding to the desired partition and enter any value between 001 and 255 (000 = no limit) to determine the maximum number of zones that can be bypassed in a selected partition.

#### Example:

Section [238] is programmed with 010. When in Bypass Programming (see section 16.2), the control panel will not let the user bypass more than 10 zones in partition 1.

## 6.12 DISPLAY “BYPASS” IF ARMED

---

### SECTION [504]: OPTION [5]

When option [5] is enabled, the keypad will not display that there are bypassed zones when the system is armed.

## 6.13 BELL SQUAWK

---

### SECTIONS [507], [511], [515], & [519]: OPTIONS [1] TO [6]

Sections [507], [511], [515], and [519] represent partitions 1 through 4 respectively. Since the control panel can enable the Bell Squawk features for each individual partition, select the section that corresponds to the desired partition and turn on the desired option (when the option is off, the feature is disabled):

#### BELL SQUAWK UPON DISARMING

Option [1] ON

The bell or siren will emit two squawks upon disarming.

#### BELL SQUAWK UPON ARMING

Option [2] ON

The bell or siren will squawk once upon arming.

#### BELL SQUAWK ON AUTO-ARM

Option [3] ON

The bell or siren will squawk at 1-second intervals during the 60 seconds before a partition automatically arms itself. During the final 10 seconds of the 60-second period, the bell or siren will emit three squawks at 1-second intervals.

#### BELL SQUAWK DURING EXIT DELAY

Option [4] ON

The bell or siren will squawk at 1-second intervals during the Exit Delay. During the final 10 seconds of the Exit Delay, the bell or siren will emit three squawks at 1-second intervals.

#### BELL SQUAWK ON ENTRY DELAY

Option [5] ON

The bell or siren will squawk at 1-second intervals during the Entry Delay.

#### BELL SQUAWK ON REMOTE ARMING

Option [6] ON

When using a wireless module (OMN-RCV3), the bell or siren will squawk once upon arming or disarming with a remote control.

## 6.14 RING-BACK

---

### SECTIONS [507], [511], [515], [519]: OPTIONS [7] AND [8]

After disarming the system, the control panel can warn the user that there was an alarm and that it may be dangerous to enter by having the keypad beep 10 times and/or by squawking the bell 10 times. The user should leave immediately and contact the central station from a secure location. Sections [507], [511], [515], and [519] represent partitions 1 through 4 respectively. Since the control panel can enable the *Ring-Back* features for each individual partition, select the section that corresponds to the desired partition and turn on the desired option:

Option [7] ON = Bell Squawk Ring-Back Enabled

Option [8] ON = Keypad Ring-Back Enabled

## 6.15 SWITCH TO STAY ARMING

---

If no Entry Delay zones are opened and closed during the Exit Delay after Regular Arming a partition, the control panel can switch from Regular Arming to Stay Arming (see section 16.1). Since the control panel can enable *Switch to Stay Arming* for each individual partition, select the section that corresponds to the desired partition and turn on the corresponding option as listed below.

Section [505] = Partition 1 = Option [1]

Section [509] = Partition 2 = Option [2]

Section [513] = Partition 3 = Option [3]

Section [517] = Partition 4 = Option [4]

## 6.16 ALWAYS FORCE ARM WHEN REGULAR ARMING

---

### SECTIONS [506], [510], [514], [518]: OPTION [8]

(Default = disabled) When option [8] is enabled for a particular partition, the system will Force Arm that partition whenever Regular or Force arming is activated.



Stay and Instant arming are not affected by this option.

# ALARM OPTIONS

---

## 7.1 BELL/ALARM OUTPUT

---

### SECTION [500]: OPTIONS [5] TO [8]

When a partition generates an alarm, the control panel can toggle the on-board BELL/ALARM output enabling any bells or sirens connected to it. Since the control panel can enable this feature for each individual partition, in section [500] turn on the option that corresponds to the desired partition, where options [5] to [8] represent partitions 1 through 4 respectively.

## 7.2 BELL CUT-OFF TIMER

---

### SECTIONS [234] TO [237]

After an audible alarm, the bell or siren will stop once the partition is disarmed or when the Bell Cut-Off Timer has elapsed. Sections [234] to [237] represent partitions 1 through 4 respectively. Since the control panel can set a Bell Cut-Off Timer for each individual partition, select the section corresponding to the desired partition and enter any value between 001 and 255 minutes (000 = 4 minutes).

### 7.2.1 No Bell Cut-Off on Fire Alarm

#### SECTION [502]: OPTION [8]

The control panel can disable the Bell Cut-Off Timer when alarms are generated from zones defined as Standard or Delayed Fire Zones (see section 4.2). The bell/siren output will remain enabled until a user disarms the partition in alarm.

### 7.2.2 Recycle Alarm Rate

#### SECTIONS [246] TO [249]

Once an alarm has occurred, the control panel will re-verify the zone status at a programmed rate once the Bell Cut-Off Timer and the Recycle Delay have elapsed. If any open zones remain, the control panel will regenerate the alarm. The number of times in one armed period that the control panel will re-verify the zone status after the Bell Cut-off occurs is programmed in sections [246] to [249], which represent partitions 1 through 4. Enter rate from 001 to 255 (000 = no limit).

### 7.2.3 Recycle Delay

#### SECTIONS [242] TO [245]

The Recycle Delay is the amount of time the control panel will wait after the Bell Cut-off occurs before re-verifying the zone status. In the section corresponding to the desired partition, program the Recycle Delay from 001 to 255 minutes (000 = disabled). Sections [242] to [245] represent partitions 1 through 4.

## 7.3 WIRELESS TRANSMITTER SUPERVISION OPTIONS

---

### SECTION [501]: OPTIONS [1] AND [2]

The Supervision feature must be enabled in a wireless module (OMN-RCV3) in order for this feature to function. When the control panel receives a Supervision Loss message (wireless receiver no longer receiving signals from a wireless transmitter) in an armed partition, the control panel will generate an alarm unless the Wireless Transmitter Supervision Options have been disabled. Alarms will be silent or audible depending on individual zone settings.

If a supervision loss occurs in a disarmed partition, the control panel will follow the programmed settings:

### DISABLED

#### [1] OFF and [2] OFF

When a supervision loss occurs, the control panel will display the zone as open in the keypad display, but will not generate an alarm or a trouble. *This option is not permitted on UL systems.*

### TROUBLE ONLY

#### [1] OFF and [2] ON

If a partition is armed, the control panel will generate a standard alarm when a supervision loss occurs. If the partition is disarmed when a supervision loss occurs, the *Zone Fault* trouble will appear in the keypad's Trouble Display and the control panel will transmit the appropriate report code (see section 8.2).

### SILENT ALARM

#### [1] ON and [2] OFF

If a partition is armed, the control panel will generate a standard alarm when a supervision loss occurs. If the partition is disarmed when a supervision loss occurs, the *Zone Fault* trouble will appear in the keypad's Trouble Display, the control panel will transmit the appropriate report code (see section 8.2), and it will also generate a silent alarm (no bells or sirens).

### AUDIBLE ALARM

#### [1] ON and [2] ON

If a partition is armed, the control panel will generate a standard alarm when a supervision loss occurs. If the partition is disarmed when a supervision loss occurs, the *Zone Fault* trouble will appear in the keypad's Trouble Display, the control panel will transmit the appropriate report code (see section 8.2), and it will also generate an audible alarm.

### 7.3.1 Supervision Bypass Options

#### SECTION [501]: OPTION [3]

With option [3] enabled in section [501], the Wireless Transmitter Supervision Options will follow the zone's bypass definition. This means that the control panel will not perform any action if a supervision loss occurs on a bypassed zone. With option [3] disabled, the control panel will ignore the bypass definition and will follow the option set in section 7.3 if a supervision loss occurs on a bypassed zone.

## 7.4 TAMPER RECOGNITION OPTIONS

---

### SECTION [501]: OPTIONS [5] AND [6]

Regardless of the Tamper Recognition Options, if a tamper or wire fault occurs on a zone or on an expansion module in an armed partition, the control panel will **always** generate an alarm unless Tamper Recognition has been disabled. Alarms will be silent or audible depending on individual zone settings.

If a tamper or wire fault occurs on a zone or on an expansion module in a disarmed partition, the control panel will follow the programmed settings:

## TAMPER RECOGNITION DISABLED

[5] OFF and [6] OFF

If a partition is armed, the control panel will generate a standard alarm when a tamper or wire fault occurs. If the partition is disarmed, the control panel will display the zone as open in the keypad display, but will not generate an alarm or a trouble. *This option is not permitted on UL systems.*

## TROUBLE ONLY

[5] ON and [6] OFF

If a partition is armed, the control panel will generate a standard alarm when a tamper or wire fault occurs. If the partition is disarmed when a tamper or wiring failure occurs, the appropriate trouble will appear in the keypad's Trouble Display and the control panel will transmit the appropriate report code (see section 8.2).

## SILENT ALARM

[5] OFF and [6] ON

If a partition is armed, the control panel will generate a standard alarm when a tamper or wire fault occurs. If the partition is disarmed when a tamper or wiring failure occurs, the appropriate trouble will appear in the keypad's Trouble Display, the control panel will transmit the appropriate report code (see section 8.2), and it will generate a silent alarm (no bells or sirens).

## AUDIBLE ALARM

[5] ON and [6] ON

If a partition is armed, the control panel will generate a standard alarm when a tamper or wire fault occurs. If the partition is disarmed when a tamper or wiring failure occurs, the appropriate trouble will appear in the keypad's Trouble Display, the control panel will transmit the appropriate report code (see section 8.2), and it will generate an audible alarm.

### 7.4.1 Tamper Bypass Options

SECTION [501]: OPTION [7]

With option [7] enabled in section [501], Tamper Recognition follows the zone bypass definition. This means that the control panel will not perform any action if a tamper or wire fault occurs on a bypassed zone. With option [7] disabled, the control panel will ignore the zone's bypass definition and will follow the option set in section 7.4 if a tamper or wire fault occurs on a bypassed zone.

## 7.5 KEYPAD PANIC OPTIONS

SECTIONS [506], [510], [514], [518]: OPTIONS [1] TO [6]

Since the control panel can enable Keypad Panic Options for each partition, select the section that corresponds to the desired partition

and set options [1] through [6] on/off to obtain the desired options. Sections [506], [510], [514], and [518] represent partitions 1 to 4 respectively.

### PANIC 1:

Option [1] ON/OFF= Enabled/Disabled

Option [4] ON = Panic 1 is Audible

Option [4] OFF = Panic 1 is Silent

**For LCD keypads:** Press and hold keys [1] and [3] simultaneously on the LCD keypad for 2 seconds to generate a Panic 1 alarm.

**For Grafica keypads:** Press and hold the  key on the Grafica keypad for 2 seconds to generate a Panic 1 (Medical) alarm.

### PANIC 2:

Option [2] ON/OFF= Enabled/Disabled

Option [5] ON = Panic 2 is Audible

Option [5] OFF = Panic 2 is Silent

**For LCD keypads:** Press and hold keys [4] and [6] simultaneously on the LCD keypad for 2 seconds to generate a Panic 2 alarm.

**For Grafica keypads:** Press and hold the  key on the Grafica keypad for 2 seconds to generate a Panic 2 (Auxiliary) alarm.

### PANIC 3:

Option [3] ON/OFF= Enabled/Disabled

Option [6] ON = Panic 3 is Pulsed (Fire)

Option [6] OFF = Panic 3 is Silent

**For LCD keypads:** Press and hold keys [7] and [9] simultaneously on the LCD keypad for 2 seconds to generate a Panic 3 alarm.

**For Grafica keypads:** Press and hold the  key on the Grafica keypad for 2 seconds to generate a Panic 3 (Fire) alarm.

### SILENT OPERATION

The control panel emits a single Confirmation Beep and transmits the appropriate report code (see section 8.2.5) to the central station.

### AUDIBLE OPERATION


The alarm output (bell/siren) activates until a user cancels the alarm with a valid User Access Code or when the Bell Cut-Off Timer elapses (see section 7.2).

### FIRE OPERATION

Same as audible operation, except that the bell/siren output will be pulsed as shown in Figure 4-4 on page 16.

# EVENT REPORTING

**Figure 8-1: Event Reporting**



## 8.1 REPORTING ENABLED

### SECTION [521]: OPTION [3]

This option will either enable or disable event reporting. With option [3] on in section [521], Event Reporting will be enabled. When an event (e.g. zone in alarm) occurs in the system, the control panel verifies if a report code was programmed in the section corresponding to the event. If a report code is programmed, the control panel will dial the central station telephone number defined by the Event Call Direction feature. When the central station answers, the control panel will transmit the system account code, followed by the programmed report code.

## 8.2 REPORT CODES

A report code is a 2-digit or 1-digit hexadecimal value, consisting of digits from 0 to F. Each section from [600] to [718] represents a set of four specific events. Each of these events can be programmed with a 1-digit or 2-digit report code. For a comprehensive list of the events and their relevant sections, please refer to the *Digiplex Programming Guide*. Please note that only the Ademco Slow, Silent Knight, Sescoa and Pager Formats support 1-digit report codes.

When a specific event occurs, the control panel will send the programmed report code to the central station. The method of report code transmission is defined by the following two items: **Reporting Formats** (see section 8.5) and **Event Call Direction** (see section 8.6). These two items define how and where the report codes are transmitted. If you are using the Ademco CID or SIA formats, an Auto Report Code Programming feature is available. Using this feature, sections [600] to [718] do not have to be manually programmed (see section 8.13). The following sub-sections provide a brief description of the events that the control panel can report:

### 8.2.1 Arming Report Codes

#### SECTIONS [600] TO [625]

A report code can be programmed for each of the 96 User Access Codes and 8 keyswitch zones. When using an access code or keyswitch to arm one or more partitions, the control panel can send the appropriate report code to the central station identifying which access code or keyswitch zone was used to arm the partition(s).

### 8.2.2 Special Arming Report Codes

#### SECTIONS [626] TO [627]

Whenever the system is armed using one of the special arming features, the control panel can send the appropriate report code to the central station identifying how the system was armed.

#### Section [626]

- Auto-Arming (see section 6.5)
- PC Arming: system armed using WinLoad (see section 15)
- Late to Close (see section 6.5)
- No Movement (see section 6.6)

#### Section [627]

- Partial Arming: when partitions are Stay Armed, Instant Armed or armed with bypassed zones
- Quick Arming: partitions armed using any of the One-Touch Arming features (see section 6.8)

### 8.2.3 Disarming Report Codes

#### SECTIONS [628] TO [653]

A report code can be programmed for each of the 96 User Access Codes and 8 keyswitch zones. Whenever an access code or keyswitch is used to disarm one or more partitions, the control panel can send the appropriate report code to the central station identifying which access code or keyswitch was used to disarm the partition(s). The control panel can transmit the report codes every time a partition is disarmed or only when disarmed following an alarm. Please refer to Disarm Reporting Options in section 8.10.

### 8.2.4 Special Disarming Report Codes

#### SECTION [654]

Whenever using one of the special disarming features listed below, the control panel can send the report code to the central station identifying how the system was disarmed. The control panel can transmit the report codes every time a partition is disarmed or only when disarmed following an alarm. Please refer to Disarm Reporting Options in section 8.10.

#### Section [654]

- Cancel Auto-Arm: if a user disarms the partition during the Auto-Arm 60-second delay
- Quick Disarm: partitions disarmed using the One-Touch Disarming feature (see section 6.8)
- PC Disarm: when WinLoad is used to disarm the system

### 8.2.5 Zone Alarm Report Codes

#### SECTIONS [655] TO [666]

A report code can be programmed for each of the 48 available zones. Whenever a zone generates an alarm, the control panel can send the appropriate report code to the central station identifying which zone generated an alarm.

### 8.2.6 Zone Restore Report Codes

#### SECTIONS [667] TO [678]

A report code can be programmed for each of the 48 available zones. The control panel can transmit these report codes to the central station when the zone closes after generating an alarm or once the bell has cut-off after alarm generation (see section 7.2). Please refer to Zone Restore Report Options in section 8.11.

### 8.2.7 Special Alarm Report Codes

#### SECTIONS [679] TO [680]

Whenever the system generates an alarm due to one of the conditions listed below, the control panel can send the appropriate report code to the central station identifying the type of alarm.

#### Section [679]

- Emergency Panic (Panic 1): if Panic 1 has been activated (see section 7.5)
- Auxiliary Panic (Panic 2): if Panic 2 has been activated (see section 7.5)
- Fire Panic (Panic 3): if Panic 3 has been activated (see section 7.5)
- Recent Closing: if after having armed the system, an alarm is generated within the *Recent Close Delay* (see section 8.7)

### Section [680]

- Auto Zone Shutdown: a zone communicates more than the programmed number of transmissions in a single armed period (see section 4.4.1)
- Duress: a Duress enabled access code is keyed in (see section 13.5.2).

### 8.2.8 Zone Tamper Report Codes

#### SECTION [681] TO [692]

A report code can be programmed for each of the 48 available zones. Whenever a tamper or wire fault occurs on a zone, the control panel can send the appropriate report code to the central station identifying which zone was tampered. If the Tamper Recognition Options (see section 7.4) are disabled, the control panel will not report the occurrence of any tampers or wire faults.

### 8.2.9 Zone Tamper Restore Codes

#### SECTIONS [693] TO [704]

A report code can be programmed for each of the 48 available zones. Whenever a tampered zone is restored, the control panel can send the appropriate report code to the central station identifying which zone has been restored.

### 8.2.10 Special Tamper Report Codes

#### SECTION [705]

- Keypad Lockout: (see section 6.10)

### 8.2.11 System Trouble Codes

#### SECTIONS [706] TO [711]

##### Section [706]

- AC Failure: no AC input detected on the control panel. The control panel can delay reporting this event, please refer to Power Fail Report Delay in section 8.9.
- Battery Failure: the back up battery is disconnected or the battery voltage is less than or equal to 10.5V
- Auxiliary Supply: the auxiliary power supply's current is greater than or equal to 1.1A.

##### Section [707]

- Bell Output: the bell/siren output is disconnected or the current is greater than or equal to 3A
- Clock Loss: the control panel detects a loss in panel time (see section 12.7)
- Fire Loop Trouble: a tamper has been detected on a fire zone (see section 4.2)
- N/A

##### Section [708]

- Combustion Fault: a module has been removed from the combus.
- Module Tamper: a tamper or wire fault is detected on a module other than a motion detector connected to the combus
- ROM Check Error: problem with on-board Read-Only Memory
- Module TLM: TLM failure detected on voice dialer connected to the combus

### Section [709]

- Module Fail to Communicate: a module has failed to communicate with the central station
- Printer Fault: the Printer Module connected to the combus has detected an error (see the Printer Module Manual for details).
- Module AC Failure: no AC power detected on a module connected to the combus
- Module Battery Failure: the backup battery on a module is disconnected or the battery voltage is low

### Section [710]

- Module Auxiliary Failure: the auxiliary output of a module connected to the combus has exceeded current limits
- Wireless Transmitter Low Battery
- Wireless Module Supervision Failure: This report code is global unless using the Contact ID or SIA reporting formats.

### Section [711]

- Phone Number 1 Fail to Communicate
- Phone Number 2 Fail to Communicate
- Phone Number 3 Fail to Communicate
- Phone Number 4 Fail to Communicate

Please note: there is no Fail to Communicate for Pager telephone numbers.

### 8.2.12 System Trouble Restore Codes

#### SECTION [712] TO [716]

##### Section [712]

- TLM: a TLM failure has restored.



***If the Telephone Line Monitoring (see section 9.1) is disabled, the control panel will not transmit the TLM report code.***

- AC Failure Restored
- Battery Failure Restored
- Auxiliary Supply Restored

##### Section [713]

- Bell Output Restored
- Time programmed
- Fire Loop Trouble Restored
- N/A

##### Section [714]

- Combustion Fault Restored
- Module Tamper Restored
- ROM Check Error Restored
- Module TLM Restored

##### Section [715]

- N/A
- Printer Fault Restored
- Module AC Failure Restored
- Module Battery Failure Restored

##### Section [716]

- Module Auxiliary Failure Restored
- Wireless Transmitter Low Battery Restored
- Wireless Module Supervision Restored: This report code is global unless using the Contact ID or SIA Reporting formats.

### 8.2.13 Special Reporting Codes

#### SECTION [717] AND [718]

Whenever the system generates one of the following instances, the control panel can send the appropriate report code to the central station identifying the type of system occurrence:

#### Section [717]

- Cold Start: the control panel was completely shutdown (total power loss) and the control panel was re-started
- Warm Start: the control panel performs a reset due to any sudden problem other than power loss
- Test Report: report generated automatically (see section 8.8)

#### Section [718]

- WinLoad Access: the panel ended communication with WinLoad
- Installer In: installer has entered the programming mode
- Installer Out: installer has exited the programming mode

## 8.3 CENTRAL STATION PHONE #

#### SECTIONS [561] TO [564]

The Digiplex Control Panel can dial up to 4 different central station telephone numbers. Sections [561] to [564] represent central station telephone numbers 1 to 4 respectively. You can enter any digit from 0 to 9 and any special-function key (see Table 10, *Special Telephone Number Keys*) up to a maximum of 32 digits. Refer to Event Call Direction in section 8.6 and Reporting Formats in section 8.5 for details on how these telephone numbers are used.



**For North American installations using either SIA or Contact ID reporting formats (see section 8.5), enter \*70 and then either P (4-second pause) or W (wait for second dial tone) before the phone number to disable call-waiting.**

**Table 10: Special Telephone Number Keys**

Function	LCD	Grafica
*	[STAY]	[#] (press key until desired letter/symbol appears)
#	[FORCE]	
Switch to Tone Dialing (T)	[ARM]	
Wait for second dial tone (W)	[DISARM]	
4-second pause (P)	[BYP]	
Clear	[CLEAR]	Left action key (Clear)
Delete	[TRBL]	—
Delete from cursor to the end	[ACC]	—

## 8.4 PARTITION ACCOUNT #

#### SECTIONS [551] TO [554]

All report codes are preceded by a 4-digit or 3-digit Partition Account Number to ensure correct identification of active zones in a partitioned system. Sections [551] to [554] represent the Partition Account Codes for partitions 1 through 4. Partition account numbers can be any hexa-digit from 0 to F.

#### Example:

*If a zone generates an alarm in Partition 1, the control panel will send Partition Account Number 1 followed by the report code.*



**Only SIA formats support the “0” digit in its account numbers. For account numbers that use another reporting format, you must replace the “0” with an “A”. To enter an “A”, press the [STAY] key on LCD keypads or the [#] key on Grafica keypads. When using the SIA Format, the control panel will only use Partition Account Number 1 programmed in section [551], but the report code will include the partition number.**

## 8.5 REPORTING FORMATS

#### SECTION [550]

The Digiplex Control Panel can use a number of different reporting formats and each of the four Central Station Phone Numbers (see section 8.3) should be programmed with the same reporting format unless it is combined with a Pager format. The first digit entered into section [550] represents the reporting format (see Table 11, *Reporting Formats*) used to communicate with central station telephone number 1, the second digit represents telephone number 2 and so forth.

**Table 11: Reporting Formats**

0 = Ademco slow (1400Hz, 1900Hz, 10BPS)
1 = Silent Knight fast (1400Hz, 1900Hz, 20BPS)
2 = SESCOA (2300Hz, 1800Hz, 20BPS)
3 = Ademco Express (DTMF 4+2)
4 = Reserved for future use
5 = Ademco Contact ID
6 = SIA FSK
7 = Pager

### 8.5.1 Standard Pulse Formats

The Digiplex Control Panel can use the Ademco slow, Silent Knight fast and SESCOA standard pulse reporting formats (see Table 11, *Reporting Formats*).

### 8.5.2 Ademco Express

The Ademco Express is a high-speed reporting format that communicates 2-digit (00 to FF) report codes programmed into sections [600] to [718]. Unlike other Ademco formats, the Ademco Express does not use the Contact ID Report Codes.

### 8.5.3 Ademco Contact ID

Ademco Contact ID is a fast communicator format that uses tone reporting instead of pulse reporting. This communicator format also uses a pre-defined list of industry standard messages and report codes that will suit most of your basic installation needs. To manually program the report codes, key in the 2-digit hexadecimal values from the *Contact ID Report Codes List* in the *Programming Guide* into the desired report codes in sections [600] to [718] (see section 8.2). You can also enter 00 to disable reporting or FF to use the default report code from the *Automatic Report Code List* in the *Programming Guide*. To automatically program a set of default Contact ID codes, refer to section 8.13.

### 8.5.4 SIA FSK

SIA FSK is a fast communicator format that uses tone reporting instead of pulse reporting. This communicator format uses a pre-defined list of industry standard messages and report codes that will suit most of your basic installation needs. To manually program

the report codes, enter 00 to disable reporting or any other value to use the default report code from the *Automatic Report Code List* in the *Programming Guide*. To automatically program a set of default SIA FSK codes, refer to section 8.13.

### 8.5.5 Pager Reporting Format

Using this format allows the control panel to transmit report codes to a pager. A pound symbol “#” is automatically generated after the report code. Please refer to Pager Delay in section 8.12.

## 8.6 EVENT CALL DIRECTION

---

### SECTIONS [522] TO [536]

As shown in Figure 8-1 on page 27, the control panel events are divided into three event groups for each partition and two global event groups. Each event group can be programmed to dial up to four central station telephone numbers and to use one of the four telephone numbers as a backup. The numbers are dialed sequentially starting from 1, skipping any disabled numbers and stopping once all selected telephone numbers have been reached. If the control panel still fails to report to a central station telephone number after reaching the Maximum Dialing Attempts (see section 8.6.1), the control panel will dial the selected backup telephone number unless the Alternate Backup Option is enabled (see section 8.6.3). When the Alternate Backup Option is enabled, the control panel will dial the backup number after every failed attempt.

### 8.6.1 Maximum Dialing Attempts

#### SECTION [257]

The number (001 to 255) programmed into section [257] determines how many times the control panel will dial the same central station telephone number before proceeding to the next number. Also refer to section 8.6.3.

### 8.6.2 Delay Between Dialing Attempts

#### SECTION [258]

This delay will determine the amount of time the control panel will wait between dialing attempts. This delay can be set from 001 to 255 seconds.

### 8.6.3 Alternate Backup Option

#### SECTION [522]: OPTION [6]

With option [6] enabled in section [522], the control panel will dial the selected backup telephone number after every failed attempt to contact a central station telephone number. Otherwise (option [6] off), the control panel will only dial the backup telephone number after the Maximum Dialing Attempts (see section 8.6.1) to one central station telephone number have failed.

## 8.7 RECENT CLOSE DELAY

---

### SECTION [219]

If after having armed the system, an alarm is generated within the period programmed into section [219] (000 to 255 seconds), the control panel will transmit the *Recent Close* report code programmed into section [679].

## 8.8 AUTO TEST REPORT

---

### SECTIONS [261] AND [270]

The control panel will transmit the test report code programmed into section [717] after the number of days (000 to 255)

programmed into section [261] has elapsed and at the time (00:00 to 23:59) programmed into section [270].

### 8.8.1 Hourly Test Transmission

#### SECTION [522]: OPTION [3]

Alternatively, the control panel can transmit the test report code programmed into section [717] every hour. Turn off option [3] to disable this feature. Program the minute of each hour (00:00 to 00:59) it sends the test report into section [270].

## 8.9 POWER FAIL REPORT DELAY

---

### SECTION [260]

The control panel will delay transmission of the *AC Failure* report code programmed into section [712] by the period programmed into section [260] (000 to 255 minutes).

## 8.10 DISARM REPORTING OPTIONS

---

### SECTIONS [506], [510], [514], [518]: OPTION [7]

Since the control panel can enable the Disarm Reporting Options for each individual partition, select the section that corresponds to the desired partition and turn option [7] on or off as desired. Sections [506], [510], [514], [518] represent partitions 1 to 4 respectively.

#### REPORT ON DISARM AFTER ALARM ONLY

##### Option [7] ON

The DigiPlex Control Panel will send Disarming Report Codes (see section 8.2.3) to the central station only when the system is disarmed following an alarm.

#### REPORT ON DISARM

##### Option [7] OFF

The DigiPlex Control Panel will send the Disarming Report Codes (see section 8.2.3) to the central station whenever a partition is disarmed.

## 8.11 ZONE RESTORE REPORT OPTIONS

---

### SECTION [522]: OPTION [8]

#### REPORT ON ZONE CLOSURE

##### Option [8] ON

The control panel will send the *Zone Alarm Restore* report codes (see section 8.2.6) to the central station as soon as the zone returns to normal (zone closure) or upon disarming

#### REPORT ON BELL CUT-OFF

##### Option [8] OFF

The control panel will send the *Zone Alarm Restore* report codes (see section 8.2.6) to the central station when the Bell Cut-Off Timer has elapsed or when the alarm has been disarmed (see section 7.2).

## 8.12 PAGER DELAY

---

### SECTION [259]

When using the Pager Reporting Format (see section 8.5.5), the control panel will wait for the delay period programmed into section [259] (001 to 060 seconds) before uploading the report codes to

the pager. This is to allow time for the pager system to provide a dial tone or to bypass the welcome message before sending data.

## 8.13 AUTO REPORT CODE PROGRAMMING

---

### SECTIONS [790] TO [795]

When using either the Contact ID or SIA Reporting Formats (see section 8.5), the Digiplex system can automatically program a set of default report codes. From programming mode (see section 3.1) enter any of the following sections to set the indicated report codes:

#### ALL CODES

##### Section [790]

Sets all report codes in sections [600] to [718] with the default values from the *Automatic Report Codes List* in the *Programming Guide*.

#### ARMING & DISARMING CODES

##### Section [791]

Sets all report codes in sections [600] to [654] with the default values from the *Automatic Report Codes List* in the *Programming Guide*.

#### ALARM RESTORE CODES

##### Section [792]

Sets all report codes in sections [655] to [680] with the default values from the *Automatic Report Codes List* in the *Programming Guide*.

#### TAMPER & TAMPER RESTORE CODES

##### Section [793]

Sets all report codes in sections [681] to [705] with the default values from the *Automatic Report Codes List* in the *Programming Guide*.

#### TROUBLE RESTORE CODES

##### Section [794]

Sets all report codes in sections [706] to [716] with the default values from the *Automatic Report Codes List* in the *Programming Guide*.

#### SPECIAL CODES

##### Section [795]

Sets all report codes in sections [717] to [718] with the default values from the *Automatic Report Codes List* in the *Programming Guide*.

Please note that even after automatic report codes have been set, you can still use the manual programming method (see section 8.5.3 & section 8.5.4) to program remaining report codes or change some of the defaults.

# DIALER OPTIONS

---

## 9.1 TELEPHONE LINE MONITORING

---

### SECTION [521]: OPTIONS [1] AND [2]

When enabled, the system verifies the existence of a telephone line once every second. A line test failure occurs when the TLM detects less than 3 volts for the period defined by the TLM Fail Timer (see section 9.1.1). If the line test fails, the panel will generate one or more conditions as defined by the TLM settings below, until the control panel detects the telephone line again. Please note that when the dialer detects a telephone ring, the TLM test stops for 1 minute.

### TLM DISABLED

[1] OFF and [2] OFF

### TROUBLE ONLY

[1] ON and [2] OFF

Upon line test failure, the *Communicator* trouble will appear in the keypad's Trouble Display.

### ALARM IF SYSTEM ARMED

[1] OFF and [2] ON

Upon line test failure, the *Communicator* trouble will appear in the keypad's Trouble Display and the control panel will generate an alarm if the system is armed.

### SILENT ALARM BECOMES AUDIBLE

[1] ON and [2] ON

Upon line test failure, the *Communicator* trouble will appear in the keypad's Trouble Display and cause a *Silent Alarm* zone or *Silent* panic alarm to switch to an audible alarm.

### 9.1.1 TLM Fail Timer

#### SECTION [255]

If the TLM does not detect the existence of a telephone line for the time programmed in this section, the control panel will generate the condition(s) defined by the TLM options (see section 9.1). Enter any value between 016 and 255 (value is X2 seconds) into section [255]. Entering a value between 000 and 016 will set the TLM Fail Timer to 32 seconds.

## 9.2 TONE/PULSE DIALING

---

### SECTION [521]: OPTION [4]

Option [4] ON = the control panel can dial using the tone/DTMF format.

Option [4] OFF = the control panel will use the pulse dialing format. Refer to section 9.3 for setting the pulse ratio.

## 9.3 PULSE RATIO

---

### SECTION [521]: OPTION [5]

When using Pulse dialing (see section 9.2), you can select one of two Pulse Ratios. Although most European countries use the 1:2 pulse ratio, the 1:1.5 ratio may provide better results in some cases. The same applies for North American countries. If the 1:1.5 pulse ratio is not providing the desired results, the 1:2 ratio may be used.

Option [5] ON = North American pulse ratio of 1:1.5

Option [5] OFF = European pulse ratio of 1:2

## 9.4 BUSY TONE DETECTION

---

### SECTION [521]: OPTION [6]

Option [6] ON = the control panel can immediately hang up if it receives a busy signal when dialing an outside number.

Option [6] OFF = feature disabled

## 9.5 SWITCH TO PULSE

---

### SECTION [521]: OPTION [7]

Option [7] ON = When reporting events to the central station, the control panel can switch from tone dialing to pulse dialing on the fifth attempt. The control panel continues to use pulse dialing until it establishes communication. If switching to another central station telephone number, the control panel will return to tone dialing and will switch back to pulse dialing on the fifth attempt.

Option [7] OFF = Feature disabled

## 9.6 BELL ON COMMUNICATION FAIL

---

### SECTION [521]: OPTION [8]

Option [8] ON = If the control panel fails to communicate with the central station when the system is armed, the control panel can enable the BELL output, which will set off any bells or sirens connected to the output.

Option [8] OFF = Feature disabled

## 9.7 DIAL TONE DELAY

---

### SECTION [522]: OPTION [7]

Option [7] ON = Dialer will hang up if no dial tone is present after 32 seconds

Option [7] OFF = Dialer will continue to dial if no dial tone is present after 3 seconds. If more time is required, you can insert a 4-second pause into the desired telephone number sequence (see section 8.3).

# PROGRAMMABLE OUTPUTS

A PGM is a programmable output that toggles to its opposite state (i.e. a normally open PGM will close) when a specific event has occurred in the system.

*For example, a PGM can be used to reset smoke detectors, activate strobe lights, open/close garage doors and much more.*

When a PGM closes, the control panel supplies a ground to the PGM activating any device or relay connected to it. When a PGM opens, the circuit opens from ground therefore not providing any power to devices connected to it. The control panel provides a maximum of 100mA to PGM1 and 50mA to PGMs 2, 3 and 4. PGM1 to PGM4 are normally open outputs and PGM5 is a normally open or normally closed 5A relay. For information on how to connect a relay to a PGM, please refer to section 2.9.

## 10.1 PGM ACTIVATION EVENT

SECTIONS [400], [402], [404], [406], AND [408]

The PGM Activation Event will activate the selected PGM when a specific event or events occur in the system. The control panel can set separate activation events for each PGM.

*For example, the control panel can be programmed to activate PGM2 whenever the system is Force Armed.*

To program a PGM activation event:

- 1) Enter the section that represents the desired PGM.  
PGM1 = [400]      PGM4 = [406]  
PGM2 = [402]      PGM5 = [408]  
PGM3 = [404]
- 2) Enter the first digit (see *PGM Programming Table* on page 36) where each digit from 0 to F represents a specific group of events.
- 3) Enter the second digit, which can be any digit from 0 to F depending on the first digit.
- 4) After entering the second digit, use the Feature Select method (enable/disable options [1] to [8]) to select up to eight specific events as detailed in the *PGM Programming Table*.

If you select a group and set all options to OFF, all users/zones/selections of that group will be enabled (result is "ANY" of that group).

*For example, if you select A0, and set all 8 options to OFF, the PGM will activate whenever a user between 1 and 8 arms the system.*


For details on the available activation events please refer to the *PGM Programming Table* on page 36. Below you will find brief details on just a few of the available activation events:

**Smoke Reset:** Deactivates the PGM for a period of 4 seconds every time the [CLEAR] and [ENTER] (LCD keypad) or [\*] and [#] (Grafica keypad) keys are pressed simultaneously and held for 2 seconds. Please refer to section 2.15.3 for instructions on

connecting the PGM in order to perform a smoke detector reset. Program First Digit = [4], Second Digit = [1], then [5] on.

**Ground Start:** Just before the control panel attempts to dial an outside line when using ground start telephone equipment, the PGM will activate for the period defined by the PGM Delay (see section 10.3.1). Please note that the PGM Deactivation Option must be set to Timed (see section 10.3). Program First Digit = [4], Second Digit = [1], then [6] on.

Figure 10-1: Ground Start Circuit



**Kissoff:** After receiving a handshake from the central station, the control panel activates the PGM for the period defined by the PGM Delay (see section 10.3.1). This can be used to latch the central station connection to another device such as a microphone/speaker module. Please note that the PGM Deactivation Option must be set to Timed (see section 10.3). Program First Digit = [4], Second Digit = [1], then [7] on.

**Strobe:** Activates the PGM whenever the system is in alarm. The PGM will remain activated even after Bell Cut-off and will wait until the alarm is cancelled before deactivating the PGM. Program First Digit = [1], Second Digit = choose [PARTITION] (0 = all enabled partitions, 8 = any enabled partition), then [5] on.

## 10.2 PGM DEACTIVATION EVENT

SECTIONS [401], [403], [405], [407], AND [409]

If the PGM Deactivation Option is set to Follow (see section 10.3), the PGM will deactivate when the programmed event occurs unless the first digit of the PGM Activation Event is 1 to 7. To program a PGM Deactivation Event:

- 1) Enter the section that represents the desired PGM.  
PGM1 = [401]      PGM4 = [407]  
PGM2 = [403]      PGM5 = [409]  
PGM3 = [405]
- 2) Enter the first digit (see *PGM Programming Table* on page 36) where each digit from 0 to F represents a specific group of events.
- 3) Enter the second digit, which can be any digit from 0 to F depending on the first digit.

- 4) After entering the second digit, use the Feature Select method (enable/disable options [1] to [8]) to select up to eight specific events as detailed in the *PGM Programming Table*.

If you select a group and set all options to OFF, all users/zones/selections of that group will be enabled (result is "ANY" of that group).

*For example, if you select A0, and set all 8 options to OFF, the PGM will deactivate whenever a user between 1 and 8 arms the system.*

If the PGM Deactivation Option is set for Timed (see section 10.3), the PGM will ignore the PGM Deactivation Event.

## 10.3 PGM DEACTIVATION OPTION

---

### SECTION [502]: OPTIONS [1] TO [5]

Once the PGMs are activated (see section 10.1) they will deactivate according to the options programmed in section [502]. Options [1] to [5] represent PGMs 1 to 5 respectively. Each PGM can be set to Follow or Timed by turning the option representing the PGM on or off:

*For example, if option [1] is on in section [502], then PGM1 is set to Timed.*

### FOLLOW

#### Option OFF

- 1) If the first digit of the PGM Activation Event is set at 1, 2, 3, 4 or 7, the PGM will remain activated until the PGM Activation Event has ended. It will ignore the PGM Deactivation Event.
- 2) If the first digit of the PGM Activation Event is set at 8, 9, A, B, C, D, E, or F, the PGM will remain activated until the PGM Deactivation Event occurs.

### TIMED

#### Option ON

After activating the PGM, the control panel will start the PGM Delay Timer (see section 10.3.1) and the PGM will deactivate only when the PGM Delay Timer has elapsed and will ignore the PGM Deactivation Event.

### 10.3.1 PGM Delay Timers

#### SECTIONS [250] TO [254]

To program the PGM Delay Timers, enter the section that corresponds to the desired PGM, where sections [250] to [254] represent PGM1 to PGM5 respectively, and enter a value from 001 to 255. The value entered is either in seconds or minutes as determined by the PGM Time Base Selection (see section 10.3.2).

### 10.3.2 PGM Time Base Selection

#### SECTION [503]: OPTIONS [1] TO [5]

The PGM Time Base Selection determines whether the Delays programmed in sections [250] to [254] are in minutes or seconds. Options [1] to [5] represent PGMs 1 to 5 respectively. Each PGM Delay Timer can be set to minutes or seconds by turning the options on or off in section [503]:

Option ON = Minutes

Option OFF = Seconds

## 10.4 PGM1 IS SMOKE INPUT

---

### SECTION [502]: OPTION [7]

Enabling option [7] in section [502] will set PGM1 to act as a zone input for two-wire smoke detectors. When programming Zone Numbering (see section 4.1), the control panel will recognize PGM1 as input number 255. For more information on how to connect two-wire smoke detectors, please refer to section 2.15.1

# PGM PROGRAMMING TABLE

**\*Note1:** 0 = All partitions enabled in the system (see section 12.5)  
 1 = Partition 1    3 = Partition 3  
 2 = Partition 2    4 = Partition 4  
 8 = Any partition enabled in the system (at least one)

First Digit	Event	Second Digit	Feature Select Programming								
			1	2	3	4	5	6	7	8	
0	PGM Disabled	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
1	Status 1	Note 1*	Any Arming Method	Force Arm	Stay Arm	Instant Arm	Strobe <small>(until alarm is cancelled)</small>	Silent Alarm <small>(until alarm is cancelled or bell is cut off)</small>	Audible Alarm <small>(until alarm is cancelled or bell is cut off)</small>	Fire Alarm <small>(until alarm is cancelled or bell is cut off)</small>	
2	Status 2	Note 1*	Ready Status	Exit Delay	Entry Delay	Trouble	Alarm Memory	Zones Bypassed <small>(armed or not)</small>	User or Installer Programming	Keypad Lockout	
3	Status 3	Note 1*	Intellizone Delay	Fire Delay	Auto-Arm Delay	Access	Any Zone Tamper	Zone Low Battery	Fire Loop	Zone Supervision	
4	Status 4	0	Chime Partition 1	Chime Partition 2	Chime Partition 3	Chime Partition 4	Siren Partition 1	Siren Partition 2	Siren Partition 3	Siren Partition 4	
		1	N/A	N/A	N/A	N/A	Smoke Reset	Ground Start	Kissoff	N/A	
		2	System Trouble	Comm. Trouble	Module Trouble	Combustion Trouble	N/A	N/A	N/A	N/A	Clock Loss
		3	AC Fail	Battery Fail	Aux. Limit	Bell Limit	Bell Absent	ROM Error	N/A	N/A	N/A
		4	TLM	Fail to Com1	Fail to Com2	Fail to Com3	Fail to Com4	Fail to ComPC	N/A	N/A	N/A
		5	Module Tamper	Module ROM Error	Module TLM	Module Fail to Com Phone#	Printer Fault	Module AC Fail	Module Battery Fail	Module Aux. Fail	
		6	Missing Keypad	Any Module Missing	N/A	N/A	N/A	Global Combustion Failure	Combustion Overload	Module Combustion Com Fail	
7	At the Selected Time	0	00:00	00:15	00:30	00:45	01:00	01:15	01:30	01:45	
		1	02:00	02:15	02:30	02:45	03:00	03:15	03:30	03:45	
		2	04:00	04:15	04:30	04:45	05:00	05:15	05:30	05:45	
		3	06:00	06:15	06:30	06:45	07:00	07:15	07:30	07:45	
		4	08:00	08:15	08:30	08:45	09:00	09:15	09:30	09:45	
		5	10:00	10:15	10:30	10:45	11:00	11:15	11:30	11:45	
		6	12:00	12:15	12:30	12:45	13:00	13:15	13:30	13:45	
		7	14:00	14:15	14:30	14:45	15:00	15:15	15:30	15:45	
		8	16:00	16:15	16:30	16:45	17:00	17:15	17:30	17:45	
		9	18:00	18:15	18:30	18:45	19:00	19:15	19:30	19:45	
		A	20:00	20:15	20:30	20:45	21:00	21:15	21:30	21:45	
B	22:00	22:15	22:30	22:45	23:00	23:15	23:30	23:45			
8	Utility Keys	0	Keys 1 & 2	Keys 4 & 5	Keys 7 & 8	LCD: <small>(CLEAR &amp; 0)</small>  Grafica: <small>(* &amp; 0)</small>	Keys 2 & 3	Keys 5 & 6	Keys 8 & 9	LCD: <small>(0 &amp; ENTER)</small>  Grafica: <small>(0 &amp; #)</small>	

First Digit	Event	Second Digit	Feature Select Programming								
			1	2	3	4	5	6	7	8	
9	Access Granted	0	Door 01	Door 02	Door 03	Door 04	Door 05	Door 06	Door 07	Door 08	
		1	Door 09	Door 10	Door 11	Door 12	Door 13	Door 14	Door 15	Door 16	
		2	Door 17	Door 18	Door 19	Door 20	Door 21	Door 22	Door 23	Door 24	
		3	Door 25	Door 26	Door 27	Door 28	Door 29	Door 30	Door 31	Door 32	
	User Code Entered	8	Code 01	Code 02	Code 03	Code 04	Code 05	Code 06	Code 07	Code 08	
		9	Code 09	Code 10	Code 11	Code 12	Code 13	Code 14	Code 15	Code 16	
		A	Code 17	Code 18	Code 19	Code 20	Code 21	Code 22	Code 23	Code 24	
		B	Code 25	Code 26	Code 27	Code 28	Code 29	Code 30	Code 31	Code 32	
		C	Code 33	Code 34	Code 35	Code 36	Code 37	Code 38	Code 39	Code 40	
		D	Code 41	Code 42	Code 43	Code 44	Code 45	Code 46	Code 47	Code 48	
		E	Code 49	Code 50	Code 51	Code 52	Code 53	Code 54	Code 55	Code 56	
		F	Code 57	Code 58	Code 59	Code 60	Code 61	Code 62	Code 63	Code 64	
	A	Arming	0	Code 01	Code 02	Code 03	Code 04	Code 05	Code 06	Code 07	Code 08
			1	Code 09	Code 10	Code 11	Code 12	Code 13	Code 14	Code 15	Code 16
2			Code 17	Code 18	Code 19	Code 20	Code 21	Code 22	Code 23	Code 24	
3			Code 25	Code 26	Code 27	Code 28	Code 29	Code 30	Code 31	Code 32	
4			Code 33	Code 34	Code 35	Code 36	Code 37	Code 38	Code 39	Code 40	
5			Code 41	Code 42	Code 43	Code 44	Code 45	Code 46	Code 47	Code 48	
6			Code 49	Code 50	Code 51	Code 52	Code 53	Code 54	Code 55	Code 56	
7			Code 57	Code 58	Code 59	Code 60	Code 61	Code 62	Code 63	Code 64	
Disarming		8	Code 01	Code 02	Code 03	Code 04	Code 05	Code 06	Code 07	Code 08	
		9	Code 09	Code 10	Code 11	Code 12	Code 13	Code 14	Code 15	Code 16	
		A	Code 17	Code 18	Code 19	Code 20	Code 21	Code 22	Code 23	Code 24	
		B	Code 25	Code 26	Code 27	Code 28	Code 29	Code 30	Code 31	Code 32	
		C	Code 33	Code 34	Code 35	Code 36	Code 37	Code 38	Code 39	Code 40	
		D	Code 41	Code 42	Code 43	Code 44	Code 45	Code 46	Code 47	Code 48	
	E	Code 49	Code 50	Code 51	Code 52	Code 53	Code 54	Code 55	Code 56		
	F	Code 57	Code 58	Code 59	Code 60	Code 61	Code 62	Code 63	Code 64		
B	Zone is OK	0	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08	
		1	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16	
		2	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24	
		3	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32	
		4	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40	
		5	Zone 41	Zone 42	Zone 43	Zone 44	Zone 45	Zone 46	Zone 47	Zone 48	
	Zone is Open	8	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08	
		9	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16	
		A	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24	
		B	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32	
		C	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40	
		D	Zone 41	Zone 42	Zone 43	Zone 44	Zone 45	Zone 46	Zone 47	Zone 48	

First Digit	Event	Second Digit	Feature Select Programming							
			1	2	3	4	5	6	7	8
C	Auto Zone Shutdown	0	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08
		1	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16
		2	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24
		3	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32
		4	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40
		5	Zone 41	Zone 42	Zone 43	Zone 44	Zone 45	Zone 46	Zone 47	Zone 48
	Zone Bypass (when system is armed)	8	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08
		9	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16
		A	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24
		B	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32
		C	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40
D	Zone Fault (Tamper/Fire Loop)	0	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08
		1	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16
		2	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24
		3	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32
		4	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40
		5	Zone 41	Zone 42	Zone 43	Zone 44	Zone 45	Zone 46	Zone 47	Zone 48
	RF Zone Fault (Low Battery Supervision)	8	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08
		9	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16
		A	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24
		B	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32
		C	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40
E	Fire or Burglar Alarms	0	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08
		1	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16
		2	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24
		3	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32
		4	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40
		5	Zone 41	Zone 42	Zone 43	Zone 44	Zone 45	Zone 46	Zone 47	Zone 48
	Fire or Burglar Restore	8	Zone 01	Zone 02	Zone 03	Zone 04	Zone 05	Zone 06	Zone 07	Zone 08
		9	Zone 09	Zone 10	Zone 11	Zone 12	Zone 13	Zone 14	Zone 15	Zone 16
		A	Zone 17	Zone 18	Zone 19	Zone 20	Zone 21	Zone 22	Zone 23	Zone 24
		B	Zone 25	Zone 26	Zone 27	Zone 28	Zone 29	Zone 30	Zone 31	Zone 32
		C	Zone 33	Zone 34	Zone 35	Zone 36	Zone 37	Zone 38	Zone 39	Zone 40
F	Module Troubles	0	Combus Fault	Module Tamper	ROM Error	Module TLM	Fail to Com	Printer Fault	AC Fail	Battery Fail
		1	Aux. Output Fail	N/A	N/A	N/A	N/A	N/A	N/A	N/A
		8	Combus Fault Restore	Module Tamper Restore	ROM Error Restore	Module TLM Restore	Fail to Com. Restore	Printer Fault Restore	AC Fail Restore	Battery Fail Restore
		9	Aux. Fail	N/A	N/A	N/A	N/A	N/A	N/A	N/A

## 12.1 HARDWARE RESET

Performing a hardware reset will set all programmable sections from [001] to [718] to default values, including the Installer Code and System Master Code. Only the Panel ID, PC Password, PC Telephone Number and Event Buffer will not be reset.

- 1) Make sure the Installer Code Lock is disabled (see section 12.4)
- 2) Remove the battery and AC power from the control panel.
- 3) Set the RESET jumper to on by placing a jumper on the reset pins of the control panel.
- 4) Re-connect the AC power and the battery to the control panel.
- 5) Wait 10 seconds and remove the jumper.

## 12.2 SOFTWARE RESET

Performing a software reset will set certain parameters to default values or program certain sections with a set of pre-defined values.

To do so:

- 1) Make sure the RESET jumper on the control panel is on.
- 2) Enter *Panel Programming Mode* (see section 3.1).
- 3) Enter the 3-digit [SECTION] corresponding to the software reset you wish to perform:

### Section [970]

Entering this section will reset all programmable sections from [001] to [896] (except sections [451] to [498], [555], [556], [560], [790] to [795], and [800]) to default values. The Zone Labels, Panel ID, PC Password, PC Telephone Number, Installer Code, System Master Code, Event Buffer, and Automatic Report Codes will not be reset.

### Section [974]

Entering this section resets the following Access Control sections: [301] to [332], [340] to [355], [361] to [375], [381] to [392], and [537].

### Section [975]

Entering this section will reset all Zone and Keyswitch programming sections from [001] to [056], and [101] to [156] to default values.

### Section [976]

Entering this section will reset the following sections to default values: [200] to [261], [270] to [274], [400] to [409], and [440] to [442].

### Section [977]

Entering this section will reset sections from [500] to [522] to default values.

### Section [978]

Entering this section will reset the following communication sections to default values: [521] to [536], [550] to [554], [561] to [564], and [600] to [718].

### Section [979]

Entering this section will reset all user code sections from [801] to [896] to default values.

## 12.3 BATTERY CHARGE CURRENT

### SECTION [503]: OPTION [6]

Option [6] ON = Battery Charge Current: 700mA (minimum 40VA transformer)

Option [6] OFF = Battery Charge Current: 350mA

## 12.4 INSTALLER CODE LOCK

### SECTION [990]

Enter 147 into section [990] to lock all programming. When 147 is programmed in section [990], performing a hardware reset as described in section 12.1 will not affect the current panel settings. To remove the Installer Lock, enter 000 into section [990]. (Default: Unlocked)

## 12.5 PARTITIONING

### SECTION [500]: OPTIONS [1] TO [4]

The Digiplex Control Panel can provide your system with up to four completely independent partitions. Most features and options in the Digiplex System can be independently set for each partition such as Event Reporting, Entry/Exit Delay, Bell Squawk, One-touch Arming, Panic Alarms and many more. All zones, keyswitch zones, user codes and system modules are assigned to specific partitions, making this a true partitioned system. In section [500], enable the option(s) that correspond to the desired partition(s). Where options [1] to [4] represent partitions 1 through 4.

### 12.5.1 Panel Partition Assignment

#### SECTION [440]

The control panel will report system events as originating from the partitions enabled in this section. The System Troubles (i.e. AC Failure, TLM Failure, etc.) can only be viewed through the partitions enabled in this section.

00 = All enabled partitions (see section [500])

01 = Control Panel installed in Partition 1

02 = Control Panel installed in Partition 2

03 = Control Panel installed in Partition 3

04 = Control Panel installed in Partition 4

## 12.6 INSTALLER FUNCTION KEYS

To access the installer functions, press and hold the [0] key, enter the [INSTALLER CODE], and then...

**For LCD keypads:** press the key indicated in the list below that corresponds to the function you wish to activate.

**For Grafica keypads:** press the center action key (**Options**), highlight the desired function and then press the left action key (**Select**).

### TEST REPORT: [STAY]

Sends the *Test Report* report code programmed in section [717] to the central station.

### CALL WINLOAD: [FORCE]

Will dial the PC telephone number programmed in section [560] to communicate with a computer using WinLoad.

### ANSWER WINLOAD: [ARM]

Will force the control panel to answer a call made by the Central Monitoring Station that is using WinLoad.

### CANCEL COMMUNICATION: [DISARM]

Pressing this function key cancels all communication with the Central Station or WinLoad until the next reportable event.

### INSTALLER TEST MODE: [MEM]

The Installer Test Mode will allow you to perform walk tests where the bell or siren will squawk to indicate opened zones. Press [MEM] again to exit. Partitions cannot be armed if the Installer Test Mode is enabled.

### MODULE SCAN: [TRBL]

This feature instructs the control panel to verify the status of the modules connected to the combus. The control panel will fix any problems with the internal organization of the modules in the control panel. The keypads will display the serial number of each module that has been connected to the combus.

### COMBUS VOLTMETER: [ACC]

LCD keypads (DGP2-641) only.

To verify if the combus is supplying sufficient power, press and hold the [0] key, enter the [INSTALLER CODE] and press the [ACC] key on the LCD keypad. A reading of 9.2V indicates that the voltage is too low. The voltage may drop during the control panel battery test (see section 2.4.1).

## 12.7 SYSTEM DATE & TIME

### SECTION [502]: OPTION [6]

The System Date and Time is programmed through the User Menu, please refer to Clock Loss section 16.7.

### 12.7.1 Daylight Savings Time

By enabling option [6] in section [502], the control panel will automatically adjust the system's clock (time) for daylight saving changes. At 2:00AM on the first Sunday of a full weekend in April, the control panel will add one hour to the programmed time (clock). At 2:00AM on the last Sunday of a full weekend in October, the control panel will subtract one hour from the programmed time (clock).

## 12.8 SHABBAT FEATURE

### SECTION [522]: OPTION [4]

With option [4] on, all addressable detection devices and keypads in the system will no longer display any system status through the LCD and/or LEDs between noon (12:00PM) Friday and midnight (12:00AM) Saturday. Therefore, normal operation will be re-instated Sunday morning at 12:00:01AM.

During the Shabbat period:

- the LCD keypads only display the date and time
- the backlight is disabled
- the LED indicators on all addressable detection devices and keypads in the system are disabled

If required, a user can access all the usual commands and features during the Shabbat period by pressing a key or, if Confidential Mode is enabled in the keypad, by entering their access code. When no actions have occurred for two minutes, the Shabbat Feature will re-activate.

## 12.9 MODULE RESET

### SECTION [951]

To reset a module that is connected to the combus to its default values, key in the module's serial number into section [951].

## 12.10 LOCATE MODULE

### SECTION [952]

If you wish to locate a specific module (e.g. detector, zone expansion module, etc.) connected to the combus, key in the module's serial number into section [952]. The green LOCATE LED on the module will begin to flash until the serial number is re-entered into section [952] or the appropriate tamper or unlocate switch on the module is pressed.

## 12.11 MODULE PROGRAMMING

### SECTION [953]

All modules connected to the combus are programmed through the control panel. Therefore, if you wish to program a module, enter section [953] to enter *Module Programming Mode* (see section 3.2) and key in the module's serial number. At this point, any sections entered will be those of the selected module. For details on how to program the modules, refer to the module's Installer's Guide or the module's *Programming Guide*. To exit this mode, press the [CLEAR] key on LCD keypads, or the right action key (**Exit**) on Grafica keypads, as many times as needed to return to the desired screen.

## 12.12 MODULE BROADCAST

### SECTION [954]

This feature allows you to copy the contents of all programming sections from one module to one or more of the same type of module.



**The Module Broadcast feature will only work when a module is broadcasting its data to a module or to modules of the same type and model number. For example, an APR-PRT1 (Printer Module) cannot broadcast to an APR3-PRT1. Likewise, a DGP module cannot broadcast to a DGP2 module.**

- 1) Press and hold the [0] key.
- 2) Enter the [INSTALLER CODE] (Default is 000000).
- 3) Enter [954].
- 4) Enter the source module's 8-digit [SERIAL NUMBER].
- 5) Enter the destination module's 8-digit [SERIAL NUMBER]. Repeat this step once for every additional module.
- 6) For LCD keypads, press [ACC]. For Grafica keypads, press the center action key (**Start**).

**For example:** Using an LCD keypad, you've completed the programming of a zone expansion module (sn#34540033) and you wish to program another two zone expansion modules (sn#34540075 and sn#34412100) with the same settings:

- 1) Press and hold the [0] key.
- 2) Enter the [INSTALLER CODE].
- 3) Enter [954].
- 4) Enter 34540033, 34540075, and 34412100.
- 5) Press [ACC].

The control panel will automatically copy the contents of 34540033 into the other two zone expansion modules.

## 12.13 REMOVE MODULE

---

### SECTION [955]

After entering section [955], the control panel will scan all modules connected to the combus. If any missing modules are detected (i.e. detector removed from the combus) during this scan, the control panel will erase the module's serial number and remove the module from the control panel's memory.

## 12.14 SERIAL NUMBER VIEWING

---

### SECTION [900]

This feature allows you to view the serial number of the control panel as well as the serial numbers of all modules connected to the combus.

**For LCD keypads:** After entering section [900], the keypad will display the 8-digit serial number of the control panel. Use the [▲] and [▼] keys to scroll through the serial number of each module connected to the combus.

**For Grafica keypads:** After entering section [900], the keypad will display the 8-digit serial number of the control panel. Press the center action key (Next) to scroll through the serial number of each module connected to the combus.

## 12.15 POWER SAVE MODE

---

### SECTION [504]: OPTIONS [4]

When the control panel is running on the backup battery (no AC), the control panel can set all keypads into a "sleep mode" or Power Save Mode. In Power Save Mode the keypad's backlight and LEDs will be disabled until a key is pressed, an alarm occurs or an Entry Delay is triggered.

## 12.16 AUTO TROUBLE SHUTDOWN

---

### SECTION [218]

If, in a 24-hour period, a trouble has occurred more than the number of times programmed in section [218], the control panel will no longer report this trouble. Enter a value (001 to 015, 000 = disabled) into section [218]. Please note that each trouble has its own counter. This counter is reset every day at midnight or when a *Module Scan* is performed (see section 12.6). Also, note that it cannot be set to more than 15.

## 12.17 No AC FAIL DISPLAY

---

### SECTION [503]: OPTION [7]

With option [7] in section [503] enabled, the control panel will not display the AC Failure as a trouble. This means that when an AC Failure occurs when this option is on:

- the AC LED will extinguish
- the trouble will not appear in the Trouble Display
- the keypad will not beep to indicate the trouble
- the AC Failure report code will be reported.

# ACCESS CODES

The Digiplex control panel supports 95 User Access Codes, 1 System Master Code, and 1 Installer Code.

## 13.1 INSTALLER CODE

### SECTION [800]

(Default: 000000) The Installer Code is used to enter the control panel's programming mode, which allows you to program all the features, options and commands of the control panel and any modules connected to the combus. **The Installer Code can program the User Code Options and the Partition Assignment, but cannot program the personal identification numbers.** The Installer Code is six digits in length where each digit can be any value from 0 to 9.

To change the Installer Code:

- 1) Press and hold [0].
- 2) Enter [INSTALLER CODE].
- 3) Enter section [800].
- 4) Enter new 6-digit [INSTALLER CODE].

## 13.2 ACCESS CODE LENGTH

### SECTION [504]: OPTIONS [2] AND [3]

Access codes can be between 1 and 6 digits in length. When programming access codes with less than 6 digits, press the [ENTER] key. When you change the User Access Code Length from 4 digits to 6 digits, the control panel will automatically add the last 2 digits by using the first 2 digits. For example, if your Access Code is 1234 and you switch to 6 digits the code will become 123412. When you change the Access Code Length from 6 digits to 4 digits, the control panel will automatically remove the last 2 digits.

[2]	[3]	Option
Off	Off	4-digit Access Codes
Off	On	6-digit Access Codes
On	Off	Same as On/On
On	On	Flexible Access Codes

## 13.3 SYSTEM MASTER CODE

(Default: 123456) With the System Master Code a user can use any of the available arming methods with access to all partitions and can program all User Access Codes, User Options, Partition Assignments, and Access Control Options.

Each digit in the System Master Code can be any value from 0 to 9. The length of the System Master Code is determined by the Access Code Length feature (see section 13.2). The System Master Code cannot be set to less than 4 digits in length.

### 13.3.1 System Master Code Reset

#### SECTION [950]

To reset the System Master Code to its default (123456):

- Set the RESET jumper to on by placing a jumper on the reset pins of the control panel
- Use the Installer Code to enter section [950]



Do not remove the power from the control panel.

## 13.4 PROGRAMMING ACCESS CODES

### Sections [801] to [896]


The instructions that follow detail how to program access codes when using an LCD keypad. For instructions on how to program users when using a Grafica keypad, refer to Grafica's User Manual. A complete Grafica user manual is available on our Web site at [www.paradox.ca](http://www.paradox.ca). In section [801] the installer can program the System Master Code with an Access Card's serial number and change the Access Card's arming method (see section 13.7).

In sections [802] to [896], the Installer Code can program the User Code Options, Partition Assignment, and Access Control Options, but cannot program the user code for the System Master Code or the User Access Codes. To program the User Access Codes, refer the users to the appropriate manual: LCD Keypad System Manager's Manual and LED Keypads User Manual. If no partition assignment is selected, the User Access Code will **only** be able to activate PGMs.



To program user labels, refer to the LCD Keypad System Manager's Manual.

Figure 13-1: Programming User Access Codes



## 13.5 USER OPTIONS

The User Options define how each User Access Code can arm or disarm the system. Regardless of these settings, all users can Regular Arm (see section 16.1) their assigned partitions and all users, except those with the *Arm Only* option (see section 13.5.4), can disarm an assigned partition. Select one or more of the options described in the following sub-sections for each User Access Code as shown in Figure 13-1 on page 42. The System Master Code or a User Access Code with the Master Feature enabled can also program the User Options using a different programming method. To program the User Access Codes, refer the users to the appropriate Manual: LCD Keypad System Manager's Manual or LED Keypad User Manual.

### 13.5.1 Master Feature

SECTIONS [802] TO [896]: OPTIONS [1] AND [2]

[1]	[2]	Option
Off	Off	Master Feature Disabled
Off	On	Master Feature Disabled
On	Off	Users can create or modify User Access Codes that have the same partition assignment.
On	On	Users can create or modify User Access Codes with the same partition assignment and program the User Options and Partition Assignment (assigns only partitions the Master Feature Code has access to).

### 13.5.2 Duress

SECTIONS [802] TO [896]: OPTION [3]

When a user is forced to arm or disarm their system, entering a Duress enabled User Access Code (option [3] On) will arm or disarm the system and, if programmed, will immediately transmit a silent alarm to the Central Station.

### 13.5.3 Bypass Programming

SECTIONS [802] TO [896]: OPTION [4]

The User Access Code with option [4] enabled can program bypass entries as described in section 16.2.

### 13.5.4 Arm Only

SECTIONS [802] TO [896]: OPTION [5]

The User Access Code with option [5] enabled can arm assigned partitions, but cannot disarm any partitions. The type of arming is determined by the other User Options selected. Please note that with the Arm Only option, the user who just armed the system can cancel arming by re-entering the same User Access Code during the Exit Delay.

### 13.5.5 Stay & Instant Arming

SECTIONS [802] TO [896]: OPTION [6]

The User Access Code with option [6] enabled, can Stay Arm or Instant Arm (see section 16.1) assigned partitions.

### 13.5.6 Force Arming

SECTIONS [802] TO [896]: OPTION [7]

The User Access Code with option [7] enabled will be able to Force Arm assigned partitions (see section 16.1).

### 13.5.7 User Menu Access Conditions

SECTIONS [802] TO [896]: OPTION [8]

This feature will govern which partitions users have access to when entering their access codes. With option [8] on, the control panel

will grant access to all partitions assigned to the User Access Code. With option [8] off, the control panel will only grant access to partitions that have been assigned to both the User Access Code and the keypad.

## 13.6 USER PARTITION ASSIGNMENT

SECTIONS [802] TO [896]: OPTIONS [1] TO [4]

Each of the 95 User Access Codes can be assigned to one or more partitions. A user can only arm, disarm and view status of the partitions assigned to their User Access Codes. Select one or more of the partitions for each User Access Code as shown in Figure 13-1 on page 42. If no partition assignment is selected, the User Access Code will **only** be able to activate PGMs. The System Master Code or a user with the Master Feature enabled can also program the User Partition Assignment using a different method of programming (see section 16.4).

## 13.7 ACCESS CONTROL

SECTIONS [801] TO [896]

In addition to the User Access Code options, the following options can be programmed when Access Control is enabled on the Digiplex system: Access Level, Schedule, Access User Options, and Access Card.



The System Master Code and User Access Codes with the Full Master feature enabled can also program the Access Level, Schedule, Access User Options, and Access Card on User Access Codes.



***The System Master Code in section [801] has access to all doors all the time. Only the card's serial number and the choice of arming method can be changed. If the other options are changed, the System Master Code will revert to its original programming.***

### 13.7.1 Access Level Assignment

SECTIONS [802] TO [896]: LEVEL & SCHEDULE SCREEN, FIRST BRACKETS

Enter the two-digit Access Level number (00 to 15) to be assigned to that User Access Code. Access Levels are defined in the sections [341] to [355] (see section 14.6). An Access Level is a combination of Access Doors that a User Access Code assigned to that level will be able to open. Access Level [00] will permit access to all Access Doors (unrestricted Access Level).

### 13.7.2 Schedule Assignment

SECTIONS [802] TO [896]: LEVEL & SCHEDULE SCREEN, SECOND BRACKETS

Enter the two-digit Schedule number (00 to 15) to be assigned to that User Access Code. Schedules determine the hours, days, and holidays that a User Access Code will be allowed to open Access Doors. The Schedules are defined in the sections [361] to [375] (see section 14.7). Schedule [00] will permit access at all times (unrestricted hours and days).

### 13.7.3 Activate Card for Access Control

SECTIONS [802] TO [896]: ACCESS OPTION SCREEN, OPTION [1]  
Option [1] ON = The Access Card is activated and can be used when the Access Control is enabled.

Option [1] OFF = The User Access Code can be used with the Digiplex alarm system, but cannot use the Access Control features. This can be used to disable a lost or stolen card **without** deleting the User Access Code.

### 13.7.4 Disarm with Access Card

SECTIONS [802] TO [896]: ACCESS OPTION SCREEN, OPTION [2]  
When the partition assigned to an Access Door (see section 14.4) is armed, it can be disarmed and unlocked upon presentation of a valid Access Card to the reader. For an Access Card to be valid, it must be presented during its assigned Schedule, within its assigned Access Level and be assigned to the access control module's assigned partitions depending on the Door Access Mode (see section 14.5). Codes assigned with the "Arm Only" User Option will not be able to disarm with the card.

Option [2] ON = The Access Card can disarm partitions.


Option [2] OFF = The Access Card cannot disarm partitions.

### 13.7.5 Card with Extended Unlocked Period

SECTIONS [802] TO [896]: ACCESS OPTION SCREEN, OPTION [3]  
Each Access Control Module is programmed with a Door Unlocked Period and a Door Unlocked Period Extension. The Door Unlocked Period is the time the door can remain unlatched after access is granted or after a Request for Exit is received. The Door Unlocked Period Extension is the amount of time added to the Door Unlocked Period. For more details refer to the appropriate *Digiplex Module Reference & Installation Manual*.

When Card with Extended Unlocked Period is enabled, the two time periods are added together to allow extra time for the user to open the Access Door, which may be useful for seniors and for the physically challenged. Access is only granted during the card's assigned Schedule and to doors programmed in its Access Level.  
Option [3] ON = Extended Unlocked Period is enabled on card  
Option [3] OFF = Extended Unlocked Period is disabled on card

Example:



### 13.7.6 Arming with Access Card

SECTIONS [802] TO [896]: ACCESS OPTION SCREEN, OPTIONS [4], [5], [6], AND [7]

An Access Card can be programmed to arm the partition(s) assigned to the door when the valid card is presented to the reader twice within approximately 5 seconds while the door remains closed. For an Access Card to be valid, it must be presented during its assigned Schedule, within its assigned Access Level and be assigned to the keypad's assigned partitions depending on the Door Access Mode (see section 14.5). The arming method is determined by turning ON or OFF one of the options from [5] to [7].

#### NO ARMING WITH CARD

Option [4] OFF = Arming with Access Card is disabled.

#### REGULAR ARMING WITH CARD

Option [4] ON and Options [5], [6], & [7] OFF = The Access Card can Regular Arm partitions (see section 16.1).

#### STAY ARMING WITH CARD

Options [4] and [5] ON and Options [6] and [7] OFF = The Access Card can Stay Arm the partitions (see section 16.1).

#### INSTANT ARMING WITH CARD

Options [4] and [6] ON and Options [5] and [7] OFF = The Access Card can Instant Arm the partitions (see section 16.1).

#### FORCE ARMING WITH CARD

Options [4] and [7] ON and Options [5] and [6] OFF = The Access Card can Force Arm the partitions (see section 16.1).

### 13.7.7 Access to Armed Access Doors

SECTIONS [802] TO [896]: ACCESS OPTION SCREEN, OPTION [8]  
An Access Door can be assigned to a zone in Digiplex so it can be protected by the security system as well (see section 14.4). When a valid Access Card with this feature enabled is presented to an armed door, access will be granted and the Entry Delay will begin. When this option is enabled, extra security is provided since a user **must** enter a User Access Code to disarm the area. Access is only granted during the card's assigned Schedule and to doors programmed in its Access Level. For User Access Codes assigned with the "Arm Only" User Option, option [8] should remain off since they cannot disarm the partition(s).

For this feature to function properly, Option [2] Disarm with Access Card must be disabled. If option [2] is enabled, access will be granted and the partition(s) will be disarmed without entering the User Access Code.

Option [8] ON = Access to armed doors is granted

Option [8] OFF = Access to armed doors is denied

### 13.7.8 Access Card Assignment

SECTIONS [801] TO [896]: ACCESS CARD SCREEN

The Access Card is activated by assigning its serial number to the User Access Code. This system supports only the proximity cards by Position Technology. Either enter the serial number manually or present the Access Card to the reader and its serial number will register automatically.

## 13.8 MULTIPLE ACTION FEATURE

SECTION [504]: OPTION [1]

By enabling option [1] in section [504], users will remain in the User Menu after entering their access code. This allows users to perform more than one action without having to re-enter their access code. With option [1] off in section [504], the control panel will exit the User Menu after every action.

# ACCESS CONTROL

---

Access control is an industry term for a system that monitors and regulates the passage into and out of protected areas. With access control, you can identify who accesses a site and limit the days and times that specific people can enter and exit that site.

Each door in the access control system is equipped with a reader, an access control module, a request-for-exit motion detector, a door contact and an electronic door strike. These devices work together with the control panel to unlock the door only for authorized personnel at authorized periods of time.

Each person who is authorized to access the protected area is issued a card. The card is assigned to a User Access Code and programmed with an Access Level (see section 14.6) and a Schedule (see section 14.7). When a card is presented to the reader, the control panel will determine whether or not to unlock the door depending on if the card is allowed to open that door (Access Level) and if the card is permitted at that particular time and day (Schedule).

Access Control features can only be enabled and programmed through the LCD Keypad (DGP2-641) and setup through an Access Control Module (DGP2-ACM1P). The general Access Control options are programmed in the control panel. Specific options for each door are programmed through the LCD keypads (see the appropriate *Digiplex Module Reference & Installation Manual*).

In order to program the Access Control features in the Digiplex Control Panel, you must enter Panel Programming Mode:

- Step 1: Press and hold the **[0]** key.
- Step 2: Enter the **[INSTALLER CODE]** (by default 000000)
- Step 3: Panel Programming Mode: Enter desired 3-digit **[SECTION]**
- Step 4: Enter the required **[DATA]**.

## 14.1 PROGRAMMING ACCESS CONTROL OVERVIEW

---

The following is the minimum required to program an Access Control system. Depending on the requirements of the installation, some of the other features explored in the this chapter may be necessary.

- Step 1: Enable Access Control in section **[537]** option **[1]**
- Step 2: Assign the modules to Doors in sections **[301]** to **[332]**
- Step 3: Create the Access Levels in sections **[341]** to **[355]**
- Step 4: Set the Holidays in sections **[381]** to **[392]**
- Step 5: Create the Schedules in sections **[361]** to **[375]**
- Step 6: Program User Access Code with Access Control Options in sections **[801]** to **[896]**

## 14.2 COMMON ACCESS CONTROL TERMS

---

### ACCESS ALARM:

An audible or silent warning generated by the reader to indicate that a protected door has not closed within the programmed time allowed or that a protected door was opened without an "Access Granted" or "Request for Exit" signal.

### ACCESS CARD:

A tag assigned to a User Access Code used to identify the user to the Access Control system. By presenting the tag to a reader, the system can verify whether the tag is valid.

### DOOR LEFT OPEN:

Each Access Door is programmed with a period of time it is allowed to remain open. Once the door has been open past this time limit, an Access Alarm will be triggered.

### FORCED DOOR:

If a protected door was opened without an "Access Granted" or "Request for Exit" signal, a silent or audible Access Alarm can be triggered.

### READER:

An Access Control device (Posiprox CR-R880) normally located near a protected door that serves to relay the information from an Access Card presented to it to the control panel.

### REQUEST FOR EXIT:

When a REX device (Paradoor 460) installed above an Access Door within a protected area detects movement, it sends a signal to the panel to permit a user to leave the protected area.

### VALID CARD:

An Access Card presented to a reader during its assigned Schedule and within its assigned Access Level.

## 14.3 ENABLE ACCESS CONTROL

---

### SECTION [537]: OPTION [1]

When Access Control is enabled, the control panel and the keypads must be programmed for the feature to function properly. Option **[1]** ON = Access Control is enabled.  
Option **[1]** OFF = Access Control feature is disabled. (default)

## 14.4 ASSIGNING THE MODULE TO A DOOR

---

### SECTIONS [301] TO [332]

Each door to be monitored and controlled requires an Access Control Module (DGP2-ACM1P). The module is assigned to the door through the module's serial number in these sections. You can assign up to 32 Access Control Modules in a Digiplex system. The Access Doors are then combined to determine the Access Levels. If you want the Access Doors also to be linked to the alarm system, assign the keypad zone input to a zone in the control panel (see section 4).

## 14.5 DOOR ACCESS MODE

---

### SECTION [340]

Although the keypad can be programmed to display the status of various partitions, the Access Door can be assigned to one or more partition(s) in the alarm system. This means that the actions performed with the Access Card will be directly linked to the partition(s) assigned to that door. For more details refer to *Partition Assignment* and *Assigning Doors to Partitions* in the appropriate *Digiplex Module Reference & Installation Manual*.

Each door can be programmed to grant access only to cards assigned to **all** the door's assigned partitions ("AND" Door Access Mode) **or** to cards assigned to **at least one** of the door's partitions ("OR" Door Access Mode). For an "AND" Access Door to grant access or to arm all its assigned partitions, the Access Card must be assigned to all the door's assigned partitions. To access an "OR" Access Door, the Access Card must be assigned to at least one partition assigned to the door. An "OR" door will arm or disarm only the partitions that it has in common with the card.

Section [340] consists of four screens of eight options each. Each option represents an Access Door. Enable the option corresponding to the door to be set in "OR" Door Access Mode. Options that remain disabled represent doors set in the "AND" Door Access Mode. For example, if option [2] in the Second Screen is enabled in section [340], Door 10 will use the "OR" Door Access Mode.

Option ON = "OR" Door Access Mode  
 Option OFF = "AND" Door Access Mode (default)

## 14.6 ACCESS LEVELS

### SECTIONS [341] TO [355]

Users will only be allowed access to the doors assigned in the Access Level programmed on their User Access Codes (see section 13.7.1). Each Access Level is a combination of the Access Doors that were assigned in sections [301] to [332]. You can program up to 15 different Access Levels (from 01 to 15). Level 00 allows the user access to all the Access Doors. Using *Feature Select Programming*, enable or disable options representing the desired doors. For example, if the options representing doors 01, 02, and 03 are enabled in section [341], any User Access Code or Access Card assigned to Level 01 will only have access to doors 01, 02, and 03.

## 14.7 SCHEDULES

### SECTIONS [361] TO [375]

Schedules determine the hours, days, and holidays that users are permitted access. You can program up to 15 different Schedules (from 01 to 15). Schedule 00 allows the user access at all times. Each Schedule consists of two programmable time periods called Intervals that determine the time of day and which days the users will be granted access. When a schedule is programmed with "H", users will have access during the days programmed in the sections [381] to [392] (see section 14.8). Each user is assigned a Schedule through the User Access Code.

Program the Start Time and End Time according to the 24-hour clock within the same day. Use *Feature Select Programming* to set the options representing the Days.

Option	Day	Option	Day
[1]	Sunday (S)	[5]	Thursday (T)
[2]	Monday (M)	[6]	Friday (F)
[3]	Tuesday (T)	[7]	Saturday (S)
[4]	Wednesday (W)	[8]	Holidays (H)

For example, program Schedule 01 in section [361]:

- Interval A with Start time **07:00**, End time **16:00**, Days **M, T, W, T, and F**
- Interval B with Start time **10:00**, End time **17:00**, Days **S, S, and H**

Then, any User Access Code with this Schedule assigned will only be allowed access Monday to Friday from 7AM to 4PM and on Saturday, Sunday, and Holidays from 10AM to 5PM.

## 14.8 HOLIDAY PROGRAMMING

### SECTIONS [381] TO [392]

Holiday Programming identifies the days that are considered holidays. When option [8] is enabled in sections [361] to [375], access is permitted during the programmed holidays.

Each section represents a month. Each section includes four groups of eight options that represent the days of the month. Use *Feature Select Programming* to enable the options representing the days to be designated as holidays. For example, if 1 and 2 are enabled in the fourth screen in section [392], then December 25 and 26 are designated as holidays. When [8] is enabled in sections [361] to [375], those users will have access according to their Schedule on December 25 and 26.

## 14.9 LOGGING ACCESS CONTROL EVENTS

### 14.9.1 Log Request For Exit In Event Buffer

#### SECTION [537]: OPTION [2]

When the REX device registers movement at the door, a Request for Exit (REX) event is generated (see section 14.2). The Control Panel can record the REX events generated from all the Access Doors in the system, but cannot report these events to the Monitoring Station. The events can be viewed through an LCD Keypad by entering the *Event Record Display* (see section 16.8).

Option [2] ON = Record the REX events  
 Option [2] OFF = Do not record the REX events (default)



**Since REX events can occur often, the Event Buffer may fill up quickly.**

### 14.9.2 Log Door Left Open Restore In Event Buffer

#### SECTION [537]: OPTION [3]

The Door Left Open Interval is the time that a door can remain open after an Access Granted or a Request for Exit without generating an Access Alarm. If an Access Door is left open beyond its keypad's programmed Door Left Open Interval and then is closed, it can generate a Door Left Open Restore event in the Event Buffer. These events cannot be reported to the Monitoring Station, but they can be viewed through an LCD Keypad by entering the *Event Record Display* (see section 16.8).

Option [3] ON = Record the Door Left Open Restore events  
 Option [3] OFF = Do not record the Door Left Open Restore events (default)

### 14.9.3 Log Door Forced Open Restore In Event Buffer

#### SECTION [537]: OPTION [4]

An Access Door is considered forced when its door contact is opened without the use of a valid Access Card or User Access Code or receiving a Request for Exit signal (see section 14.2).

If an Access Door is forced open then closed, it can generate a Door Forced Open Restore event in the Event Buffer. This event cannot be reported to the Monitoring Station, but it can be viewed through an LCD Keypad (DGP2-641) by entering the *Event Record Display* (see section 16.8). To have the Door Forced Open Alarm reported to the Monitoring Station see section 14.10.1.

Option [4] ON = Record the Door Forced Open Restore events  
Option [4] OFF = Do not record the Door Forced Open Restore events (default)

## 14.10 GLOBAL ACCESS DOOR FEATURES

### 14.10.1 Burglar Alarm On Forced Door

SECTION [537]: OPTION [5]

An Access Door can be assigned to a zone in the Digiplex security system to also be protected by the burglar alarm. If an armed Access Door is forced open (see section 14.2), it can send a signal to the control panel to trigger a burglar alarm and to report to the Monitoring Station. The burglar alarm is generated instantly regardless of the zone's definition (i.e. entry delay is ignored).

For this feature to function, the following must be done:

- Install a door contact (see appropriate *Digiplex Module Reference & Installation Manual*)
- Assign the Access Door to a zone (see section 4)
- Enable option [4] in section [537]: Log Door Forced Open Restore (optional) (see section 14.9)
- Enable option [5] in section [537]: Burglar Alarm on Forced Door (see section 14.10.1)

Option [5] ON = Burglar Alarm on Forced Door enabled

Option [5] OFF = Burglar Alarm on Forced Door disabled (default)

### 14.10.2 Skip Exit Delay When Arming With Access Card

SECTION [537]: OPTION [6]

When an Access Card is presented to a reader twice within approximately 5 seconds with the door closed, some or all the partitions (see section 14.5) assigned to the Access Door can arm with or without starting the Exit Delay. This feature is useful when

the reader is outside the partition so the partition will be armed immediately.

Option [6] ON = The Exit Delay will not be triggered

Option [6] OFF = The Exit Delay will be triggered (default)

### 14.10.3 Burglar Alarm On Door Left Open

SECTION [537]: OPTION [7]

An Access Door can be assigned to a zone in the Digiplex security system to also be protected by the burglar alarm. Each Access Door is programmed with a period of time that it is allowed to remain open. Once the door has been open longer than the programmed time period, a signal can be sent to the control panel to trigger the burglar alarm and to report to the Monitoring Station.

For this feature to function, the following must be done:

- Install a door contact (see appropriate *Digiplex Module Reference & Installation Manual*)
- Assign the Access Door to a zone (see section 4)
- Enable option [3] in section [537]: Log Door Left Open Restore In Event Buffer (optional) (see section 14.9)
- Enable option [7] in section [537]: Burglar Alarm on Door Left Open (see section 14.10.3)

Option [7] ON = Burglar Alarm on Door Left Open enabled

Option [7] OFF = Burglar Alarm on Door Left Open disabled (default)

### 14.10.4 Door Access During Clock Loss

SECTION [537]: OPTION [8]

If the system registers a Clock Loss Trouble, the system will no longer be able to recognize the Schedules. Only the *System Master Code* and *User Access Codes* with the *Master* feature enabled can reset the clock when option [8] is enabled. To avoid a Clock Loss Trouble, the Digiplex Time Module (DGP2-TM1) can be installed on the control panel. Until the Clock is reset, the Access Control system can be programmed to grant access to:

Option [8] ON = only the System Master Code, User Access Codes with the Full Master feature enabled or User Access Codes with the Schedule 00

Option [8] OFF = all users regardless of their programmed Schedule (default)



*The Winload software is not verified by UL.*

## 15.1 ANSWERING MACHINE OVERRIDE

### SECTION [441]

When using WinLoad to communicate remotely with an installation site that uses an answering machine or service, the Answering Machine Override must be programmed. Using WinLoad, call the installation site and on the second ring press the [ENTER] key on the keyboard to hang up or hang up manually. After hanging up, WinLoad will immediately call the installation site back or call the site back manually. The value (00 to 15 X 4 seconds) programmed in section [441] represents the delay period the control panel will wait between the first and second call. If the installation site is called back within the programmed delay period, the control panel will override the answering machine or service by picking-up the line on the first ring. To disable this option program 00 in section [441]. Also, see section 15.2.

*Example: A security installation is using an answering machine set to answer after three rings and section [441] has been programmed with 10 (10 x 4 = 40 seconds). When you call the installation site with WinLoad the first time, wait two rings and press [ENTER] on the keyboard. WinLoad will immediately call the installation site back. If the second call is made within 40 seconds, the control panel will pick-up the line on the first ring. If it takes more than 40 seconds, the control panel will not answer on the first ring and the answering machine will answer after three rings.*

## 15.2 RING COUNTER

### SECTION [442]

The value (01 to 15, 00 = disabled) programmed in section [442] represents the number of rings the control panel will wait before picking-up the line. If the line is not answered after the number of programmed rings, the control panel will answer the call. The control panel resets the Ring Counter every 10 seconds. Therefore, if there is more than 10 seconds between each ring, the control panel will reset the counter on the next call. Also, see section 15.1.

## 15.3 PANEL IDENTIFIER

### SECTION [555]

This four-digit code identifies the control panel to WinLoad before initiating upload or download. The control panel will verify if the panel identifier in WinLoad is the same. If the codes do not match, the control panel will not establish communication. Therefore, program the same Panel Identifier into both the Digiplex Control Panel and WinLoad. To program the Panel Identifier, key in the desired 4-digit hexadecimal number into section [555].

## 15.4 PC PASSWORD

### SECTION [556]

This four-digit password identifies the computer running the WinLoad software to the panel before beginning the download process. Program the same PC Password into both the Digiplex control panel and WinLoad. If the passwords do not match, WinLoad will not establish communication. To program the PC Password, enter the desired four-digit hexadecimal number into section [556].

## 15.5 PC TELEPHONE NUMBER

### SECTION [560]

The control panel will dial this number when trying to initiate communication with a computer using WinLoad. You can enter any digit from 0 to 9 and any special keys or functions (see Table 10, *Special Telephone Number Keys*, on page 30) up to a maximum of 32 digits into section [560].



*For North American installations using either SIA or Contact ID reporting formats (see section 8.5), enter \*70 and then either P (4-second pause) or W (wait for second dial tone) before the phone number to disable call-waiting.*

## 15.6 CALL WINLOAD

Dial the PC Telephone Number programmed in section [560] in order to communicate with WinLoad. The control panel and WinLoad will verify that the Panel Identifier and the PC Password match before establishing communication.

**For LCD keypads:** press and hold the [0] key, enter the [INSTALLER CODE] and then press [FORCE].

**For Grafica keypads:** press and hold the [0] key, enter the [INSTALLER CODE], press the center action key (Options), highlight Call Winload and then press the left action key (Select).

## 15.7 ANSWER WINLOAD

To perform on-site upload/downloading, connect your computer directly to the control panel using an ADP-1 line adapter. In WinLoad set *Dialing Condition* to *Blind Dial*. Program the panel telephone number in WinLoad and follow the ADP-1 Adapter's instructions. When the computer has dialed...

**For LCD keypads:** press and hold the [0] key, enter the [INSTALLER CODE] and press [ARM] to manually answer WinLoad from the panel. Press [DISARM] to hang up.

**For Grafica keypads:** press and hold the [0] key, enter the [INSTALLER CODE], press the center action key (Options), highlight Answer Winload and then press the left action key (Select). To hang up, highlight **Cancel Communication** and then press the left action key (Select).

## 15.8 EVENT BUFFER TRANSMISSION

### SECTION [522]: OPTION [2]

If the Event Buffer contains 974 events since the last upload, the control panel will make two attempts to establish communication with a computer using WinLoad by calling the PC Telephone Number programmed in section [560]. WinLoad must be in *Wait To Dial* mode. When the system establishes communication, it will upload the contents of the Event Buffer to WinLoad. If communication is interrupted before completing transmission or if after two attempts, communication is not established, the system will wait until the Event Buffer attains another 974 events before attempting to re-communicate with the central station. When the

Event Buffer is full, each subsequent new event will erase the oldest event in the buffer. The Event Buffer can hold 1024 Events.

## 15.9 CALL BACK FEATURE

### SECTION [522]: OPTION [1]

For additional security, when a computer using WinLoad attempts to communicate with the control panel, the control panel can hang

up and call the computer back to re-verify identification codes and re-establish communication. When the control panel hangs up, WinLoad automatically goes into *Wait For Call Mode*, ready to answer when the control panel calls back. Please note that the PC Telephone Number must be programmed in order to use the Call Back feature.

## USER FEATURES

### 16.1 ARMING AND DISARMING FEATURES

Partitions can be armed using various arming methods. Refer to section 16.1.7 for information on how to arm.

#### 16.1.1 Regular Arming

This method is used for the everyday arming of the system. All zones within the partition must be closed to arm the system. The system can also be Regular Armed by using a One-touch Feature (see section 6.8) or a keyswitch (see section 5.4.6). All users are able to Regular Arm the partition(s) assigned to their User Access Codes.

#### 16.1.2 Stay Arming

Stay Arming will partially arm the partition to permit the user to remain in the protected area. The programmed *Stay Zones* (see section 4.4.3) will not arm when Stay Arming a partition. For example, the doors and windows can be armed without arming the motion detectors. The system can also be Stay Armed by using a One-touch Feature (see section 6.8) or a keyswitch (see section 5.4.3). Only User Access Codes with the *Stay and Instant Arm* option enabled can Stay Arm a partition.

#### 16.1.3 Stay Arming with Delay

*Stay Arming with Delay* functions like Stay Arming except armed zones can be programmed with an *Entry Delay Timer* (see section 4.2.9). If these zones are accidentally triggered, the timer will start to allow the user time to disarm the partition(s).

#### 16.1.4 Instant Arming

This feature is similar to *Stay Arming*. Instant Arming will partially arm the partition to permit the user to remain in the protected area, but all zones, including the entry/exit point, are changed to instant alarm zones. Therefore, if any armed zone is breached, the alarm will instantly be triggered. The system can also be Instant Armed by using a One-touch Feature (see section 6.8) or a keyswitch (see section 5.4.5). Only User Access Codes with the *Stay and Instant Arm* option enabled can Instant Arm a partition.

#### 16.1.5 Instant Arming with Delay

*Instant Arming with Delay* functions like Instant Arming except armed zones can be programmed with an *Entry Delay Timer* (see section 4.2.9). If these zones are accidentally triggered, the timer will start to allow the user enough time to disarm the partition(s).

#### 16.1.6 Force Arming

Force Arming allows the user to arm a partition when Force zones are open (see section 4.4.4). Once the open zone in an armed partition is closed, however, the system will then arm it as well. This feature is commonly used when a motion detector is protecting an area that is occupied by a keypad. For example, during Force arming the motion detector will remain unarmed until the user exits the area that it protects. The system will then arm the motion detector. The system can also be Force Armed by using a One-touch Feature (see section 6.8) or a keyswitch (see section 5.4.4). Only User Access Codes with the *Force Arm* option enabled can Force Arm a partition.

#### 16.1.7 How to Arm

The following section details how to arm the system using an LCD or Grafica keypad.

##### For LCD keypads:

To arm, users:

- 1) Enter their [ACCESS CODE].
- 2) Press the key corresponding to the desired arming method (see Table 12). If the users have access to more than one partition, they can press the key corresponding to the desired partition or press [0] to arm all their assigned partitions.

##### For Grafica keypads:

To arm, users:

- 1) Enter their [ACCESS CODE].
- 2) Using the scroll keys, highlight the desired arming method (see Table 12) and then press the center action key (Ok). If you have access to more than one area, proceed to step 3.
- 3) Highlight either **Arm All Areas** or **Select Area(s)** and then press the center action key (Ok). If you selected the Select Area(s) method, follow steps 4 and 5.
- 4) Highlight an area you wish to arm and then press the left action key (Select). Repeat this step for any additional area.
- 5) Press the center action key (Arm)

**Table 12: Arming Methods**

Arming Method	LCD	Grafica
<b>Regular</b>	[ARM]	 (Arm System)
<b>Stay</b>	[STAY]	 (Stay Arm)
<b>Instant</b>	[5]	 (Instant Arm)
<b>Force</b>	[FORCE]	 (Force Arm)

### 16.1.8 Disarming

Users can only disarm the partitions assigned to their User Access Codes. User Access Codes with the *Arm Only* option (see section 13.5.4) enabled cannot disarm.

#### For LCD keypads:

To disarm, users:

- 1) Enter through a designated entry. The Entry Delay Timer will begin.
- 2) Enter their [ACCESS CODE].
- 3) Press the [DISARM] key. If the users have access to more than one partition, they can press the key corresponding to the desired partition or press [0] to disarm all their assigned partitions.

#### For Grafica keypads:

To disarm, users:

- 1) Enter through a designated entry. The Entry Delay Timer will begin.
- 2) Enter their [ACCESS CODE].
- 3) Using the scroll keys, highlight **Disarm** and then press the center action key (**Ok**). If you have access to more than one area, proceed to step 4.
- 4) Highlight either **Disarm All Areas** or **Select Area(s)** and then press the center action key (**Ok**). If you selected the Select Area(s) method, follow steps 5 and 6.
- 5) Highlight the area you wish to disarm and then press the left action key (**Select**). Repeat this step for any additional area.
- 6) Press the center action key (**Disarm**).

## 16.2 BYPASS PROGRAMMING

Bypass Programming allows users to program the alarm system to ignore specified zones the next time the system is armed. For a user to bypass a zone, the zone must have the Bypass option enabled, the User Access Code must have the Bypass option enabled, and the zone must be within the User Access Code's partition assignment.

#### For LCD keypads:

To bypass, users:

- 1) Enter their [ACCESS CODE].
- 2) Press the [BYP] key.
- 3) Enter the zones' 2-digit number.
- 4) Press [ENTER] key to exit.

#### For Grafica keypads:

To bypass, users:

- 1) Enter their [ACCESS CODE].
- 2) Using the scroll keys, highlight **Bypass** and then press the center action key (**Ok**).
- 3) Highlight the zone that you wish to bypass and then press the left action key (**Bypass**). Repeat this step for any additional zone.
- 4) Press the right action key (**Back**) to save the data.

Users can also activate *Bypass Recall*. Bypass Recall reinstates all the zones that were bypassed the last time the partition(s) assigned to the User Access Code were armed.

#### For LCD keypads:

To activate Bypass Recall, users:

- 1) Enter their [ACCESS CODE].
- 2) Press the [BYP] key.
- 3) Press the [MEM] key.
- 4) Press [ENTER] key to exit.

#### For Grafica keypads:

To activate Bypass Recall, users:

- 1) Enter their [ACCESS CODE].
- 2) Using the scroll keys, highlight **Bypass** and then press the center action key (**Ok**).
- 3) Highlight **Bypass Recall** and then press the center action key (**Ok**).

## 16.3 CHIME ZONES

The keypads can be programmed to emit rapid, intermittent beeps whenever designated zones within their assigned partitions are opened or when they are opened within a certain time period. These zones are Chime Zones. The instructions that follow are for LCD keypads. For Grafica keypads, a complete Grafica user manual is available on our Web site at [www.paradox.ca](http://www.paradox.ca).

#### For LCD keypads:

To program a Chime Zone, users:

- 1) Enter their [ACCESS CODE].
- 2) Press the [9] key.
- 3) Press the [1] key.
- 4) Enter the zones' 2-digit number.
- 5) Press [ENTER] key to save.

To program a time period when the Chime Zones are activated, users:

- 1) Enter their [ACCESS CODE].
- 2) Press the [9] key.
- 3) Press the [2] key.
- 4) Enter the time that keypads will **start** beeping when Chime Zones are opened according to the 24-hour clock (i.e. 9AM is 09:00 and 9PM is 21:00).
- 5) Enter the time that keypads will **stop** beeping when Chime Zones are opened according to the 24-hour clock (i.e. 9AM is 09:00 and 9PM is 21:00).
- 6) Press [ENTER] key to save.

## 16.4 ACCESS CODES

Refer users to the appropriate manual: LCD Keypad System Manager's Manual or LED Keypad User Manual.

## 16.5 NORMAL AND CONFIDENTIAL MODES

### For LCD Keypads:

When no actions are being performed on the keypad, the keypad will remain in Normal Mode as shown in Figure 16-1 and will automatically display:


- The current status of the zones for every area the keypad is assigned
- The *Alarm Memory Display* if any alarms have occurred
- The *Trouble Display* if any troubles are occurring
- The current state of the *Indicator Lights*

### In Confidential Mode:

- The zones and status messages will NOT be displayed
- The *Indicator Lights* will not illuminate

Depending on how the keypad was programmed, the user must press a key or enter a User Access Code to illuminate the *Indicator Lights* and activate *Normal Mode*.

Figure 16-1: Normal and Confidential Mode



### 16.5.1 Scroll Restart

In Normal mode the keypad will scroll through the status of the different parts of your system. Press the [CLEAR] key at any time during Normal Mode to return to the beginning of the sequence and view the status of the areas assigned to the keypad.

### For LED Keypads:

When no actions are being performed on the keypad, the keypad remains in Normal Mode and the LED keypad will illuminate:

- The AC Light if power is present
- The Numerical Symbols representing any open zones
- The Area Symbols if any areas are armed
- The [MEM] Symbol if any alarms have occurred
- The [TRBL] Symbol if any troubles are occurring
- The [BYP] Symbol if zones are bypassed and shows the status of the STATUS LED.

In Confidential Mode all the LEDs are extinguished. Depending on how the keypad was programmed, the user must press a key or enter a *User Access Code* to illuminate the LEDs and activate *Normal Mode*.

### For Grafica keypads:

If Confidential Mode is enabled and no actions are performed on the Grafica keypad for a specified period of time, Grafica will

display the time and the date only, and all LEDs on the keypad will turn off until either a key is pressed or an access code is entered, depending on the configuration.

## 16.6 KEYPAD SETTINGS


The keypad's setting can be modified to suit the user's needs. The instructions that follow are for LCD and LED keypads only. For Grafica keypads, a complete Grafica user manual is available on our Web site at [www.paradox.ca](http://www.paradox.ca).

### For LCD Keypads:

- 1) **Scrolling Speed:** how long the messages will stay on the LCD screen before moving to the next message.
- 2) **Contrast:** how dark or pale characters will appear on the LCD screen
- 3) **Backlight:** the illumination behind the keys and the screen

Use the System Master Code to modify the settings as shown in Figure 16-2 on page 51.

Figure 16-2: LCD Keypad Settings



### For LED Keypads:

Modify Backlight only:

- 1) Enter an [ACCESS CODE].
- 2) Press the [6] key.
- 3) Use the [▲] and [▼] keys to increase or decrease the illumination. The range is between zero and seven with seven as the brightest. ([10] LED = zero).

## 16.7 TROUBLE DISPLAY

When the system experiences problems or is tampered with, the Trouble Display will activate. In LED Keypads, the [TRBL] Symbol illuminates. In LCD Keypads, the Trouble Display will appear on the LCD screen. In Grafica keypads, the Trouble Icon will appear in the corresponding area window in the System Status Screen. Keypads will only display troubles that occur in their assigned area(s).

Potential troubles have been sorted into eight groups. The Group headings are listed below with a brief explanation of the potential troubles sorted within each group.

**TO VIEW THE TROUBLE DISPLAY ON LCD OR LED KEYPADS:**

- 1) Press the [TRBL] key.
- 2) **For LEDs:** Press the Numerical Symbol corresponding to the Group heading to view the specific trouble.  
**For LCDs:** Press the number representing the trouble and use the [▲] and [▼] keys to view the specific trouble.

**TO VIEW THE TROUBLE DISPLAY ON GRAFICA KEYPADS:**

- 1) Enter your [ACCESS CODE].
- 2) Using the scroll keys, highlight **Trouble** and then press the center action key (Ok). The trouble(s) will appear by Trouble Group.
- 3) If more than one Trouble Group appears, highlight the desired group before pressing the center action key (**View**) to view the specific trouble.

Trouble	Description
<b>GROUP [1]: SYSTEM</b>	
[1] AC Failure	Power failure detected. The system is running on the backup battery.
[2] Battery Trouble	The backup battery is disconnected, needs to be recharged or replaced.
[3] AUX Current Limit	Devices connected to AUX have exceeded current limits (1.1A). The Auxiliary Output will shutdown until the trouble is corrected.
[4] Bell Current Limit	The bell or siren has exceeded current limits (3A). The Bell/Siren Output will shutdown until the trouble is corrected.
[5] Bell Absent	The bell or siren is not connected. When the bell output is not used, connect a 1kΩ resistor across the bell output.
[6] ROM Check Error	The control panel registers a data memory error. Contact distributor for replacement.
<b>GROUP [2]: COMMUNICATOR</b>	
[1] TLM1	The control panel is unable to access the main telephone line.
[2] Fail to Communicate 1 [3] Fail to Communicate 2 [4] Fail to Communicate 3 [5] Fail to Communicate 4	The control panel tried all assigned telephone numbers and failed to contact the Monitoring Company.
[6] Fail to Communicate PC	The control panel is unable to communicate with the WinLoad software.
<b>GROUP [3]: MODULES</b>	
[1] Module Tamper	A module's tamper switch was triggered
[2] ROM Check Error	A module is experiencing a data memory error. Contact distributor for replacement.
[3] TLM Trouble	A module is unable to access the telephone line.
[4] Fail to Communicate	A module failed to communicate with the Monitoring Company.
[5] Printer Trouble	The control panel registers a problem with a printer connected to a Printer Module. Check printer for problems (paper jam, no paper, no power, etc.).
[6] AC Failure	Module power failure.
[7] Battery Failure	Module's battery is disconnected, needs to be recharged or needs to be replaced.
[8] Supply Output	Module has exceeded current limits.

Trouble	Description
<b>GROUP [4]: COMBUS</b>	
[1] Missing Keypad	A keypad is no longer communicating with the control panel.
[2] Missing Module	A device is no longer communicating with the control panel.
[6] General Failure	No communication between the devices and the control panel.
[7] Combus Overload	Too many devices (over 95) are on the combus.
[8] Combus Comm. Error	The combus is having difficulty communicating between the devices and the control panel.
<b>GROUP [5]: ZONE TAMPER</b>	
Press [5] to display zone(s)	Zones displayed were tampered.
<b>GROUP [6]: ZONE LOW BATTERY</b>	
Press [6] to display zone(s)	Zone displayed indicates where a wireless device's battery needs to be replaced. Also, the device's yellow light will flash.
<b>GROUP [7]: ZONE FAULT</b>	
Press [7] to display zone(s)	A smoke detector is experiencing a wiring problem, needs to be cleaned, or a wireless device is no longer communicating with its receiver (supervision loss).
<b>GROUP [8]: CLOCK LOSS</b>	
Press [8] to re-program	The time and date were reset to default. Step 1: Press the [8] key Step 2: Set the hour and minutes according to the 24-hour clock (i.e. 9AM is 09:00 and 9PM is 21:00). Step 3: Enter the correct date according to yyyy/mm/dd. Step 4: Press [CLEAR] to exit.



If the Access Control feature is enabled in the system and the option *Door Access during Clock Loss* is ON (section [537] option [8]), only the System Master Code and User Codes with the Master feature enabled will be able to program the clock. Enter the System Master or a Master Code, press [TRBL], then continue with the steps above.

## 16.8 TROUBLE LATCH

### SECTION [504]: OPTION [6]

(Default: OFF) With the *Trouble Latch* feature disabled, when a trouble occurs and is corrected, the trouble is automatically cleared and no longer displayed. With the *Trouble Latch* feature enabled, the trouble will remain displayed until it is manually cleared by the user. To clear the trouble, users must enter the keypad's trouble display (see section 16.7) and then exit the trouble display. For LCD and LED keypads, press [CLEAR] to exit. For Grafica keypads, press the left action key (**Back**) to exit.



**Only troubles that have been corrected can be cleared. If a trouble has not been corrected, it will continue to be displayed even if the user tries to clear the trouble by using the method described above.**

## 16.9 CLEAR BELL LIMIT TROUBLE

### SECTION [522]: OPTION [5]

(Default: OFF) When an activated bell output is shorted, a Bell Current Limit trouble is displayed and can be sent to the Central Station. This feature determines how the Bell Current Limit trouble is cleared.

Option		Description
[5]	ON	When an activated bell output is shorted, the Bell Current Limit trouble will remain displayed until it is manually cleared by the user. The user must clear the trouble through the trouble display.
[5]	OFF	When an activated bell output is shorted, the Digiplex control panel will attempt to reactivate the bell output once every minute for as long as the bell is activated. The Bell Current Limit trouble is cleared automatically the first time the control panel does not detect a short when attempting to reactivate the bell.



**UL Note:** For UL installations, section [522] option [5] must be enabled (ON).

**Only troubles that have been corrected can be cleared. If a trouble has not been corrected, it will continue to be displayed even if the user tries to clear the trouble through the trouble display.**

## 16.10 EVENT RECORD DISPLAY

The Event Record Display can only be viewed through an LCD or Grafica keypad. The Event Record Display will record the user-initiated actions that occurred in the system as well as any alarms or troubles.

*For example, when a valid code is entered, the User Access Code and the action taken (arm, disarm, etc.) is recorded.*

You have the choice of viewing the events in all the partitions at once or by individual area. In either case the most recent event is displayed first (see Figure 16-3: Event Record screens).

### For LCD keypads:

To view the events, users:

- 1) Enter their [ACCESS CODE].
- 2) Press the [7] key.
- 3) Press the [0] key for all partitions.  
Press the [1] key for Partition 1.

Press the [2] key for Partition 2.


Press the [3] key for Partition 3.

Press the [4] key for Partition 4.

- 4) Use the [▼] key to view subsequent events.
- 5) Press the [CLEAR] key to exit.

Once you have entered the Event Record Display, you can change the order that the Event Record screens (see Figure 16-3: Event Record screens) appear by pressing the [7] key. If you already know the number of the event you want to view, press the [MEM] key and then enter the event's number.

**Figure 16-3: Event Record screens**



### For Grafica keypads:

To view the events, users:

- 1) Enter their [ACCESS CODE].
- 2) Using the scroll keys, highlight **View Status** and then press the center action key (**Ok**).
- 3) Highlight **View Events** and then press the center action key (**Ok**). If the event list appears on the screen go to step 6.
- 4) Highlight **View All Areas** or **Select Area(s)** and then press the center action key (**Ok**).
- 5) If you selected **Select Area(s)** in step 4, highlight the area you wish to view and then press the center action key (**Ok**).
- 6) Use the scroll keys to scroll through the events.

# INDEX

---

## Sections

001 to 048 .....	15	451 to 498 .....	17
049 to 056 .....	20	500 .....	25, 39
101 to 148 .....	15	501 .....	22, 25, 26
149 to 156 .....	20	502 .....	25, 35, 40
200 .....	17	503 .....	22, 35, 39, 41
201 to 216 .....	19	504 .....	19, 24, 41, 42, 44, 52
217 .....	16	505 .....	22–23
218 .....	41	506 .....	24, 26, 31
219 .....	31	507 .....	24
220 .....	23	508 .....	23
221 .....	23	509 .....	22–23
222 to 225 .....	23	510 .....	24, 26, 31
226 to 229 .....	23	511 .....	24
230 to 233 .....	15	512 .....	23
234 to 237 .....	25	513 .....	22–23
238 to 241 .....	24	514 .....	24, 26, 31
242 to 245 .....	25	515 .....	24
246 to 249 .....	25	516 .....	23
250 to 254 .....	35	517 .....	22–23
255 .....	33	518 .....	24, 26, 31
256 .....	17	519 .....	24
257 .....	31	520 .....	23
258 .....	31	521 .....	28, 33
259 .....	31	522 .....	31, 33, 40, 48, 52
260 .....	31	522 to 536 .....	31
261 .....	31	537 .....	45, 46, 47
270 .....	31	550 .....	30
271 to 274 .....	22	551 to 554 .....	30
301 to 332 .....	45	555 .....	48
340 .....	45	556 .....	48
341 to 355 .....	46	560 .....	48
361 to 375 .....	46	561 to 564 .....	30
381 to 392 .....	46	600 to 625 .....	28
400 .....	34	626 .....	22, 28
401 .....	34	627 .....	28
402 .....	34	628 to 653 .....	28
403 .....	34	654 .....	28
404 .....	34	655 to 666 .....	28
405 .....	34	667 to 678 .....	28
406 .....	34	679 to 680 .....	28
407 .....	34	681 to 692 .....	29
408 .....	34	693 to 704 .....	29
409 .....	34	705 .....	23, 29
440 .....	39	706 to 711 .....	29
441 .....	48	712 .....	31
442 .....	48	712 to 716 .....	29
		717 .....	29

718 .....	29
790 to 795 .....	31
800 .....	42
801 .....	42
802 to 896 .....	42–44
900 .....	41
950 .....	42
951 .....	40
952 .....	40
953 .....	12, 40
954 .....	40
955 .....	41
961 .....	13
962 .....	13
965 .....	13
966 .....	13
970 .....	39
974 .....	39
975 .....	39
976 .....	39
977 .....	39
978 .....	39
979 .....	39
990 .....	39
<b>A</b>	
AC Power .....	5
Access Alarm .....	45
Access Card .....	45
Access Card Assignment .....	44
Access Control feature .....	43
Access Control Terms .....	45
Access Level .....	46
Access Level Assignment .....	43
Account Codes .....	30
Activate Card .....	44
Ademco Contact ID .....	30
Ademco Express .....	30
Advanced Technology Zoning (ATZ) .....	19
Alarm	
On Door Left Open .....	47
On Forced Door .....	47
Alarm Transmission Delay. See Delay Alarm Transmission	
Alarm Types .....	17
Alternate Backup Option .....	31
Always Force Arm When Regular Arming .....	24
AND Door Access Mode .....	46
Answer WinLoad .....	40
Arm Only .....	43
Armed Access Doors .....	44
Arming methods .....	49

Arming with Access Card .....	44
Skip Exit Delay .....	47
Assigning keyswitches to partitions .....	21
ATZ .....	19
Audible Alarm	
Bell Cut-off Timer .....	25
Pulsed .....	17
Steady .....	17
Tamper Recognition .....	26
Wireless Transmitter Supervision .....	25
Auto Zone Shutdown .....	16
Auto-Arming	
No Movement .....	22
No Movement Timer .....	23
Timed .....	22
Timer .....	22
Automatic Event Buffer Transmission .....	48
Auxiliary Power .....	5
Auxiliary Output .....	5
Calculating power consumption .....	7
Power Limitations .....	7
Power Supply Connections .....	8
Troubles .....	52
Away Arming. See Force Arming	
Away Zones. See Force Zones	
<b>B</b>	
Backlight .....	51
Battery .....	5
Battery Test .....	5
Bell	
Bell terminals .....	5
Bell/siren Output .....	5
Bell/Siren Output During Fire Alarm .....	16
Sirens .....	5
Troubles .....	51
Bell Current Limit Trouble, Clearing .....	52
Broadcast .....	40
Burglar Alarm	
On Door Left Open .....	47
On Forced Door .....	47
Burglary Zones .....	15
Buzzer Zones .....	15
Bypass Programming .....	50
Bypass Recall .....	50
Bypass Zones .....	17
<b>C</b>	
Call Direction .....	31
Call WinLoad .....	39
Cancel Communication .....	40
Chime Zones .....	50
CleanMeTM .....	10
Clear Bell Current Limit Trouble .....	52
Clock Loss	
Access during Clock Loss .....	47
Codes	

Alarm Report Codes .....	28
Arming Report Codes .....	28
Disarming Report Codes .....	28
Special Alarm Report Codes .....	28
Special Arming Report Codes .....	28
Special Disarming Report Codes .....	28
Special Tamper Report Codes .....	29
System Trouble Codes .....	29
System Trouble Restore Codes .....	29
Zone Restore Report Codes .....	28
Zone Tamper Report Codes .....	29
Zone Tamper Restore Codes .....	29
Connections	
Advanced Technology Zone (ATZ) .....	19
Bell/siren Output .....	5
Double Zone Connections .....	10, 19
in Noisy Environments .....	9
Keypad Zone Connections .....	10
Keyswitch Connections .....	10
Network Connections .....	9
PGM .....	9
Power .....	5
Single Zone Connections .....	9
Telephone Line Connections .....	5
Contrast .....	51
Control Panel Programming Mode .....	12
Current setting for charging battery .....	39
D	
Daylight Savings Time .....	40
Delay Alarm Transmission .....	17
Delay Alarm Transmission Timer .....	17
Delay Between Dialing Attempts .....	31
Delayed 24Hr Fire Zone .....	15
Digiplex Memory Key. See Paradox Memory Key	
Disabled	
Wireless Transmitter Supervision .....	25
Disarm with Access Card .....	44
Door Access Mode .....	45
Door Forced Open Restore event .....	47
Door Left Open .....	45
Door Left Open Restore event .....	46
Doors	
Access During Clock Loss .....	47
Assigning The Keypad To A Door .....	45
Burglar Alarm On Door Left Open .....	47
Burglar Alarm On Forced Door .....	47
Double Zone Connections .....	10
Duress .....	43
E	
Earth Ground .....	5
Enable Reporting .....	28
Entry Delay Timers .....	15
Entry Delay zones .....	15
EOL Zones .....	19
ESL CleanMeTM Installation .....	10
Event Buffer	
Log Door Forced Open Restore In Event Buffer ...	46
Log Door Left Open Restore In Event Buffer .....	46
Log Request For Exit In Event Buffer .....	46
Event Record Display .....	53
Everyday arming. See Regular Arming	
Exit Delay .....	23
Exit Delay cancelled on Remote Arm .....	23
Exit Delay Termination .....	23
Extended Unlocked Period .....	44
F	
Feature Select Programming .....	12
Fire Circuits .....	10
Fire Zone .....	10
Fire Zone, Delayed 24hr. ....	15
Fire Zone, Standard 24hr. ....	16
Follow zone .....	15
Force Arm When Regular Arming, Always .....	24
Force Arming .....	49
Force Zones .....	17
Forced Door .....	45
Function Keys, Installer .....	39
G	
Ground .....	5
H	
Hardware Reset .....	39
Holiday Programming .....	46
Hourly Test Transmission .....	31
I	
Identifier, Panel .....	48
Input Numbers	
Keyswitch Numbering .....	20
Zone Numbering .....	15
Input Speed .....	19
Installer Code .....	42
Installer Function Keys .....	39
Installer Lock .....	39
Installer Test Mode .....	40
Instant Arming .....	49
Instant Arming with Delay .....	49
Instant zone .....	15
Intellizone .....	17
K	
Keypad connections. See Connections	
Keypad Lockout .....	23
Keypad Zone Connections .....	10
Keyswitch	
Arm/Disarm .....	21

Connections .....	10
Definitions .....	20, 21
Disabled .....	21
Keyswitch Numbering .....	20
Maintained .....	21
Momentary .....	21
Options .....	20, 21
Partition Assignment .....	20, 21
Stay/Instant Disarm .....	21

## L

Labels, Zone .....	17
LCD Display	
Confidential Mode .....	51
Keypad Settings .....	51
Shabbat Feature .....	40
Locate Module .....	40
Location & Mounting .....	5
Logging Access Control Events .....	46

## M

Master Feature .....	43
Maximum Dialing Attempts .....	31
Memory Key .....	13
Module Programming Mode .....	12
Module Scan .....	40
Multiple Action Feature .....	44

## N

Network Connections .....	9
in Noisy Environments .....	9
No Bell Cut-Off on Fire Alarm .....	25
No Exit Delay on Remote Arm .....	23

## O

One-touch Features .....	23
OR Door Access Mode .....	46

## P

Pager Reporting Format .....	30
Panel Answer Options .....	48
Panel Identifier .....	48
Panel Partition Assignment .....	39
Panel Programming Mode .....	12
Panic Options .....	26
Paradox Memory Key .....	13
Partitioning .....	39
PCB Layout .....	6
PGM .....	9
As a 2-wire smoke detector .....	10
As a 4-wire smoke detector .....	11
Connections .....	9
PGM Activation Event .....	34
PGM Deactivation Event .....	34
PGM Delay Timers .....	35
PGM Programming Table .....	36–38

PGM Time Base Selection .....	35
Relay .....	9
Power Supply Connections .....	8
Power Unit Consumption Table .....	7
Problems. See Trouble Display	
Programmable Outputs. See PGM	
Programming .....	12
Decimal Programming .....	12
Feature Select Method .....	12
Hexadecimal Programming .....	12
Level Programming .....	13
Modules .....	12, 40
Panel Programming Mode .....	12
Paradox Memory Key .....	13
Zone Programming .....	14

Pulse formats. See Standard Pulse Formats

Pulsed Audible Alarm .....	17
----------------------------	----

## R

Record REX events .....	46
Record the Door Forced Open Restore events .....	47
Record the Door Left Open Restore events .....	46
Record. See Event Record Display	
Recycle Alarm .....	25
Recycle Delay .....	25
Regular Arming .....	49
Report Only .....	17
Reporting Formats .....	30
Request for Exit (REX) event .....	46
Reset	
Hardware .....	39
Module .....	40
Software .....	39
System Master Code Reset .....	42

Restrict Arming on

Power Failure .....	22
Supervision Loss .....	22
Tamper .....	22

Ring-back .....	24
-----------------	----

## S

Schedule .....	46
Schedule Assignment .....	43
Scrolling Speed .....	51
Shabbat Feature .....	40
SIA FSK .....	30
Silent Alarm .....	17
Tamper Recognition .....	26
Silent Alarms	
Wireless Transmitter Supervision .....	25
Sirens .....	5
Skip Exit Delay When Arming With Card .....	47
Smoke Detector .....	10
CleanMe™ feature .....	10
Special Characters .....	17

Special Telephone Number Keys .....	30
Standard 24Hr Fire Zone .....	16
Standard Pulse Formats .....	30
Stay Arming .....	49
Stay Arming with Delay .....	49
Stay Delay zone .....	16
Stay Zones .....	17
Supervision Bypass Options .....	25
Swinger Shutdown. See Auto Zone Shutdown	
System Master Code Reset .....	42
<b>T</b>	
Tamper .....	25
Tamper Bypass Options .....	26
Tamper Recognition	
Audible Alarm .....	26
Disabled .....	26
Silent Alarm .....	26
Trouble only .....	26
Telephone Line Connection .....	5
Test Report .....	39
TLM Fail Timer .....	33
Transformer .....	5
Trouble Display .....	51
Trouble Latch .....	52
Troubles .....	51
<b>W</b>	
WinLoad .....	48
Answer WinLoad .....	40, 48
Call WinLoad .....	39, 48
Cancel Communication .....	40

Wireless Transmitter Supervision Options .....	25
<b>Z</b>	
Zone Labels .....	17
Zones	
24Hr Burglary zone .....	15
24Hr Buzzer .....	15
Alarm Transmission Delay .....	17
Bypass .....	17
Clearing a Zone's Numbering .....	15
Connections .....	9
Definition .....	14, 15
Delayed 24Hr Fire Zone .....	15
Disabled .....	15
Doubling .....	19
Entry Delay .....	15
EOL .....	19
Follow .....	15
Force Zone .....	17
Generates a report only .....	17
Input Speed .....	19
Instant .....	15
Intellizone .....	17
Options .....	14
Partition Assignment .....	14, 16
Pulsed Audible Alarm .....	17
Silent Alarm .....	17
Standard 24Hr Fire Zone .....	16
Stay Delay zone .....	16
Stay Zone .....	17
Steady Audible Alarm .....	17
Zone Doubling (ATZ) .....	19
Zone Numbering .....	14, 15
Zone Options .....	16
Zone Parameters .....	14

# WARNINGS

---

## ***FCC Warnings***

### IMPORTANT INFORMATION

This equipment complies with Part 68 of the FCC rules subpart D and CS-03. Inside the cover of this equipment is a label that contains, among other information, the FCC registration number of this equipment.

### NOTIFICATION TO TELEPHONE COMPANY

Upon request, customer shall notify telephone company of particular line to which the connection will be made and provide the FCC registration number and the ringer equivalence of the protective circuit.

FCC REGISTRATION NUMBER: 5A7CAN-22633 - AL - E  
RINGER EQUIVALENCE NUMBER: 0.1B (U.S. & CANADA)  
USOC JACK: RJ31X (USA), CA31A (CANADA)

### TELEPHONE CONNECTION REQUIREMENTS

Except for telephone company provided ringers, all connections to the telephone network shall be made through standard plugs and telephone company provided jacks, or equivalent, in such a manner as to allow for easy, immediate disconnection of terminal equipment. Standard jacks shall be so arranged that, if plug connected thereto is withdrawn, no interference to operation of equipment at customer's premises which remains connected to telephone network shall occur by reason of such withdrawal.

### INCIDENCE OF HARM

Should terminal equipment/protective circuitry cause harm to telephone network, telephone company shall, where practicable, notify customer that temporary disconnection of service may be required; however, where prior notice is not practicable, the telephone company may temporarily discontinue service if action is deemed reasonable in circumstances. In case of temporary discontinuance, telephone company shall promptly notify customer and will be given opportunity to correct the situation.

### CHANGES IN TELEPHONE COMPANY EQUIPMENT OR FACILITIES

The telephone company may make changes in its communication facilities, equipment operations or procedures, where such actions are reasonably required and proper in its business. Should any such changes render customer's terminal equipment incompatible with the telephone company facilities, the customer shall be given adequate notice to effect the modifications to maintain uninterrupted service.

### GENERAL

This equipment shall not be used on coin telephone lines. Connection to party line service is subject to state tariffs.

### RINGER EQUIVALENCE NUMBER (REN)

The REN is useful to determine the quantity of devices that you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, sum of the REN's of all devices connected to one line should not exceed five (5). To be certain of the number of devices that you may connect to your line, you may want to contact your local telephone company.

### EQUIPMENT MAINTENANCE FACILITY

If you experience trouble with this telephone equipment, please contact facility indicated below for information on obtaining service or repairs. The telephone company may ask that you disconnect this equipment from network until problem is corrected or until you are sure that the equipment is not malfunctioning.

### FCC PART 15, WARNINGS: INFORMATION TO USER

This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to equipment intermittently, the user is encouraged to try to correct the interference by one or more of the following measures: (1) reorient or relocate the receiving antenna; (2) increase the separation between the equipment and receiver; (3) connect the equipment to an outlet on a circuit other than the one to which the receiver is connected, or (4) consult the dealer or an experienced radio/tv technician for assistance.

### CAUTION:

Changes or modifications not expressly approved by PARADOX SECURITY SYSTEMS could void the user's authority to operate the equipment.

## ***CTR-21 Warnings***

The equipment has been approved in accordance with Council Decision 98/482/EC for pan-European single terminal connection to the public switched telephone network (PSTN). However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN network termination point. In the event of problems, you should contact your equipment supplier in the first instance.

## ***General Warning***

This equipment must be installed and maintained by qualified service personnel only.

# UL and C-UL Warnings

## UL AND C-UL INSTALLATION NOTES

This equipment is UL listed in accordance with standard UL1023 (Household Burglar -- Alarm Systems Units), standard UL985 (Household Fire Warning Units) and standard CAN/C-UL S545 (Residential Fire Warning System Control Units). This equipment has the capability of being programmed with features not verified for use in UL installations. To stay within these standards, the installer should use the following guidelines when configuring the system:

- All components of the system should be UL listed for the intended application.
- If the system will be used for "Fire" detection, the installer should refer to NFPA Standards #72, Chapter 2. In addition, once installation is complete, the local fire authority must be notified of the installation.
- This equipment must be verified by a qualified technician once every three years.
- All keypads must use a tamper switch.
- Maximum allowed entry delay is 45 seconds.
- Maximum allowed exit delay is 60 seconds.
- Minimum 4 minutes for bell cut-off time.
- The following features do not comply with UL requirements: Bypass Recall, Shabbat, Auto Trouble Shutdown, and "No AC Fail" display.
- Do not connect the primary indicating device to a relay. The installer must use the bell output.
- The metallic enclosure that houses the Digiplex control panel must be grounded to the cold water pipe.
- Use a UL/C-UL listed Siren: Wheelock model# 46T-12.
- Use a UL/C-UL listed 12Vdc 7Ah rechargeable battery: YUASA model# NP7-12.
- Transformer requirements: UL listed transformer - 16VAC 40VA
  - UL listed Basler Electronics Transformer - #BE156240CAA
  - CSA listed Basler Electronics Transformer - #BE116240AAA
- The AUX, PGM and Keypad's maximum current cannot exceed 200mA for UL installations.

All outputs are Class 2 or power-limited, except for the battery terminal. The Class 2 and power-limited fire alarm circuits shall be installed using CL3, CL3R, CL3P, or substitute cable permitted by the National Electrical Code, ANSI/NFPA 70.

## WARRANTY

---

The Seller warrants its products to be free from defects in materials and workmanship under normal use for a period of one year. Except as specifically stated herein, all express or implied warranties whatsoever, statutory or otherwise, including without limitation, any implied warranty of merchantability and fitness for a particular purpose, are expressly excluded. Because Seller does not install or connect the products and because the products may be used in conjunction with products not manufactured by Seller, Seller cannot guarantee the performance of the security system. Seller obligation and liability under this warranty is expressly limited to repairing or replacing, at Seller's option, any product not meeting the specifications. In no event shall the Seller be liable to the buyer or any other person for any loss or damages whether direct or indirect or consequential or incidental, including without limitation, any damages for lost profits, stolen goods, or claims by any other party, caused by defective goods or otherwise arising from the improper, incorrect or otherwise faulty installation or use of the merchandise sold.

### ATTACHMENT LIMITATION NOTICE

The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**CAUTION:** Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all of the devices does not exceed 100.

Industry Canada certification is only applicable to installation of devices which include transformers approved by the Canadian Standards Association (CSA).

Digiplex, Grafica, InTouch, Omnia and WinLoad are trademarks or registered trademarks of Paradox Security Systems Ltd or its affiliates in Canada, the United States and/or other countries.

Specifications may change without prior notice. All rights reserved. © 2003 Paradox Security Systems Ltd.



**P ▲ R ▲ D O X<sup>®</sup>**  
**S E C U R I T Y S Y S T E M S**

780 Industriel Blvd., Saint-Eustache (Quebec) J7R 5V3 CANADA  
Tel.: (450) 491-7444 Fax: (450) 491-2313

[www.paradox.ca](http://www.paradox.ca)

Printed in Canada - 01/2004

DGP848-EI01