

**JLR-7700MK II**

---

**GPS NAVIGATOR**

**INSTRUCTION  
MANUAL**



*Japan Radio Co., Ltd.*





## Before Commencing the Equipment Operation

### Graphical Symbols

Several graphical symbols are used in this manual to ensure safety and proper operation of the equipment and to avoid possible human injury or property damage. The symbols and their meanings are shown below. We would recommend you to carefully read the manual to obtain a thorough understanding on these symbols.

 **WARNING** Instructions shown with this symbol represent those that can cause death or severe injury, if not observed.

 **CAUTION** Instructions shown with this symbol represent those that can cause injury or property damage, if not observed.

### Examples of the Symbols



The symbols shown in the  $\triangle$  mark represent those that require attention (including the potential dangers and warnings). A tangible instruction is shown in the symbol. For example, the symbol shown to the left indicates that one is likely to get an electric shock.



The circle symbols with a slash from the upper left to the right bottom represent the specific actions prohibited to avoid potential hazards. A tangible instruction is shown in the symbol. For example, the symbol shown to the left indicates that the disassembly is prohibited.



The black circle symbols represent the obligatory actions or instructions to avoid potential hazards. A tangible instruction is shown in the symbol. For example, the symbol shown to the left indicates that the power supply plug needs to be disconnected.



# CAUTION




This equipment is not designed to automatically make judgments on the position data. The navigation information including the position data needs to be judged by the user himself.




Do not allow the equipment to fall or immerse in water. The equipment can be damaged.



When removing the power and antenna cord, be sure to remove the cord terminal correctly. If the cord is pulled, the cord may be damaged resulting in a fire or an electrical shock.



When cleaning the surface, do not use any organic solvent such as thinner or benzene. Otherwise, the painting on the surface may be damaged.  
For cleaning the surface, remove the dust and refuse and wipe with clean dry cloth.
























### 1.4 Construction


(1) Outline drawing of NWZ-4570B navigator



Unit : mm  
Weight : less than 1.8Kg



(3) Outline drawing of NQE-7700A junction box



Unit : mm  
Weight : less than 0.7Kg



## 2. Unit Descriptions and Functions

### 2.1 Operation Panel of the Navigator

The following figure shows the keys provided on the operation panel of the navigator and the functions thereof.




Fig. 2-1 Operation Panel of the Navigator



## 2.2 Rear Panel of the Navigator




Fig. 2-2 Rear Panel of the Navigator

No.	Description	Function
⑰	DATA OUT connector	This connector outputs various data (DATA 1 and DATA 2) for the plotter, auto pilot, printer, remote display and so on, in addition to the external buzzer or log pulse.
⑱	GPS/DGPS connector	This connector connects the NNN-4331 DGPS receiver.
⑲	12/24 VDC connector	This connector connects the CFQ-3598B power supply cable included in the equipment.
⑳	Terminal E	This connector needs to be connected to the earth of the vessel frame. Use the attached copper tape (25W×2,000×0.3t) to connect it.










### 3.1.3 Installation of the DGPS Receiver on the Mast

The following figure shows how to install the receiver on the mast.



1. Loosen the fitting belt screw with a screwdriver to remove the clamp.

Clamp

Minus screwdriver

2. Coil the fitting belt around mast as shown below.

3. Tighten the clamp screw with the screwdriver.

How to Install the Receiver on the Mast












### 3.4 Connection of the Navigator

#### 3.4.1 Connection of the Power Supply Cable

A 1.8m long DC power supply cable is included in the equipment, which needs to be securely inserted all the way into the 12/24 VDC connector provided on the rear panel of the navigator.



Connect the red cable to the plus terminal of the battery or power distribution panel and the black cable to the minus terminal.

The equipment needs to be connected to the DC power supply source having the voltage range of 10 to 35 VDC. The power consumption by the equipment is 10 W or less with the GPS or DGPS receiver connected to it. Use an AWG #17 cable or greater if the attached CFQ-3598B power supply cable (1.8m long) needs to be extended.

#### 3.4.2 Connection of the Grounding Line

The navigator needs to be grounded to protect it from the static electricity and to avoid possible noise generation. Connect the terminal “E” provided on the rear panel of the navigator to the nearest vessel frame with the copper plate (25Wx2,000x0.3t) included in the equipment.








### 3.4.6 Connection of the Junction Box

Connect the respective cables (cable from the DGPS receiver and extension cable) to the terminals provided in the junction box as shown in the following figure.



## CAUTION




The rubber gasket is suitable for the cable of size  $\phi 10$  to  $\phi 20$ .








### 3.8 Connection of the NKG-84 Printer (Optional Unit)





#### 4.1.4 Backlight Adjustment

The intensity of the backlight for the LCD and key panel can be selected among which can be changed each time when the **DIM** key is pressed. Note that the intensity is set to the “Low” position after turning the power on.




**Caution**

An EL plate is used for the backlight of which service life is limited. Thus, it is recommended not to overuse it to extend its service life.

#### 4.1.5 Return to the SELECT MODE Screen

A given operation will be interrupted and the screen will return to the SELECT MODE screen whenever the **MODE** key is pressed.



### 4.2 Screens

The key screens and functions for the equipment are shown in the next page.

Pressing the  key will display a given menu, which will provide ease in operating the navigator. You will be able to seize the overall operation flow by simply looking at the figure shown on the next page.

You will be able to freely operate the navigator by simply looking at the figure if you are once get accustomed to it.

## CAUTION



The password is needed to enter the setting screens on this navigator in order to comply with IMO requirement that any non-essential operation activities are not readily available from controls and to avoid changing the settings by mishandling.




The password is as follows.

press the , then input   **1** **0**  .  
password

### 4.2.1 Display and Operation List for the NWZ-4570B Navigator

#### 4.3 How to use the Navigation Information Screens

#### 4.3.2 COURSE DEVIATION IND. Screen




- \* Setting the destination
- \* Skipping to the destination
- \* Canceling the route plan
- \* Entering an event
- \* Manual leg change


Switching the CDI meter scale range (±0.1nmx ⇔ ±0.3nm)

Switching the display for the two bottom lines (CMG, VAR, and VTD display)

#### 4.4 PLOT Screen




- \* Setting the destination
- \* Switching the plot scale (Increase) (Decrease)
- \* Erasing the tracked line
- \* Setting the storage interval for the tracked line
- \* Turning on or off the display for the two bottom lines
- \* Entering an event



Switching the compass correction and manual input

Switching the display unit


Switching of the data format for DATA



Switching the geodetic system number

Switching the reception mode for the beacon signal

Switching the relay output




Designation of the waypoint number


Entering the waypoint name

Entering the latitude and longitude

Entering the bearing and distance for the waypoint



Copying the directory for the waypoint




Setting the route plan

Setting the arrival alarm range

Automatic or manual route sequence

Switching the navigation system (Great circle ⇔ Rhumb line)




Setting the arrival alarm

Setting the off-course alarm

Setting the anchor alarm

Setting the boundary alarm





Setting the estimated position

Setting the Loran time difference display

Performing the search-the-sky function

Performing the master reset function

#### 4.6 SAT STATUS Screen



Setting the averaging for calculating the position and the speed

Setting the HDOP level

Setting the position fixing mode

Setting the RAIM Accuracy level

Message Type16

### 4.3 How to use the Navigation Information Screens

The navigation information screens provide you with a variety of information you require to steer the vessel. The screens consist of the following three screens.

Screen	Key functions
NAVIGATE	This screen mainly informs you on the bearing and distance to the next destination along the route and the position of your vessel.
COURSE DIVIATION IND.	This screen mainly informs you of the deviation from a planned course.
NAVIGATE AUX	This screen enables you to select the operating mode of the equipment among compass correction, display unit, and data output format.

#### 4.3.1 NAVIGATE Screen


The screen automatically changes to the NAVIGATE screen if the first position fixing was finished after turning the power on.

The NAVIGATE screen displays the following information:

- NAVIGATE** (Screen title)
- 09:53:25** (Local time)
- RTE** (Route): 000-001
- WPT** (Waypoint): 001 α FISH1
- BRG** (Bearing): 049° m
- DTG** (Distance to Go): 6.995 m
- CD1** (Course Deviation)
- W84** (Geodetic system): WGS-84
- RAIM** (RAIM operation): 100m SAFE
- 35° 41.264' N** (Current position latitude)
- 139° 34.253' E** (Current position longitude)
- CRS** (Course over ground): 049° m
- TTG** (Time to Go): 99:59
- AUX** (AUX screen)
- SPD** (Speed over ground): 0.0 kt
- XTE** (Cross-Track Error): 0.00 L

**Course deviation (Cross-Track Error) and direction to steer**  
 L : Steer to the left  
 R : Steer to the right  
 The shortest possible course can be obtained by steering the boat to display 0.00 for the course deviation.






In case the next destination is changed to a given waypoint included in the route plan.

↓

The navigation can be resumed according to the route plan.



In case a new waypoint is set as the next destination which is not included in the route plan.

↓

The route plan is erased.


If the vessel was deviated from the route and does not return to the preset route, you can go to the destination along the shortest course.

Make the following operations to set the waypoint #002 as the next destination.

Press the **GOTO**, **0**, **0**, **2**, and **ENT** keys.

Now the leg of route plan display on the NAVIGATE screen will change from #001- #002 to #000 - #002.

Resume the route plan from #002.










Terminology

- VTD (Speed of the destination component)  
 VTD (An acronym of "Velocity Toward destination")  
 This is an index that shows how fast the boat is approaching toward the destination in the unit of knot when it is navigating at a given bearing angle and speed.
- VAR (Speed of the COG component)  
 VAR (An acronym of "Velocity Along Route")  
 This is an index that shows how fast the vessel is approaching along the planned route in the unit of knot when it is navigating at a given course and speed.
- CMG (Average bearing)  
 CMG (An acronym of "Course Made Good")  
 The bearing angle to the current position when viewed from the starting point.





Memo

- All the bearing angles will be displayed in the magnetic compass mode if a correction value other than zero is set.
- The display will be in the magnetic compass mode (the symbol “m” will be shown after a given value) if the magnetic variation is automatically corrected.
- The correction value may change from one sea area to another. In this case, a new correction value needs to be entered after coming the new area.

**4.3.3.2 Setting the Display Unit**

The distance can be displayed in either one of the two units, nm or km. The speed will be displayed in the unit of knot (kt) if nm is selected, or in the unit of km/h (KH will be displayed on the display) if km is selected. The unit is factory set to nm, press the  key provided on the right hand side of the DISP UNIT to select the desired unit.

**4.3.3.3 Selection of the Data Output Format**

Select the data format that was selected under the item 3.4.4 "Data Output".

Any one of the following six data formats can be output, which are output from the DATA OUT connector provided on the rear panel. (See the item 3.4.4 "Data Output".)

Data format	Display on the screen
NMEA0180	0180
NMEA0183 version 1.5	0183 V1.5
NMEA0183 version 2.1	0183 V2.1
NMEA0183 version 2.3 (IEC61162-1)	0183 V2.3
JRC format	JRC
NMEA0183 version 2.3/SEC	0183 1SEC

To set the data format that the connection equipment is receivable, press **MODE**, NAVIGATE , AUX , then enter password and press DATA TYPE .

Press Data 1  to set the desired output format of Data 1.

Press Data 2  to change the type of output format of Data 2.

If "NMEA0183 version 2.3 (IEC61162-1) output per second" is selected, the output sentences can be selected among the following:


ZDA, GGA, RMC, GNS, VTG, DTM, GLL, GRS, GSA, GST, GSV, MSS, APB, BWC, RMB, XTE, GBS, PJRC DGP8 (\_\_\_ : Default)

Memo

It is impossible to select all the sentences at a time.



## 4.4 PLOT Screen (Tracked Line Screen)



### 4.4.1 PLOT Screen

The following operations can be made on the PLOT screen.

#### 4.4.1.1 Setting the Horizontal Scale Range

The term range means the horizontal length on the PLOT screen. In other words, the distance between the leftmost and rightmost end of the PLOT screen will be 5 nm if the range is set to 5 nm. The ranges of 1, 2, 5, 10, 20, 50 and 100 nm are available, which can be selected by pressing either the **INC** or **DEC** key.

When the **INC** key is pressed the range will increase.

When the **DEC** key is pressed the range will decrease.

#### 4.4.1.2 Setting the Plot Interval

The equipment can store a maximum of 300 points of tracked positions.

The memory continues to store the tracked points at a preset interval, and the latest 300 tracked point data are maintained at any time. This means that the old position data will be erased in the chronological order if the tracked position data has exceeded 300 points.

- Set the storage interval with ▲ or ▼ key (scroll key).























#### 4.5.4.4 Setting the Boundary Alarm Range

An alarm can be activated when the vessel has crossed the borderline for the planned course.


The boundary alarm informs the steersman that the vessel has entered the preset area along a given course, which is defined with two given points.

The alarm can also be activated when the vessel has crossed a borderline (planned course), such as 200 nm from the coastal line or fishery agreement line, or so on.

Example) In case it is necessary to activate the alarm when the vessel has crossed the borderline for the planned course, which has been set 1.00 nm away from it. (See the figure below.)

- Press the  key provided on the right hand side of the BAUNDARY, and then the , , , and  keys.


In case the vessel is navigating from the destination 001 to 002 based on the route plan set to the destination 001 to 003. (See the figure shown below.)



#### Memo

- Pressing the  key will turn off the alarm sound, however, the alarm display will remain turned on unless the vessel has returned back into the preset alarm range or a new alarm range is entered.
- No alarm goes off when the alarm range is set to zero nm.
- The off-course alarm and boundary alarm function can not be set simultaneously since they contradict each other. Setting one alarm will automatically cancel the other.

## 4.6 SAT STATUS Screen



### 4.6.1 INITIAL SETTING Screen

#### 4.6.1.1 Setting the Initial Data

**Caution**

The initial settings will be registered on the DGPS receiver after the time difference between the universal time coordinated (UTC) and local time is enter (when the **ENT** key is pressed after entering the numerical values). The settings will be invalid if the setting operation is terminated before entering the time difference.

Enter the initial settings to the navigator if any one of the following conditions apply.

- (1) The first position fixing is to be made after installing the DGPS receiver.
- (2) The master reset function has been performed.

The navigator will automatically make settings that are required to properly operate it, which is connected to the GPS or DGPS receiver.

Entering the initial settings can reduce the time required for position fixing since they will help the equipment to locate the satellites that are required to position your vessel.

- Press the **INI** key on the SAT STATUS screen to display the INITIAL SETTING screen. Then, operate the keys in the following sequence.
  - ① Enter the vessel position latitude and longitude within the tolerance of  $\pm$  one degree.
  - ② Enter the antenna height (from the mean sea level) of the vessel.
  - ③ Enter the UTC (universal time coordinated).
  - ④ Enter the time difference between the UTC and local time.

Example) When setting the following:  
 Vessel position (N 35° 33.00' and E 139° 50.00')  
 Antenna height : 9 meters  
 UTC : 15:48 on January 11, 1999  
 Time difference : +09:00 = +9 hours

- Press the  key provided on the right hand side of the INIT L/L.
  -  ,  ,  ,  ,  ,  ,  , and  keys.
  -  ,  ,  ,  ,  ,  ,  ,  , and  keys.
  -  and  keys.
  -  ,  ,  ,  ,  ,  , and  keys.
  -  ,  ,  ,  , and  keys.
  -  ,  ,  ,  ,  , and  keys.

(The time difference needs to be obtained by subtracting the UTC from the local time and pressing the  key to select the unit (either positive or negative) for the value thus obtained.)

#### 4.6.1.2 Setting the Loran Station

Settings related to the Loran station can be made on this screen. See the item 4.7.1 “Loran Time Difference Display” for details.

#### 4.6.1.3 Search the Sky

This function may be performed if the equipment has repeatedly failed to position your vessel for a prolonged period of time and no initial settings can be made due to the unavailability of information on the approximate vessel position. (Entering the initial settings can reduce the time required for position fixing, if it is feasible.)

Normally, the approximate position of your vessel and UTC time information need to be set to the DGPS receiver in order to enable the equipment to properly position your vessel with the GPS satellites. However, this function enables the equipment to position your vessel without requiring such information inputs to it. The equipment will accurately position your vessel if it is properly installed and connected the DGPS receiver although a longer period of time would be required in this mode to position your vessel than that in the normal position fixing mode.

The function will be automatically performed if any one of the following conditions apply.

- ① After performing the master reset function
- ② When the equipment failed to position your vessel for one hour or more after turning its power on.
- ③ The position fixing is interrupted for 30 hours or more.

#### 4.6.1.4 Master Reset

This function clears all the user settings and to reset the equipment to the factory settings, which will clear all data for navigator, and DGPS receiver as well. Thus, we would recommend you to enter the initial settings to the equipment after performing this function. Entering the initial settings can reduce the time to complete the position fixing of your vessel with the GPS satellites.

Leave the equipment as is without making any operations after performing the master reset function, if the initial setting values are unknown. By doing so, the equipment will automatically perform the search-the-sky function and fix the accurately position your vessel although the time required for it will be longer than that in the normal position fixing mode as stated above.

Perform the master reset function by following either the step (1) or (2) described below after replacing the ROM IC or lithium battery mounted in the equipment, or DGPS receiver connected to the equipment.











(2) Correction for the Loran A time difference

- The time difference for the Loran A can be corrected.

Press the  key provided on the right hand side of the TD CORR to enter a correction value.

Example) Operate as described below in case it is necessary to correct the TD1 by +0.5  $\mu$  s and TD2 by -1.1  $\mu$  s.

Press the ,  and  keys.


Then, press the , ,  and  keys.

#### 4.7.1.2 Setting the Loran C Station

Press the  key on the INITIAL SETTING screen to display the REALTIME TD DATA screen (Loran station setting screen).

(1) Setting the Loran C station

- Press the  key provided on the right hand side of the LORAN A and LORAN C to highlight the LORAN C as shown in the figure below.



- Press the  key provided on the GRI CHAIN NO. to enter a value for the Loran C station to be used.

Example) In case it is necessary to enter the chain number of 9970.

Press the , , , , and  keys. (Or the setting can be made by operating the  or  key.)

(2) Setting a secondary station

- Enter the first two digits for the secondary station to be used. The operation needs to be made in the following sequence.

Press the  key provided on the right hand side of the TD DATA, then, enter the first two digits for the secondary station to be used.

Example) In case it is necessary to set 46,000  $\mu$  s for the TD1 and 60,000  $\mu$  s for the TD2.

Press the , , and  keys.

Then, press the , , and  keys.



## 5. Maintenance and Inspection

### **WARNING**



No attempt shall be made by the user to inspect or repair the equipment. Inspections or repairs carried out by unauthorized personnel can cause a fire or electric shock. Consult our local sales office or your distributor nearby your location for any inspection or repair that requires the equipment disassembly.

### **CAUTION**



Use only the specified fuse. Failure to observe the instruction can cause a fire or equipment failure.

Model : MF60NR 250V 2



Do not use the unspecified battery. Failure to observe the instruction can cause equipment failure or malfunction. The navigator and the DGPS receiver is equipped with a lithium battery to back up the RAM in the event of a power failure. The lithium battery has an average life of approx. five years, however, scheduled replacement is recommended before it is completely depleted to ensure proper equipment operation. Consult our local sales office or your distributor to have the battery replaced.

Model : CR2032-THD      JRC code : 5ZBBJ00006 (NWZ-4570B)

Model : CR2354-1VC      JRC code : 5ZBAB00108 (NNN-4331)

Daily maintenance and inspections will keep your navigator in good working conditions and prolong its service life. We would recommend you to make the following inspections before commencing the equipment operation.

- Is the equipment properly secured or any one of the mounting screws loosened? → Secure it as required.
- Are the connecting cables securely connected? → Connect them securely.
- Is the fuse blown? → Replace the fuse with a specified one.
- Is the equipment damaged? → Consult our local sales office or your distributor if the equipment malfunction is noted.
- Is any connecting cable damaged? → Use of damaged cables can cause a fire, electric shock or equipment failure. Consult our local sales office or your distributor for repair or replacement.
















### Attachment 1 Optional Units

(1) Outline drawing of NQA-4251 buffer unit






(3) NKG-84 printer specifications

● Key specifications

- Printout method : Thermal type
- Recording paper : 80 x 60 (approx. 40 meters long), JRC code 7ZPJD0044
- Operating temperature range : -15 °C to 55 °C
- Power supply : DC 10 to 35 V 7W
- Mass : 2.0 kg (Including Base)

● Outline drawing















































## 电子信息产品有害物资申明

### 日本无线株式会社

## Declaration on toxic & hazardous substances or elements of Electronic Information Products Japan Radio Company Limited

### 有毒有害物质或元素的名称及含量

(Names & Content of toxic and hazardous substances or elements)

形式名(Type): JLR-7700MkII

名称(Name): GPS Navigator

部件名称 (Part name)	有毒有害物质或元素 (Toxic and Hazardous Substances and Elements)					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr <sup>6+</sup> )	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
DGPS 接收器 (DGPS Receiver)	×	×	○	×	×	×
显示装置 (Display Unit)	×	×	○	×	×	×
外部设备(Peripherals) · 选择(Options) · 电线类(Cables) · 手册/Documents)	×	×	×	×	×	×
<p>○: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11306-2006标准规定的限量要求以下。 (Indicates that this toxic, or hazardous substance contained in all of the homogeneous materials for this part is below the requirement in SJ/T11363-2006.)</p> <p>×: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006标准规定的限量要求。 (Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials fused or this part is above the limit requirement in SJ/T 11363-2006.)</p>						

JRC Code No.: 7ZPNA4032

RE: 中华人民共和国电子信息产品污染控制管理办法

Management Methods on Control of Pollution from Electronics Information Products of the People's Republic of China





アスベストは使用しておりません  
Not use the asbestos

CODE No.7ZPNA4032

For further information, contact:



Since 1915

*Japan Radio Co., Ltd.*

URL <http://www.jrc.co.jp>

Marine Service Department

Telephone : +81-3-3492-1305

Facsimile : +81-3-3779-1420

e-mail : [tmisc@jrc.co.jp](mailto:tmisc@jrc.co.jp)

AMSTERDAM Branch

Telephone : +31-20-658-0750

Facsimile : +31-20-658-0755

e-mail : [service@jrcams.nl](mailto:service@jrcams.nl)

SEATTLE Branch

Telephone : +1-206-654-5644

Facsimile : +1-206-654-7030

e-mail : [service@jrcamerica.com](mailto:service@jrcamerica.com)

01ETM

ISO 9001, ISO 14001 Certified

©APR. 2007 Edition 1

JRC

Printed in Japan