

Thermistor monitoring S1MS

Farnell codes: 4439259-9260-9272



The S1MS thermistor monitoring relay is used in temperature monitoring circuits in accordance with EN 44081, 06/80 to protect motors, generators, storage areas etc. from overheating

Features

- For DC and AC supplies
- Normally energised mode
- Automatic reset

Approvals

	S1MS
	●
	● *
	● *

* Pending for 400 V AC version

Technical Details	S1MS
Electrical data	
Supply voltage	AC: 48, 110, 120, 230, 400 V AC/DC: 24 V
Tolerance	85 ... 110 %
Power consumption	AC: approx. 3.5 VA, DC: 2 W
Switching capability in accordance with EN 60947-4-1, 10/91	AC1: 240 V/0.1 ... 5 A/1200 VA DC1: 24 V/0.1 ... 5 A/120 W
EN 60947-5-1, 10/91	AC15: 230 V/2 A; DC13: 24 V/1.5 A
Output contacts	2 auxiliary contacts (2 C/O)
Contact material	AgCdO, 3 µm gold plating for low-load range 1-50 V/1-100 mA
Contact fuse protection in accordance with EN 60947-5-1, 10/91	Max. 6 A quick or max. 4 A slow
Measuring circuit	
Delay on energisation	Approx. 500 ms
Response value	3.6 kΩ ± 10 %
Release value	1.8 kΩ ± 10 %
Resistance at 20 °C	max. 1.5 kΩ
Mechanical data	
Max. cable cross section of ext. conductor	1 x 4 mm ² or 2 x 1.5 mm ² single core or multi-core with crimp connectors
Dimensions (H x W x D)	87 x 22.5 x 122 mm
Weight	AC: 180 g; DC: 130 g

Description

The thermistor monitoring relay is enclosed in an S-95 slimline housing. There are 5 AC versions available and one version for AC/DC operation.

Features:

- Relay outputs: 2 auxiliary contacts (2 C/O)
- Measuring circuit for connecting a temperature sensor (PTC-resistor) up to R_{max} 1.5 kΩ)
- Automatic reset
- LED display for supply voltage and fault


The S1MS meets the following safety requirements:

- Operates to normally energised mode
- Protecting the system to be monitored is guaranteed if the following cases occur:
 - voltage failure
 - coil defect
 - wire break


A temperature sensor is connected to the S1MS measuring circuit. If the temperature exceeds a defined value, i.e. the resistance of the temperature sensor reaches the response value, the output contacts switch. Contacts 11-14 and 21-24 open, contacts 11-12 and 21-22 close. If temperature falls once more, i.e. the resistance of the temperature sensor reaches the release value, the auxiliary contacts automatically switch again. The unit is ready for operation.

Thermistor monitoring S1MS

Internal wiring diagram




Timing diagram



Thermistor monitoring S1MS

Connection examples



Thermistor monitoring S1MS

General Details

Unless stated otherwise in the technical details for the specific unit.

Electrical data

AC frequency range	50 ... 60 Hz
DC residual ripple	160 %
Contact material	AgCdO
Continuous duty	100 %

Environmental data

EMC	EN 50081-1, 01/92; EN 50082-2, 03/95
Vibration in accordance with EN 60068-2-6, 04/95	Frequency: 10 ... 55 Hz Amplitude: 0.35 mm
Climatic suitability	IEC 60068-2-3, 1969
Airgap creepage	DIN VDE 0110-1, 04/97
Ambient temperature	-10 ... +55 °C
Storage temperature	-40 ... +85 °C

Mechanical data

Torque setting for connection terminals	0.6 Nm (screws)
Mounting position	Any
Housing material	Thermoplastic Noryl SE 100
Protection types	Mounting: IP 54 Housing: IP 40 Terminals: IP 20

Order reference key

U_B Supply voltage

Order references

Type	U _B	Order no.	Farnell Codes
S1MS	24 V AC/DC	839 775	4439259
S1MS	48 V AC	839 725	
S1MS	110 V AC	839 740	4439260
S1MS	230 V AC	839 760	4439272
S1MS	240 V AC	839 765	
S1MS	400 V AC	839 770	