



## **VME 602X – Series**

### **Service Manual**

## **General Remarks**

The only purpose of this manual is a description of the product. It must not be interpreted a declaration of conformity for this product including the product and software.

**W-IE-NE-R** (WIENER Plein & Baus Corp. and Plein & Baus GmbH) revises this product and manual without notice. Differences of the description in manual and product are possible.

**W-IE-NE-R** excludes completely any liability for loss of profits, loss of business, loss of use or data, interrupt of business, or for indirect, special incidental, or consequential damages of any kind, even if **W-IE-NE-R** has been advises of the possibility of such damages arising from any defect or error in this manual or product.

Any use of the product which may influence health of human beings requires the express written permission of **W-IE-NE-R**.

Products mentioned in this manual are mentioned for identification purposes only. Product names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies.

No part of this product, including the product and the software may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means with the express written permission of **W-IE-NE-R**.

**W-IE-NE-R** declines all responsibility for any damage of the VME crate or part of it and / or crate or of any equipment used inside or outside of the crate caused by improper use of it or operation / action of unauthorized not-qualified personal. This Service manual is only for qualified and authorized persons.

## **UEP 6000 Power Supply Configuration and Test Software**

The MUH6000 program is a software for Windows based PC's to test and set-up the configuration and calibration of WIENER power supplies of the UEP 6000 series. The communication is via RS232 using the WIENER UEP 6000 adapter cable.

WIENER Plein & Baus Corp. / GmbH is not responsible for any damage of the power supply and / or crate or of any module inside the crate caused by changing the factory prepared configuration and calibration of the power supply. The test and diagnostic box and MUH 6000 software has to be used by authorized and qualified personnel only!

To protect the UEP 6000 power supply for unauthorized access there is a hardware write protection. This write protection prevents unauthorized users from changing the nominal voltages, calibration values, and current limits. To override this protection you must have the Flash6.exe program.

### **!!!! DANGER - HIGH VOLTAGE !!!!**

#### **For authorized, qualified service personnel only**

This power supply uses **high voltage up to 400V** inside. Unauthorized persons are not allowed to open the UEP 6000 power supply or to connect them to AC mains or use them without completely closed chassis.

Do not open while connected to AC mains, unplug first from the wall outlet.

After opening the power supply discharge first all capacitors of primary side (AC input module and 3-pin primary distribution cables/connectors) as well as of the MUH AUX power supply with a load resistor.

In case of questions please contact:

W-IE-NE-R Plein & Baus Ltd., Dr. A. Ruben  
300 East Auburn Ave.  
Springfield, Ohio 45505  
Phone : (937) 324 2420                      FAX : (937) 324 2425  
E-mail: sales.us@wiener-d.com              URL : <http://www.wiener-d.com>


## 1) MUH 6000 installation and start

Please copy the RS232.DLL as well as the WIENER.INI configuration file to the Windows directory of your computer. Before starting the program make sure that the power supply is not connected to the AC-line. Connect the UEP 6000 power supply to the serial port of the PC via the WIENER adapter cable. **DO NOT CHANGE THIS CONNECTION WHILE THE POWER SUPPLY IS CONNECTED TO AC MAINS!!!**

Change the COM setting to fit your setup the WIENER.INI file by changing COM2 to the correct COM port of the used serial port.

Connect the power supply to the AC mains line.


During program start the software automatically detects and connects to the power supply if the RS232 connection is available through the selected COM port. The main window displays the power supply setting and status as shown in the following example. In case of any communication problem (wrong COM port, cable connection not ok, ...) the „RS232 connection is interrupted” error message is shown. The main window shows further the power supply ID (serial number or part number).



The UEP 6000 power supply can be switched on or off by mouse clicking on the POWER ON / POWER OFF line or by selecting the menu item. After switching on all power supply channels should show an „OK“ status.

## 2) Power supply operation and configuration file

Please save the present configuration of the connected power supply as a file to hard or floppy disk before changing any item. It is recommended to keep all configuration files to allow an easy restore of the configuration




data at a later time.

## 3) Power supply set-up and calibration

To access any (available) parameter point the cursor on it and click with the left mouse button.

If you do not see the parameters mentioned below, click on the “**Configuration**” menu. This will bring up a window that allows you to choose which parameters are shown.

WIENER Plein & Baus Corp. / GmbH is not responsible for any damage of the power supply, VME crate or of any module inside the crate caused by changing the factory prepared configuration and calibration of the power supply. To protect the UEP 602X power supply for unauthorized access there is software write protection. All parameters that are gray are write protected.



To enable "WRITE", you must use the WIENER flash6.exe program. This is available only to authorized personnel. Please contact WIENER for more information.

## Software Parameter Descriptions:

### **CHANNEL**


*Module definition*

define channel name

set voltage and current range setting (digits)

*Example: STBY: 31V / Ampere XXXX. / Volt XX.*

**Note: Wrong range settings can result in a wrong current and voltage display on the UEL 6020 display even in case of correct output values.**



## Voltage Calibration

### Voltage Calibration

With the UEP6000.EXE software, the lines "Calibration (Kovp)", "Calibration (Ku)" and "Calibration (Kf)" are available. These values describe the module ovp voltage divider, the module sense voltage divider, and the relation between the module coarse and fine DAC.

Typical values for different modules:

Module-Data										
MRP										
	R5[k]	alpha	Kf							
Version .B2 and below	75	0.8131	7533							
Version .B3 and above	750	0.9744	860							
Modules										
Module Type	R4,R12 [kOhm]	MRP :B2 Ku	PotI[mV]	MRP :B3 Ku	PotI[mV]	Umax [V]	R9,R10 [kOhm]	Kovp	OVPmax [V]	R5/8
5V-MEH, <= Index A5	13.3	34729	4.34	28978	0.59	5.92	27.4	24492	6.82	
5V-MEH, >= Index A6	22.1	25208	5.98	21034	0.82	8.15	43.2	15534	10.76	
MEH10	33.2	18731	8.04	15630	1.10	10.97	56.2	11941	14.00	2.2
MEH1 2, <= Index A1	61.9	11254	13.39	9391	1.83	18.26	82.5	8134	20.54	2.2
MEH1 2, >= Index A2	56.2	12223	12.33	10199	1.69	16.82	82.5	8134	20.54	2.2
MDL1 2/24, (MEH24)	110	6743	22.34	5627	3.06	30.48	133	5046	33.12	
MEH48	221	3503	43.01	2923	5.88	58.67	274	2449	68.23	4.7

To find the correct calibration values for a specific module, click in the UEP6000.EXE to the Ku value. Then the following window is displayed:

**Voltage Calibration, Channel 0** ✕

**Danger!**

During calibration the output voltage will rise over the normal limits. Continue only if you really know what you are doing. Disconnect all of your electronics and think about active backplane terminations.

ucal	<input type="text" value="755"/>		
Ku	<input type="text" value="21042"/>	DACu (Calibration)	<input type="text" value="255"/>
Kf	<input type="text" value="828"/>	measured Voltage	<input type="text"/>

Set the Ku and Kf values to the table values of the module that is used, click OK, and click to the Ku value again. Then click on the CALIBRATE button. An automatic calibration is started. Now enter the real output voltage (measured with a voltmeter) into the "measured Voltage" field. Hit the ENTER Key or click on the CALIBRATE button again. Ready.

Now you have the calibrated values for Ku and Kf. By comparing the Ku value with the table above, you could see which module you have got.

Click to the Kovp value and change it to the table value.

Now the calibration is ready, and you should set the Output Voltage and OVP levels.

Default values

	Value	Maximum
<b>Output Voltage [V]</b>	The voltage the customer wants	Umax (module table)
<b>OVP[V]</b>	125% of the Output Voltage	OVPmax (module table)


### REMARKS

In some cases, the MUH6 voltage measurement range is lower than the maximum module output voltage. (e.g., if you connect a 24V module to U0, which could measure max. 7.5V).

During calibration, the DACu value of 255 is used by default. (This will give the best accuracy). But if the module output voltage exceeds the MUH6 measurement range, the calibration will fail. In that case, you should reduce the DACu value before pushing the "CALIBRATE" button.

## Cal I-Monitor

### Current Calibration



The current calibration should be done for a current limit close to full load (90%) for each voltage channel. Connect the power supply output to a load and measure the actual current. The calibration factor is automatically calculated if writing the data for the measured current and monitor voltage to the computer and pressing "CALIBRATE". If the calibration factor is known it can be typed in directly. To store the new calibration setting for the channel press "OK".



After a current calibration the correct current monitoring should be checked for lower loads (  $\frac{1}{2}$  and  $\frac{1}{4}$  of nominal current value).

**Output Voltage** *Define Nominal Voltage*

Field	Value
Value	5.00
minimum Value	0.00
maximum Value	8.15
Exponent	-2

**Value** is the nominal voltage of the voltage channel.

**Minimum Value** is the minimum allowed value for the nominal voltage.

**Maximum Value** is the maximum allowed value for the nominal voltage.

**Exponent** gives the number of digits after the decimal.

**Current Limit** *output current limit (Secondary programmable current limit)*  
Standard setting: Hardware Limit

This Current Limit is the maximum current value that the module is permitted to produce. When this current limit is reached the module will enter into a constant current mode by lowering the voltage until it reaches the minimum allowed voltage. By default this value is set to the hardware limit of the module.

**Monitoring:Umin** *Software minimum voltage limit*  
Standard settings: 97.5% of nominal voltage Unom

The minimum voltage limit is the minimum allowed voltage for a given channel. If the voltage of that channel ever reaches or drop below the minimum value, the power supply will turn off with an “Undervoltage “ error.

Channel 0, Monitoring:Umin [V]	
Value	4.75
minimum Value	0.00
maximum Value	327.67
Exponent	-2
<input type="button" value="OK"/> <input type="button" value="CANCEL"/>	

**Value** is the minimum allowed voltage for the channel.

**Minimum Value** is the minimum allowed value.

**Maximum Value** is the maximum allowed value.

**Exponent** gives the number of digits after the decimal.

**Monitoring:Umax** *Software maximum voltage limit*

Standard settings: 105% of nominal voltage  $U_{nom}$

The maximum voltage limit is the maximum allowed voltage for a given channel. If the voltage of that channel ever reaches or exceeds the maximum value, the power supply will turn off with an “Overvoltage “ error.

Channel 0, Monitoring:Umax [V]	
Value	5.25
minimum Value	0.00
maximum Value	327.67
Exponent	-2
<input type="button" value="OK"/> <input type="button" value="CANCEL"/>	

**Value** is the maximum allowed voltage for the channel.

**Minimum Value** is the minimum allowed value.


**Maximum Value** is the maximum allowed value.

**Exponent** gives the number of digits after the decimal.

**Monitoring:Imin***Software minimum current limit*

Standard settings: No minimum (0)

The minimum current limit is the minimum allowed current for a given channel. If the current for that channel ever reaches or drop below the minimum value, the power supply will turn off with an “Undercurrent “ error.



Channel 0, Monitoring:Imin [A]	
Value	0.00
minimum Value	0.00
maximum Value	0.00
Exponent	-2
OK      CANCEL	

**Value** is the minimum allowed current for the channel.

**Minimum Value** is the minimum allowed value.

**Maximum Value** is the maximum allowed value.

**Exponent** gives the number of digits after the decimal.

**Monitoring:Umax***Software maximum current limit*

Standard settings: 100% of Hardware Limits

The maximum current limit is the maximum allowed current for a given channel. If the current of that channel ever reaches or exceeds the maximum value, the power supply will turn off with an “Overcurrent “ error.

Channel 0, Monitoring: Imax [A]	
Value	115.00
minimum Value	0.00
maximum Value	115.00
Exponent	-2
<input type="button" value="OK"/> <input type="button" value="CANCEL"/>	

**Value** is the maximum allowed voltage for the channel.

**Minimum Value** is the minimum allowed value.

**Maximum Value** is the maximum allowed value.

**Exponent** gives the number of digits after the decimal.

### **OVP** *OVP setting*

Standard settings: 125% of Unom

OVP is a secondary voltage protection. It sets the maximum voltage that a module may produce. If the module ever detects a value greater than OVP it will turn off the power supply with an “Overvoltage” error.

Channel 0, OVP [V]	
Value	6.25
minimum Value	0.00
maximum Value	10.76
Exponent	-2
<input type="button" value="OK"/> <input type="button" value="CANCEL"/>	

**Value** is the maximum allowed voltage for the module.

**Minimum Value** is the minimum allowed value.

**Maximum Value** is the maximum allowed value.

**Exponent** gives the number of digits after the decimal.

### **Temperature Limit** *Temperature Limit settings*


Standard settings: 127

Temperature Limit settings sets the maximum internal temperature of the power supply module before turning off the power supply. The default settings allow the module to run to the maximum temperature.

**Power-on Delay** *Delay between power-on and ramp*

Standard settings: 0

To allow flexibility of the voltage ramp, it is possible to set channels to begin their voltage ramp at different times. This is done by delaying the start of the ramp by some time in steps of ms.



**Temperature**

OK or Fail

**Status**

OK

**Power**

ON - OFF by software ( mouse click or <P>)

**AC**

OK - Fail (status of AC mains)

**Trip off**

Enable - Disable (temperature and OVP control enabled - disabled)

### **WARNING**

**Disable TRIP OFF only if necessary, don't leave the power supply with TRIP OFF disabled! The power supply and crate or modules in the crate can be damaged in case of error conditions without enabled automatic trip off protection.**

# Complete Test Instruction for UEP 6000

## 1. Visual test

Power Supply surface ok?  
Final set-up ok?  
Cable mounting ok?

## 2. HV-Test

2.4kVDC: *AC-mains - PE*  
Short circuit test @ 50V DC: *Output - PE.*  
- *since 1998 sticker: HIGH VOLTAGE TESTED*  
- *high voltage test has to be repeated if there are changes of the power configuration or set-up*

## 3. Put into Operation (with complete function control)

Configuration, calibration (trimmer) , current measurement adjustment ( *I-Mon* )  
Measurement of current limit (*short circuit current*)  
- *since 1998 sticker CALIBRATED*  
- *sequence of test steps according to test procedure*

## 4. Burn In

Long time test with full load and multiple on / off ( )  
- *since 1998 sticker LONG TIME TESTED*  
- *Attention: do not exceed the maximum total power (mains fuse!)*  
- *in case of parallel working AC inputs take care for equal load for both*  
- *power supply levels*

## 5. Mechanical Set-up

a) Mounting screws OK?  
b) Power terminal contacts OK?  
c) Mount missing mechanical parts and check all screws  
d) test fitting of power supply into VME bin

## 6. End check

to be done with protocol  
- *since 1998 sticker END CONTROLLED*  
- *sequence of test steps as for 3. Put into Operation*  
- write protection enabled?  
- visual check for stickers and device label

## Test Procedure Sequence UEP6000

### 1. Test AC input switch AUTO/FIX for Power Supplies with auto range AC inputs

- **AUTO** : feed 3V DC in AC mains cable, measure current (typically 0,08mA)
- switch to **115V** ( current typically 0,52mA).
- prepare for delivery with switch position to **AUTO** with locking and sticker

### 2. Start Power Supply Operation:

- disable Write protection (jumper), connect power supply to IBM-PC (RS 232)
- feed AC mains in power supply
- start software **UEP 6000**, create or copy configuration file
- *if the fan tray unit is connected to the power supply the write protection jumper has to be disabled during start for power supply software version MUH 1.00*

### 3. General behavior / settings

Main configuration OK ?  
RS 232 OK ?  
Channel? Module-current/limit? Module OVP? Module Unom?  
min/max Voltage?

### 4. Test each Voltage Channel

Check adjustment Master-Slave Imon and CV. Coding for slave  
U-nom under full Load : fine tuning ? display OK ? Noise and Ripple OK ?

Current calibration for 3 load values (full, half, no load):

<i>I-nom</i>	<i>Full load</i>	<i>Half Load</i>	<i>No Load</i>
<b>Display Fan tray</b>	?	?	?
<b>Signal I-nom</b>	?	?	?

At this time proof static regulation (U) ( Sense wiring)

T-Hold after AC-Fail, U-Dynamic, T-Recovery have been checked within power module test

### 7. Adjustments

Voltage Error adjusted?  
Current Error checked with different current values?

## Reference Table for Test and Adjustment of UEP 6000

<b>CHANNEL</b>	Module selected	Are all installed voltage channels present? <i>Example: STBY: 31V / Ampere XXXX. / Volt XX.</i>
<b>Cal I-Monitor</b>	Calibration	measure current Enter measured current and hit "CALIBRATE"
<b>Output Voltage</b>	output voltage	Nominal voltage for the channel
<b>Current Limit</b>	maximum current	The max current allowed for that channel (constant current)
<b>Monitor U-min</b>	minimum voltage	90% of nominal voltage
<b>Monitor U-max</b>	maximum voltage	112.5% of nominal voltage
<b>Monitor I-min</b>	minimum current	Generally 0
<b>Monitor I-max</b>	maximum current	112.5% of nominal expected current ("Overcurrent" error)
<b>Module OVP</b>	maximum voltage	125% of nominal voltage
<b>Power on Delay</b>	ramp Delay	Delay, in ms, between power-on and start of voltage ramp
<b>Temperature</b>		OK or Fail
<b>Status</b>		OK
<b>Power</b>		ON - OFF by software ( mouse click or <P>)
<b>AC</b>		OK - Fail (Status of AC mains at Elko)
<b>Trip off</b>		Enable - Disable



## **UEP 6000 Module Replacement Instructions**

In troubleshooting WIENER crates it is very useful to substitute Fan trays and power supplies from working crates into the crate which is problematic, this is often the best way to determine which component (fan tray, power supply, or crate) is causing the failure. It is also useful to place the power supply on a bench top and use the UEP6000 software to troubleshoot power supplies.

### **MNPFC-16**

The MNPFC-16 is the primary rectifier for the UEP6000 power supply. Common symptoms of a power supply with a faulty are MNPFC are:

- No indication that the power supply is operating.
- The green LED on the board is not lit. (Visible with case closed).
- No “click” when power supply is plugged in.
- No internal primary DC voltage from MNPFC-16 (385VDC)

If the MNPFC is found to be the problem, the following steps should be taken to replace it:

- Disconnect A/C power and remove power supply from the VME crate.
- Remove the top cover from the power supply and discharge capacitors
- Remove the side panel on which the MNPFC is mounted, including the nuts with which the module is mounted.
- Disconnect the A/C wires (Brown & Blue) as well as the flat ribbon cable and DC connector from the module.
- Installation is the reverse of removal.
- After replacing the cover, connect the A/C input and ensure that functionality is OK.

## **MEH/MDH**

The MEH/MDH modules are the secondary rectifier modules that produce the voltages used by the VME crate. Common symptoms of a faulty MEH/MDH module are:

- An over/under voltage error for a certain channel (On UEL display or via UEP6000 software).
- The power supply will start up but turn itself off quickly.

If an MDH/MEH module is found to faulty the following steps should be taken to replace it (valid only for standalone modules):

- Disconnect A/C power and remove power supply from the VME crate.
- Remove the top cover from the power supply and discharge capacitors
- Determine which power module is faulty. This is done by locating the right channel along the top of the MUH board and following the control cable to the correct module.
- Disconnect the power cables and the flat control cable(s) from the module.
- Remove the screw that holds the module to the case.
- Slide the module forward and remove the module.
- Installation is the reverse of removal.
- Calibrate the voltage and current measurements
- After replacing the cover, connect the A/C input and ensure that functionality is OK.

## MUH

The MUH module is the microprocessor control board for the power supply. Common symptoms of a faulty MUH module are:

- No function although internal operating voltage is present (385VDC).
- Under/over voltage error for 1 or more voltage channel.
- No remote interface (errors when connected to UEP6000 software).

If an MUH module is thought to be faulty the following steps should be taken to replace it:

- Disconnect A/C power and remove power supply from the VME crate.
- Remove the top cover from the power supply and discharge capacitors
- Remove the side panel next to the MUH module.
- Disconnect the flat ribbon control cables, recording where they were plugged in.
- Disconnect the sense, CAN, DC, and control cables.
- Remove the 25-pin D-sub connector to gain access to the screws holding the MUH board to the chassis.
- Remove the module from the crate.
- Remove the EEPROM from the module and place it into the new MUH module. This will transfer the channel calibration information.
- Installation is the reverse of removal.
- Once power supply cover is replaced, check that the current and voltage calibrations are correct.

## **UEP 6000 Channel Calibration**

### **Voltage Calibration**

Voltage calibration values vary depends on what kind of module you are calibrating and which nominal voltage you wish that channel to have. To calibrate a power supply channel:

- Connect the power supply to a PC and start the UEP6000 software
- Start Flash6.exe and turn off “write disabled”
- Click on “Voltage OVP” and enter the value specified in the table below.
- Turn the power supply on and measure the channel voltage.

### **Current Calibration**

Correct current calibration ensures that the power supply reports the correct current readings. To calibrate the current values for a given channel, the following steps should be taken:

- Connect the power supply to a PC on which the UEP600 software is installed via a appropriate adapter cable.
- Connect a current sink to the channel that you wish to calibrate.
- Connect A/C power and ramp the current up to 90% of the channel maximum.
- Click on “Calibration [I-monitor]” and enter the measured current.
- The UEP6000 will calibrate the current monitor and should now report the same value as the measured current.

The calibration procedure above only works for master modules. If you have two or more modules running in co-operation with each other, you will have to do a master-slave calibration. Please contact a WIENER representative for guidance with this task.

## Module-Data

### MRP

Resistor DAC[k]	12		
R6[k]	20		
	R5[k]	alpha	Kf
<b>Version .B2 and below</b>	<b>75</b>	0,81308	<b>7533</b>
<b>Version .B3 and above</b>	<b>750</b>	0,97442	<b>860</b>

### Modules

Uref(U) [10mV]	510
Uref(OVP) [10mV]	250
MRP: R13, R14 [k]	10
MRP: R17, R18 [k]	20
MRP: R4, R12 [k]	10

Module Type	R4,R12 [kOhm]	MRP :B2 Ku Poti[mV]	MRP :B3 Ku Poti[mV]	Umax [V]	R9,R10 [kOhm]	Kovp	OVPmax [V]	R5/8	R6/7	GND-floating [V]
5V-MEH, <= Index A5	13,3	34729 4,34	28978 0,59	5,92	27,4	24492	6,82	1	0	12,0
5V-MEH, >= Index A6	22,1	25208 5,98	21034 0,82	8,15	43,2	15534	10,76	1	0	12,0
MEH10	33,2	18731 8,04	15630 1,10	10,97	56,2	11941	14,00	2,21	2,21	24,0
MEH12, <= Index A1	61,9	11254 13,39	9391 1,83	18,26	82,5	8134	20,54	2,21	2,21	24,0
MEH12, >= Index A2	56,2	12223 12,33	10199 1,69	16,82	82,5	8134	20,54	2,21	4,75	37,8
MDH7-15, >= Index A0	56,2	12223 12,33	10199 1,69	16,82	82,5	8134	20,54			
MDL12/24, (MEH24)	110	6743 22,34	5627 3,06	30,48	133	5046	33,12	1	0	12,0
MEH48	221	3503 43,01	2923 5,88	58,67	274	2449	68,23	4,75	30	87,8

DACovp = U[V]\*Kovp/655.36      alte Module

---


## Connection of a Personal Computer to the Power Supply UEP6021

This connection is intended to service functions only. Because of the direct connection between the PC and the power supply, the ripple and noise of the outputs will increase!

The needed stuff is an PC running Windows, the control program UEP6 and a simple adapter (“Dongle”). The power supply is connected to the COM port of the PC. For more details, view the document \*00461.A0.


X3, 9 Pin DSUB  
male (UEP6)

9 Pin DSUB female  
(PC)



## PL6021 Connection Diagram

### POWER CONNECTOR



Pin 10,11,13...18: 6mm, 120A max.



Pin 1...9+12: 8mm, 240A max.

Polarity: + positive - negativ

U0 to U7 = standard pinning only!

SENSE/SIGNAL CONNECTOR D-SUB 37			
		19	TEMP RETURN
37	TEMP 0	18	TEMP 1
36	TEMP 2	17	TEMP 3
35	TEMP 4	16	TEMP 5
34	TEMP 6	15	TEMP 7
33	BIN EEPROM: IIC SDA	14	BIN EEPROM: IIC SCL
32	BIN EEPROM:+5V	13	VME LOGIC: SYSRESET
31	BIN EEPROM: GND	12	VME LOGIC: ACFAIL
30	VME LOGIC GND	11	VME LOGIC: SYSFAIL
29	U0 SENSE -	10	U0 SENSE + (VME: +5V)
28	VW SENSE (reserved)	9	VW SENSE (reserved)
27	VX SENSE (reserved)	8	VX SENSE (reserved)
26	U4 SENSE +	7	U4 SENSE -
25	U7 SENSE +	6	U7 SENSE -
24	U2 SENSE -	5	U2 SENSE + (VME: 48V)
23	U6 SENSE +	4	U6 SENSE -
22	U1 SENSE -	3	U1 SENSE + (VME: +12V)
21	U5 SENSE +	2	U5 SENSE - (VME: -12V)
20	U3 SENSE -	1	U3 SENSE + (VME: +3.3V)
FAN/CONTROL CONNECTOR D-SUB 9			
		5	CAN_H
9	CAN_L	4	CAN GND
8	RXD	3	TXD
7	+15V (for fan only)	2	+15V (for fan only)
6	-15V (for fan only)	1	-15V (for fan only)

## WIENER VME Crate Temperature Sensors





## VME 6000 Series Bin EEPROM configuration


**WARNING!!! Changing the BIN EEPROM setting could damage modules in the VME crate.**

WIENER 6000 series VME crates contain an EEPROM which contains data about what power supplies to accept. This prevents users from accidentally plugging in power supplies that could damage modules within the crate. If the crates function is changed and the EEPROM needs to be reprogrammed, it can be done by following the steps below.


1. Remove the fantray from the crate. This will give you access to a subD 9 pin connector. Plug one end of a WIENER power supply adapter into the connector, connect the other a computer.
2. Insert a jumper on the write protect pins for the EEPROM. The pin locations are shown below.




- Open the UEP6000 program. The current bin settings should now be visible as highlighted below.



- If screen does not show BIN configuration, select configuration and highlight these lines:



5. Select bin parameter to be changed and enter new value



6. Changes are saved automatically when you hit OK

# UEL6000 Ethernet Firmware-Update

The UEL6000 Firmware is stored in a FLASH ROM and can be updated via the RS232 connector.

Necessary equipment:

- Computer with RS232 interface, running Microsoft Windows (98 or above)
- A patch cable to connect the UEL6000 with this computer
- This software

Installation Steps:

1. Unzip the UEL6402.zip to your hard disk.
2. Connect the computers COM port to the UEL6000
3. Switch the UEL6000 into "Load Update" mode

The "Load Update" mode is a submenu of the "RS232 Configure" menu of the configuration menu.

You will use the following switches of the fan tray:

- P▲ Push "Power" switch up(ON)
- P▼ Push "Power" switch down (OFF)
- M▲ Push "Mode Select" switch up
- M▼ Push "Mode Select" switch down

Steps to get into the "Load Update" mode:

<i>Description</i>	<i>Switch</i>	<i>Display</i>
switch the crate off	P▼	_____
enter configuration menu	M▲(push and hold), P▲	Config: Wait
	hold both switches up	Config: Wait...
	after 4 seconds you can	Config: Ready !
	release the switches	+5V0 0.01V 0A
Now select the "RS232 Configure" menu	M▲ or M▼ (until right menu is displayed)	RS232 Configure
Enter this menu	P▲	Baudrate: 115.2k
Select submenu "Firmware"	M▲ or M▼ (until right menu is displayed)	UEL6000 Firmware UEL6000 4.02
Enter submenu	P▲	Load Update: No
Change to yes	M▲	Load Update: Yes
Accept settings and enter update mode	P▲	Scanning RS232..

4. Run the upload software on the computer

Open a command window, change to the folder of the unzipped file.

At the prompt enter the command

```
C:\UEL6402> F28xxConsole.exe -v -p com1 -i UEL6E.4.02.out
```

Replace "com1" with the COM port which you are using.

The software now connects to the UEL6000, the following is displayed:

Installed output message callback

```
Loading F2810SerialFlash.out
Entry point 0x003f8000
Section Address = 0x003f8000, Number of words =
3235.....
Section Address = 0x003f8ca3, Number of words = 4.
Section Address = 0x003f8ca7, Number of words = 84..
Section Address = 0x00000792, Number of words = 67..
.Boot code loaded
Connected to \.\COM1 at 5 baud
Target is programmed with "UEL6000 4.01"
Erase the flash?(y/n) y
```

This is the last chance to interrupt the update. If you say 'y' here, the UEL6000 flash is erased. Next messages are:

```
Erase the flash.
Program the flash?(y/n) y
```

You should say 'y', too. If not, you have got an empty flash which can only be reprogrammed at the factory.

```
Program UEL6E.4.02.out
Section Address = 0x003e8000, Number of words = 3676
Section Address = 0x003e8e5c, Number of words = 253
Section Address = 0x003e8f59, Number of words = 21
Section Address = 0x003e8f6e, Number of words = 629
Section ".stack" IGNORED (vaddr=0x8200 out of flash area)
Section Address = 0x003e91e3, Number of words = 3
Section ".args" IGNORED (vaddr=0x1fc out of flash area)
Section "" IGNORED (vaddr=0x340 out of flash area)
Section ".trace" IGNORED (vaddr=0x47c out of flash area)
Section Address = 0x003e91e6, Number of words = 256
Section Address = 0x003e92e6, Number of words = 32
Section Address = 0x003f7ff6, Number of words = 2
Section Address = 0x003f7ff8, Number of words = 8
Section Address = 0x003f7f80, Number of words = 118
Section Address = 0x003e9306, Number of words = 23754
Section Address = 0x003eefd0, Number of words = 3628
Section Address = 0x003f7f70, Number of words = 16
Section Address = 0x003efdfc, Number of words = 30
Section Address = 0x003efela, Number of words = 12
Section Address = 0x003efe26, Number of words = 1539
```

```
Verify UEL6E.4.02.out
Section Address = 0x003e8000, Number of words = 3676
Section Address = 0x003e8e5c, Number of words = 253
Section Address = 0x003e8f59, Number of words = 21
Section Address = 0x003e8f6e, Number of words = 629
Section ".stack" IGNORED (vaddr=0x8200 out of flash area)
Section Address = 0x003e91e3, Number of words = 3
Section ".args" IGNORED (vaddr=0x1fc out of flash area)
Section "" IGNORED (vaddr=0x340 out of flash area)
Section ".trace" IGNORED (vaddr=0x47c out of flash area)
Section Address = 0x003e91e6, Number of words = 256
Section Address = 0x003e92e6, Number of words = 32
Section Address = 0x003f7ff6, Number of words = 2
Section Address = 0x003f7ff8, Number of words = 8
```


Section Address = 0x003f7f80, Number of words = 118  
Section Address = 0x003e9306, Number of words = 23754  
Section Address = 0x003eefd0, Number of words = 3628  
Section Address = 0x003f7f70, Number of words = 16  
Section Address = 0x003efdfc, Number of words = 30  
Section Address = 0x003efe1a, Number of words = 12  
Section Address = 0x003efe26, Number of words = 1539

Press [Enter] key to exit

OK, the update is ready. Now restart the crate by removing the mains cord.  
If there are new data items in the EEPROM, after the restart they will be initialized. You have to acknowledge the "CHECKSUM xxxx" messages by pushing the "SYSRES" button at the fan tray.


## UEL6 Ethernet Pin Description

### 1. CAN-Bus (X1, X2)

RJ45	Pin	Signal	Comment
 <p>8 1</p>	1	CAN-H	
	2	CAN-L	
	3	GND	
	4	n.c.	
	5	n.c.	
	6	reserved	
	7	GND	
	8	n.c.	


This is the standard CIA pinning. Both connectors are wired in parallel, so it's easy to connect many crates in a daisy-chain.

### 2. RS232 (X2)

RJ45	Pin	Signal	Comment
 <p>8 1</p>	1	n.c.	
	2	n.c.	
	3	n.c.	
	4	GND	
	5	RXD	Output
	6	TXD	Input
	7	CTS	Output
	8	RTS	Input

This is the standard RS232D DCE pinning. Connection to DTE (e.g. computer) with a 1:1-cable.

### 3. Ethernet (X4)


RJ45	Pin	Signal	Comment
 <p>8 1</p>	1	TX+	
	2	TX-	
	3	RX+	
	4	GND 1	75 Ohm
	5	GND 1	
	6	RX-	
	7	GND 2	75 Ohm
	8	GND 2	

This is the standard NIC configuration. You need a 1:1-cable to connect a to a HUB, or a cross-over cable to connect to another NIC (e.g. a computer)






# VME6023 9U Plenum Bin




2000	Datum	Mass	Revisory
Combin	DELTA	080mm	Dimension drawing
Rev:01			9Unit Bin : Side view
Obj	W-E-N-E-R	1	1
	PLEN 16 BAUS 610H		
Zustand	Zeichnung	Datum	Rev:01



# VME6023 12U Plenum Bin






Year	Month	Day	Hour	Minute	Second	Page	Total Pages
2000	04	04	10	00	00	1	1
Dimension drawing 12Unit Bin : Side view							
W-E-N-E-R PLEN & BAUS GMBH							
Zustand	Änderung	Datum	Name/Detail		Erst		Blatt 1




C10, C11:  
max. Bauhöhe 7mm, sonst legen

<b>w-ie-ne-r Plein &amp; Baus GmbH</b>			
D-51399 Burscheid		+49-2174-678-0	
<a href="http://www.wiener-d.com">www.wiener-d.com</a>			
Title		<b>SG;I/O-Complete</b>	
Number		<b>1407053</b>	Rev <b>A5</b>
Plot	Tue Jul 13, 2004	Date	10.04.03
Filename		io-neu.PCB	
Drawn by		Fri	



w-ie-ne-r Plein & Baus GmbH	
D-51399 Burscheid	+49-2174-678-0 www.wiener-d.com
Title	I/O-Modul Sheet1
Number	1407053 Rev A5
Plot	Thu Jun 24, 2004 Date 02.April2003 Drawn by Fr
Filename	io-neu.sch Sheet 1 of 1

C1 nicht bestücken!




w-ie-ne-r Plein & Baus GmbH			
D-51399 Burscheid		+49-2174-678-0	
www.wiener-d.com			
Title			
UEL6000 CPU with Ethernet			
Number			Rev
1464212			A3
Plot	Wed Mar 10, 2004	Date	10.03.2004
Drawn by		GE	
Filename		uel6e.pcb	


DSUB9 <-> MICA10

1	6	1	2
2	7	3	4
3	8	5	5
4	9	7	6
5	-	9	-


Connection to MUH




Connection to I/O (HCT!!)




Connection to external IF (HCT!!)




Connection to CAN



RS232 Transceiver DTE Pinning (we are DCE <-> 1:1-Cable)  
11 Bauteile (0805+SOT23) weniger, wenn statt MAX232 MAX3520 verwendet wird!










Softstart (Hot-Swap)

5V-Converter







w-ie-ne-r Plein & Baus GmbH			
D-51399 Burscheid		+49-2174-678-0	
www.wiener-d.com			
Title UEL6000 CPU with Ethernet Ethernet			
Number 14644212			Rev A3
Plot	Wed Mar 10, 2004	Date	10.03.2004
Drawn by	Koe/Ge		
Filename	uel6e.sch	Sheet	4 of 4




**Montage D1, D2, U1**



**Montage Q7, Q8**



<b>w-ie-ne-r Plein &amp; Baus GmbH</b>	
D-51399 Burscheid	+49-2174-678-0
www.wiener-d.com	
Title	
<b>MUH6000 (low Noise)</b>	
Number	Rev
<b>1437008</b>	<b>B6</b>
Plot Tue Feb 07, 2006	Date 25.01.2005
Drawn by Koe / Ge	Filename muh6.PCB



Secondary Regulation:  
 R87, R92: not assembled  
 R93, C98: bridge  
 U20P34: not assembled

Primary Regulation:  
 U20: not assembled


www.wiener-Plein & Baus GmbH  
 D-51399 Burscheid+49-2174-678-0 www.wiener-d.com

Title: **MUH 6000 (Low Noise)**












Number: **1437008** Rev: **B6**

File May 09, 2006 Date: 26.01.2005 Drawn by: Koe





Filename: muh6.sch Sheet: 1 of 6






Wiener Plein & Baus GmbH  
 D-51399 Burscheid+49-2174-678-0 www.wiener-d.com  
 Title MUH 6000 (Low Noise) Digital (uP)  
 Number 1437008 Rev B6  
 Plobe May 09, 2006 Date 26.01.2005 Drawn by Koe  
 Filename muh6.sch Sheet 2 of 6














Wiener Plein & Baus GmbH	
D-51399 Burscheid+49-2174-678-0 www.wiener-d.com	
Title	MUH 6000 (Low Noise) Digital
Number	1437008 Rev B6
File Name	muh6.sch Sheet 3 of 6
Date	26.01.2005
Drawn by	Koe



47




Wiener Plein & Baus GmbH			
D-51399 Burscheid+49-2174-678-0 www.wiener-d.com			
Title		MUH 6000 (Low Noise)	
Analog Measurement			
Number	1437008	Rev	B6
File Name	muh6.sch	Sheet	4 of 6
Drawn by	Koe	Date	26.01.2005
File Name	muh6.sch	Sheet	4 of 6




wiener Plein & Baus GmbH			
D-51399 Burscheid+49-2174-678-0 www.wiener-d.com			
Title		MUH 6000 (Low Noise)	
		Sense Connection	
Number	1437008	Rev	B6
File	muh6.sch	Date	26.01.2005
Drawn by	Koe		
Sheet 5 of 6			





Close JC1 for high speed operation



CAN Operation without DC-DC Converter:


Remove R29, R58, U2, U9, U10

Connect U9 pin 3 and 6

Connect U10 pin 3 and 6

Connect U2 pin 1 and 6

Connect U2 pin 2 and 4



**Vorbereitungen:**

1. R5 mit 2.5mm Randabstand auf Alox kleben
2. Buegel fuer L1 und L4 aus 1.5mm Draht Biegen

**Bestueckungsreihenfolge:**

1. Nietmutter (19 und 20) bei L6 Bestueckungsseite
2. L2 (SMD-Spule anloeten)
3. Bauteile unter L6
4. Bauteile unter L4
5. restliche Bauteile
6. D18 wird erst veraengert auf den Rippenkuehlkoerper montiert und beim Einbau geloetet

**Nacharbeit:**

- Alle Draehnte auf Loetseite kuerzer 2.1mm  
L4 mit Silikon fixieren

w-ie-ne-r Plein & Baus GmbH


D-51399 Burscheid +49-2174-678-0 www.wiener-d.com

Title **MNPFC16**


Number **1441690** Rev **A4**

Plot Fri Jul 20, 2001 Date 18.07.01 Drawn by Ge


Filename Mnpfc16.pcb



w-i-e-n-e-r Plein & Baus GmbH			
D-51399 Burscheid		+49-2174-678-0	
www.wiener-d.com			
<b>MNPF16</b>			
Number	1441690		Rev A4
Plot	Fri Jul 20, 2001	Date	19.07.01
Filename	mnpfc16.SCH	Sheet	1 of 1



<b>wiener Plein &amp; Baus GmbH</b> D-51399 Burscheid+49-2174-678-0 www.wiener-d.com			
Title		<b>MNPFC16 Regulator</b>	
Number		<b>1449471</b>	Rev <b>A4</b>
Mon Nov 03, 2003	Date	Feb.2001	Drawn by Koe
Filename		mnpfcr16.pcb	




UNOM  
Rechtecksignal, 17Vpp  
Tastverhältnis 0...100%



URMS  
Rechtecksignal, 3.6Vpp  
Tastverhältnis 0...100%  
Spannung an URMS: 1.45-5V


1  X1:A FAN  
2  X1:B Connection


ie-ne-r Plein & Baus GmbH	
D-51399 Burscheid+49-2174-678-0 www.wiener-d.com	
Title	MNPFC16 Regulator
Number	1449471
Rev	A4
Month Nov 03, 2003	Date Jan. 2001
Drawn by	Koe
Filename	MNPFC16.SCH
Sheet	1 of 2



Wiener Plein & Baus GmbH			
D-51399 Burscheid+49-2174-678-0 www.wiener-d.com			
Title		MNPFC16 Regulator	
Number		1449471	Rev A4
Mon Nov 03, 2003	Date	Jan. 2001	Drawn by Koe
Filename		MNPFCR16.SCH	Sheet 2 of 2





	DATE	NAME	DESCRIPTION								
DRAWN	03.12.93	Fri	MEH_2-5V/100A Power CIRCUIT DIAGRAM								
CHECK											
PLOT	14.03.97	11:13									
			<table border="1"> <thead> <tr> <th>DRAWING NUMBER</th> <th>REV.</th> <th>SHEETS</th> <th>SHEET</th> </tr> </thead> <tbody> <tr> <td>1409266</td> <td>A3</td> <td>02</td> <td>02</td> </tr> </tbody> </table>	DRAWING NUMBER	REV.	SHEETS	SHEET	1409266	A3	02	02
DRAWING NUMBER	REV.	SHEETS	SHEET								
1409266	A3	02	02								



	DATE	NAME	DESCRIPTION
DRAWN	03.12.93	Fr3	MEH
CHECK			Single_Module_500W
			CIRCUIT DIAGRAM
PLOT	14.03.97	11:11	
 Flein & Baus GmbH			DRAWING NUMBER 1409266
			REV. A3/1
			SHEETS 02
			SHEET 01





Platinenmasse [mm]: 199.64x99.82  
 Platinenmaterial: FR405\_1.5mm  
 Kupferstaerke: 250um  
 Lagen: 2  
 Durchkontaktierungen: ja  
 Bestueckungsaufdruck: nein  
 Loetstop: beidseitig  
 Oberflaeche: part.verzinkt  
 Nutzen: nein

	DATE	NAME	DESCRIPTION
DRAWN	03.12.93	Fri	MEH
CHECK			Single_Module_500W
		M 1:1	PARTS LAYOUT
PLOT	09.07.98	21:24	REFERENCE NO.


**wiener**  
 Plein & Baus GmbH

DRAWING NUMBER  
**1409266**


REV.  
**A6**

SHEETS  
**01**

SHEET  
**01**



**MONTAGE LUEFTER**




CHANNEL MINUS CHANNEL PLUS

Transistormontage mit Aluoxid 4mm und Waermeleitpaste





Isolierringel Feders. M2,5x6  
Dioden mit Cho-Therm


Widerstaende nicht sicken



BOARDSICHERUNG POSITIV

w-ie-ne-r Plein & Baus GmbH			
D-51399 Burscheid		+49-2174-678-0	
www.wiener-d.com			
Title MDH Modul Double Highpower			
Number		1460193	Rev A3
Plot	Tue Oct 08, 2002	Date	02.02.02
Filename		Mdl.pcb	Drawn by GE










Schnelle Regelung

Moderate Regelung ( TENDER )


Langsame Regelung



w-ie-ne-r Plein & Baus GmbH			
D-51399 Burscheid		+49-2174-678-0	
www.wiener-d.com			
Title			MRP-DA
Number			1409657
			Rev BC
Plot	Thu May 18, 2006	Date	18.05.06
Filename		mrp SMD.pcb	
Drawn by		GE	



<b>w-ie-ne-r Plein &amp; Baus GmbH</b>	
D-51399 Burscheid +49-2174-678-0 www.wiener-d.com	
Title	<b>MRP-DA</b>
Number	<b>1409657</b>
Rev	<b>BC</b>
Plot	Mon Jun 12, 2006
Date	18.05.06
Drawn by	GE
Filename	mnp SMD.sch
Sheet	1 of 2



- X1:  
 Pin1 : CLK  
 Pin2 : CLK  
 Pin3 : PWM+  
 Pin4 : MOD-ON  
 Pin5 : BUS\_GND  
 Pin6 : CV  
 Pin7 : IMONI0  
 Pin8 : US-  
 Pin9 : BUS\_UHS-  
 Pin10 : US+  
 Pin11 : CV-INT  
 Pin12 : ISMON+  
 Pin13 : IMONI0  
 Pin14 : TEMP  
 Pin15 : DAC-CLK  
 Pin16 :  
 Pin17 : DAC-SDI  
 Pin18 : DAC-LD  
 Pin19 : UFAN-  
 Pin20 : UFAN+
- X5:  
 Pin1 : U-+  
 Pin2 : U+\*  
 Pin3 : US-  
 Pin4 : US+  
 Pin5 : COMP-U  
 Pin6 : TEMP+  
 Pin7 : GATE-OVP  
 Pin8 : US-+  
 Pin9 : US-\*  
 Pin10 : US+\*  
 Pin11 : CV-INT  
 Pin12 : ISMON+  
 Pin13 : COMP-I  
 Pin14 : ISMON-  
 Pin15 : IPMON+  
 Pin16 : GND  
 Pin17 : PWM0  
 Pin18 : PWM+

w-ie-ne-r Plein & Baus GmbH	
D-51399 Burscheid	+49-2174-678-0
www.wiener-d.com	
Title	MRP-DA
Sheet2	
Number	1409657
Rev	BC
Plot	Mon Jun 12, 2006
Date	18.05.06
Drawn by	GE
Filename	mrp.SMD.sch
Sheet	2 of 2