

255

DENON

Hi-Fi Component

SERVICE MANUAL

STEREO CD PLAYER

MODEL DCD-3500




TABLE OF CONTENTS

OPERATING INSTRUCTIONS	2 ~ 13
NOTE FOR HANDLING OF LASER PICK-UP	14, 15
DISASSEMBLY	16, 17
MECHANISM UNIT ADJUSTMENT	18
ADJUSTMENT	19 ~ 26
IC TERMINAL FUNCTION LIST	26 ~ 31
PARTS LIST OF P.W.BOARD	32 ~ 35
PARTS LIST OF EXPLODED VIEW	36
EXPLODED VIEW	37
EXPLODED VIEW OF FG-621 MECHANISM UNIT	38
PARTS LIST OF FG-621 MECHANISM UNIT	38
P.W.BOARD	39 ~ 41
WIRING DIAGRAM	42
SEMICONDUCTORS	43, 44
SCHEMATIC DIAGRAM	45, 46

NIPPON COLUMBIA CO., LTD.

IMPORTANT TO SAFETY

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION:

- 1. Handle the power supply cord carefully**
Do not damage or deform the power supply cord. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing it from wall outlet, be sure to remove by holding the plug attachment and not by pulling the cord.
- 2. Do not open the top cover**
In order to prevent electric shock, do not open the top cover. If problems occur, contact your DENON DEALER.
- 3. Do not place anything inside**
Do not place metal objects or spill liquid inside the CD player. Electric shock or malfunction may result.

Please, record and retain the Model name and serial number of your set shown on the rating label.

Model No. DCD-3560

Serial No. _____



CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user of the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instruction in the literature accompanying the appliance.

IMPORTANT (BRITISH MODEL ONLY)

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral Brown: Live

The colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows.


The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

NOTE:

This CD player uses the semiconductor laser. To allow you to enjoy music at a stable operation, it is recommended to use this in a room of 5°C (41°F) – 35°C (95°F).

LABELS (for U.S.A. model only)



CAUTION:

USE OF CONTROLS OR ADJUSTMENTS OR REPERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

THE COMPACT DISC PLAYER SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT PROPERLY QUALIFIED SERVICE PERSONNEL.

NOTE:

This unit may cause interference to radio and television reception if you do not operate it in strict accordance with this OPERATING INSTRUCTIONS.

This unit complies with Class B computing device rules in accordance with the specifications in Sub-part J or Part 15 of the FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. If the unit does cause interference to any radio or television reception, try to reduce it by one or more of the following means:

- Turn the other unit to improve reception
- Move this unit
- Move this unit away from others
- Plug this unit respectively into a different AC outlet

* This is note in accordance with Section 15.838 of the FCC Rules.

Thank you for purchasing this DENON Compact Disc Player. Please read the operating instructions thoroughly in order to acquaint yourself with the CD player and achieve maximum satisfaction from it.

— TABLE OF CONTENTS —

FEATURES	3
NAMES AND FUNCTIONS OF PARTS	4 ~ 5
BEFORE USE	6
CONNECTION	6
OPENING AND CLOSING THE DISC HOLDER AND LOADING A DISC	7
NORMAL CD PLAYBACK	7
ADVANCED CD PLAYBACK	7 ~ 10
TIMER-CONTROLLED PLAYBACK	10
THE COMPACT DISC	11
INSTALLATION PRECAUTIONS	11
PLAYBACK USING THE REMOTE CONTROL UNIT	11 ~ 12
TROUBLESHOOTING	13
SPECIFICATIONS	13

Please check to make sure the following items are included with the main unit in the carton:

- | | |
|--|---|
| (1) Operating Instructions | 1 |
| (2) LC-OFC class 1 Audio Pincord | 2 |
| (3) Remote Control Unit RC-222 | 1 |
| (4) Dry Cell Battery R03/AAA | 2 |
| (5) Mini Screw Driver | 1 |

FEATURES

The DCD-3560 Compact Disc Player incorporates DENON's Super Linear Converter which prevents deterioration of sound quality in PCM playback systems. This assures accurate reproduction of the digital signals recorded on compact discs no matter whether they are pure studio recordings or "live" performance recordings. All parts making up this CD player have been selected with the greatest care in order to produce high quality realistic playback of the full musical content on compact discs.

- Real 20-bit A.S.L.C. (Super Linear Converter)**
The use of DENON's unique system for preventing zero cross distortion, the main factor in loss of sound quality in the PCM playback section, plus real 20-bit D/A converters with superior resolution, offers reproduction of the original sound field with rich musical expression.
- High performance digital filter**
A high precision digital filter with 8 times oversampling bring out the best of the analog filter to produce crisp, clear sound.
- Thorough Anti-Vibration Structure**
The optical pickup, which requires extremely high tracing precision, is installed on a BMC (Bulk Mold Compound) with high internal loss and excellent vibration absorption, and the interior of the optical pickup mechanism is also floated using rubber with low repulsion elasticity and coil springs.
The entire mechanism is installed on a BMC chassis giving it a thorough anti-vibration structure.
- Exclusive Audio Power Transformers**
In addition to the power transformer for the digital servo circuit, the independent transformer is used exclusively for the audio circuitry, combining with the high capacity power capacitor to provide stability.
- Audio Output System with Balanced Outputs**
The DCD-3560 is equipped with balanced cannon connector outputs. There are total of three output systems, two fixed output systems (one unbalanced and one balanced) and one unbalanced variable output system, thus providing more than sufficient options even for professional use.
- Digital Outputs, Including an Optical Output**
The data on the compact disc can be output in digital format to an external digital processor or D/A unit for playback.
Aside from the two coaxial output systems, the DCD-3560 also includes an optical output which improves sound quality and eliminates noise interference.
- Simple Design**
The DCD-3560 has a simple, high quality design, with functions not often used tucked behind a door or on the remote control unit.
- Quick Time Search Function**
The time search function makes it possible to indicate a point from the beginning of a track in units of seconds, making for simple use for reference or professional purposes.
- Original Linear Motor**
A linear motor with smooth, rapid operation greatly reduces access time and improves tracking resolution for greatly fidelity in playback.
- Wireless Remote Control**
Aside from the regular functions such as play, stop, and track buttons, the remote control unit also includes a numeric keypad for the direct search, direct program, and time search functions.
These remote control functions greatly enhance the operability of the DCD-3560.

VAROITUS: SUOJAKOTELOA EI SAA AVATA. LAITE SISÄLTÄÄ LASERDIODIN, JOKA LÄHETTÄÄ NÄKYMÄTÖNTÄ SILMILLE VAARALLISTA LASERSÄTEILYÄ.


ADVARSEL: USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.

WARNING: OSYNLIG LASERSTRÅLNING VID AVLÄGSNANDE AV APPARATENS HÖLJE. UNDVIK EXPONERING AV LASERSTRÅLNING.



**"CLASS 1
LASER PRODUCT"**

NAMES AND FUNCTIONS OF PARTS



1 Power Switch (POWER)

- When the power is turned on, "00" appears in the second portion of the TIME display, and if no disc is loaded, "0000000" appears in the digital display and the calendar lights.
- If the power is turned on with a disc already loaded, the total number of tracks on the disc is displayed in the TRACK NO. display, the total time is displayed in the TIME display, and the numbers of the music calendar light up to the number of tracks on the disc, and playback begins automatically.

2 Disc Holder


- Place the disc on the disc holder with the label facing up.
- Use the open/close button (▲ OPEN/CLOSE) 3 to open and close the disc holder.
- Press the play button (▶ PLAY), pause button (⏸ PAUSE), a number button, or the disc holder directly to close it.

3 Open/Close Button (▲ OPEN/CLOSE)

- The disc holder is opened and closed by pressing this button.
- Press this button once to open the disc holder, and once again to close it.
- When the disc holder is closed with a disc loaded, the disc will rotate for a couple of seconds while the disc contents are read. The number of tracks and total playback time on the disc are then displayed on the digital display 4.

4 Display

- The digital display is divided into sections, displays for track number, index, playback time and calendar, as shown below.



5 Remote Control Sensor

- This sensor receives the infrared light transmitted from the wireless remote control unit.
- For remote control, point the supplied remote control unit RC-222 towards this sensor.
- When a signal is transmitted from the remote control unit, the remote control indicator in the display 4 will light up briefly.

6 Manual Search Reverse Button (◀◀)

- Press this button during playback for fast reverse search. As long as the button is kept pressed, music signals are played back faster than normal.
- Pressing this button when the pause mode is engaged, you can quickly reverse the pickup to a desired position, three times faster compared to manual reverse search during playback. During this time, no sound is heard.

7 Manual Search Forward Button (▶▶)

- Press this button during playback for fast forward search. As long as the button is kept pressed, music signals are played back faster than normal.
- Pressing this button when the pause mode is engaged, you can quickly forward the pickup to a desired position, three times faster compared to manual forward search during playback. During this time, no sound is heard.

8 Automatic Search Reverse Button (◀◀◀)

- Press this button to return the pickup to the beginning of the present track. Press again to return to other tracks.
- By pressing the button a number of times, the pickup will move back to the corresponding number of tracks.

9 Automatic Search Forward Button (▶▶▶)

- Press this button to move the pickup forward to the beginning of the next track. Press again to move ahead to other tracks.
- By pressing the button a number of times, the pickup will advance to the corresponding number of tracks.

10 Index Button (INDEX)

- Press this button to start playback from an index within a track. Use the number buttons 10 to specify the index number.

- 11 Program/Direct Button (PROG/DIRECT)**
- Press this button when you want to enter tracks for programmed playback. (Refer to page 8 for details.)

- 12 +10 Button (+10)**
- Press this button first when selecting track numbers over 10. Use it together with the number buttons. For example, to select track number 15, press **[+10]** then **[5]**. For track number 33, press **[+10]** three times, then press **[3]**.

- 13 Number Buttons (1, 2, 3, 4, 5, 6, 7, 8, 9 and 0)**
- Use these buttons for the direct search, time search and program memory functions. For direct search, press for example button **[3]** if you want to hear track number 3. For track number 12, press **[+10]** then **[2]**. To program tracks, press the PROG/DIRECT button to set the CD PLAYER into program mode.

- 14 Play Button (▶ PLAY)**
- Press this button to start playback of a disc.
 - When this button is pressed, **[▶PLAY]** is displayed, and the track number being played is displayed together with the elapsed playback time of the track.
 - Tracks are shown on the calendar display. Once a track has been played, the corresponding track number goes out on the calendar display.
 - With the time search function, playback can be started from specified point on the disc.

- 15 Pause Button (⏸ PAUSE)**
- Press this button to stop playback temporarily.
 - If this button is pressed during playback, playback is stopped temporarily, the **[▶PLAY]** indicator goes out and the **[⏸PAUSE]** indicator lights.
 - Press this button or the play button (▶ PLAY) again to continue playback.

- 16 Stop Button (■ STOP)**
- Press this button to stop playback. The disc will stop rotating, and the number of tracks and total playing time of the disc are displayed in the TRACK NO. and TIME displays, respectively.
 - In case programmed playback is engaged when this button is pressed, the number of tracks and total playing time of the program are displayed.

- 17 Time Mode Button (TIME)**
- This button is used to select the desired indication in the TIME display. The indication of the display will change each time the button is pressed. Normally, the elapsed playback time of the current track is displayed. Pressing the button once, **[SINGLE]** is displayed and the remaining time of the current track is displayed. Pressing once more, **[TOTAL]** is displayed, and total playing time of remaining tracks is displayed. However, when programmed play is in progress, the total remaining time of the program is displayed. Press the button once again to return to the normal display of the elapsed playback time of the current track.

- 18 Display Button (DISPLAY)**
- Press this button to change the brightness of the display.
 - Press once to make the display 2/3 as bright as normal.
 - Press once again to make the display 1/3 as bright as normal.
 - Press again to turn the entire display off during playback and all but the track number off in any other mode.

- 19 Digital Output Switch (DIGITAL OUTPUT)**
- Use this switch to turn the signals from the digital output terminals (DIGITAL OUTPUT) on and off.
 - When off, no digital signals are present on the output.

- 20 Volume Control (LINE OUT)**
- Use this to adjust the output level (volume) of the headphones or the line output (VARIABLE).
 - The same operation is possible using the included remote control unit (RC-222).


- 21 Headphones Jack (PHONES)**
- For private listening, you can connect your headphones to this jack (PHONES). Do not raise the volume level too much when listening through headphones. (Headphones are sold separately.)

- 22 Door Open Knob**
- Press to open the door.

- 23 Trap Door**
- Opens by pressing the door open knob. To close, press the right side of the door gently.

- 24 Output Terminal (FIX-VARIABLE)**
- Connect these jacks to the input jacks on your amplifier. (Refer to page 6 for details on the connections.)

- 25 Output Terminals (BALANCED TYPE)**
- These cannon type connectors are balanced outputs with an output impedance of 600Ω. Connect them to the balanced input terminals on the amplifier.
 - Cannon connector signal layout (Rear output terminals ... see Page 4-25)



- Connector: Cannon type XLR-3-32
- NOTE:** Do not short-circuit the hot or cold pin with the common pin.

- 26 Digital Output Terminals (COAXIAL-1, COAXIAL-2)**
- These terminals supply digital data.
 - Use the included RCA pin cords or 75Ω pin cords (available in stores) for connecting.

- 27 Digital Output Terminal (OPTICAL)**
- This terminal outputs digital data optically.
 - Signals are output when the (DIGITAL OUT) switch is at the 1, 2, or 1+2 positions.


- 28 Headphone/Variable Output On/Off Switch**
- Used to switch the signal of the headphone output jack and the variable output jack on and off.
 - In the off position the signal is not output to the headphone output jack or the variable output jack.

Continuous Button Operation

If the automatic search reverse button **8**, the automatic search forward button **9**, or the +10 button **12** are held in, the function of that button will be repeated.

BEFORE USE — Be sure to release the shipping lock.

- Remove the two shipping cushions inserted in the trap door.
- **"Shipping lock"**
The shipping lock keeps the laser pickup inside the player from moving during shipment.
- **When using the player**
Before turning the power on, set the player so that the front panel is facing up, insert the included mini screwdriver into the shipping lock, then turn it counterclockwise until it stops. (APPROXIMATELY 1/2 TURN).
Do not use any tool other than the included mini screwdriver. Remove the two shipping cushions inserted in the trap door.
- **Reshipping**
 - (1) Turn the power on, open the disc holder, check that no disc is loaded, then close the disc holder.
 - (2) Turn the power off, set the player so that front panel is facing up, then turn the shipping lock clockwise until it stops. (APPROXIMATELY 1/2 TURN)




CAUTION


Be sure to release the shipping lock on the bottom panel before turning the power on. When locking or freeing the shipping lock, be sure to set the player with the front panel facing up, the back panel facing down. (Refer to the diagram)

CONNECTION


- (1) **Connecting the Output Terminals (FIX-VARIABLE)**
Connect the left (L) and right (R) output terminals to the left (L) and right (R) (CD), (AUX), or (TAPE PLAY) input terminals on the amplifier using the included pin cords. There are two types of output terminals, one variable, the other fixed. To vary the output level, use the variable output terminals.



- (2) **Connecting the Output Terminals (BALANCED TYPE)**
Connect the left (L) and right (R) balanced output terminals to the left (L) and right (R) balanced inputs on the amplifier using 3-pin cords.



- (3) **Connecting the Digital Output Terminals (DIGITAL OUT)**
Connect the (COAXIAL-1) or (COAXIAL-2) digital output terminals to the coaxial digital input terminals on a digital processor or D/A unit using 75Ω pin cords. In the same way, connect the (OPTICAL) output terminal with the optical input terminal on a digital processor or D/A unit using an optical fiber cord.



Connection Precautions

- Turn the power for all equipment off when connecting or disconnecting the connecting cords.
- Be sure to connect the left (L) and right (R) sides of the cords correctly.
- Connect to the amplifier's (CD), (AUX), or (TAPE PLAY) terminals.
- Note that not plugging the pin cords in securely could result in poor connections.




OPENING AND CLOSING THE DISC HOLDER AND LOADING A DISC

Opening and closing the disc holder (This operation only works while the power is on.)

1. Press the power switch (POWER) to turn on the power.
2. Press the open/close button (▲ OPEN/CLOSE).

How to load a disc

- Make sure the disc holder is completely open.
- Hold the disc by the edges and place it on the disc tray. (Do not touch the signal surface, i.e., the glossy side.)
- When using 12 cm. diameter discs, make sure the outer edge matches the tray guide circumference (Fig. 1), and when using CD singles (8 cm. diameter) match the outer edge with the inner tray guide circumference. (Fig. 2)
- Press the open/close button (▲ OPEN/CLOSE) to close the disc holder.
- When the disc is loaded, the total number of tracks is indicated in the TRACK display, the total time is indicated in the TIME display, and the numbers in the calendar light up to the total number of tracks.
- When the disc holder is open and a disc is loaded, you may also press the play (▶ PLAY) or pause (⏸ PAUSE) button to close the disc holder. (If the play button (▶ PLAY) is pressed, playback will start immediately upon the disc contents having been read.)




Caution:

- If your finger should get caught in the disc holder when it closes, press the open/close button (▲ OPEN/CLOSE).
- Do not place any foreign objects on the disc tray, and do not place more than one disc on the tray at a time. Otherwise malfunction may occur.
- Do not push in the disc tray manually when the power is off as this may cause a malfunction and damage the CD player.


NORMAL CD PLAYBACK

(1) Starting Playback



1. Press the power switch (POWER) to turn on the power.
2. Load the disc you want to play.
 - When the disc holder is closed, the disc is read and the number of tracks and total playing time of the disc are displayed.
3. Press the play button (▶ PLAY).


(2) Stopping Playback




1. Press the stop button (■ STOP).
 - When all tracks have been played on a disc, playback will stop by itself.

NOTE:

- If no disc is loaded or if the disc is loaded upside*down, "00" appears on the TRACK display, then the entire display window changes to "00000000"




- If the data at the innermost section of the disc cannot be read properly due to scratches, dirt, etc., the display window will be as shown below. If this happens, the search operation may take more time than usual.



ADVANCED CD PLAYBACK


① Playing a Specific Track Direct Search Number buttons



(Number buttons)

- Use the number buttons and the +10 button to input the number of the desired track. For example, to play track number 4, press [4], and to play track number 12, press [+10] and [2]. Playback will begin from that track.


② Advancing to the next track during playback Automatic Search



(▶▶)

- Press the Automatic search forward button (▶▶) during playback.
- The pickup will advance to the beginning of the next track and playback will continue. Pressing the button several times will forward the pickup to the corresponding number tracks.

3 Returning to the beginning of the current track during playback **Automatic Search**




Press the Automatic search reverse button (⏮) during playback.

- The pickup will return to the beginning of the current track and playback will continue. Pressing the button several times will return the pickup the corresponding number tracks.

4 Audible quick search **Manual Search**


- Using this function, you can cue to a desired point within a track, either in the forward or reverse direction.
- Release the manual search button (⏪ or ⏩) when the desired point has been reached. Normal playback then continues.

(1) Manual Search Forward



1. Press the manual search forward button (⏩) during playback. Playback of the track is sped up.
 - As a reference, the current track number and elapsed playback time within the track are displayed.
 - Manual search forward is approximately three times faster when engaged during the pause state compared to playback. However, in this case, no sound is heard.
 - If the manual search forward button (⏩) is kept pressed after the end of the final track on the disc is reached, (∞) is displayed and manual search stops. To return to another point, press the manual search reverse button (⏮) until (∞) disappears.

(2) Manual Search in Reverse




1. Press the manual search reverse button (⏮) during playback. Reverse playback of the track is sped up.
 - As a reference, the current track number and elapsed playback time within the track are displayed.
 - Manual search in reverse is approximately three times faster when engaged during the pause state compared to playback. However, in this case, no sound is heard.
 - If the manual search reverse button (⏮) is kept pressed after the beginning of the first track on the disc is reached, (∞) is displayed and manual search stops. To return to another point, press the manual search forward button (⏩) until (∞) disappears.

5 Playing Specific Tracks in a Specific Order **Programmed Play**

- With this function, you can choose any of the tracks on the disc and program them to play in any order.
- Programming is possible with the disc holder open.
- Up to 20 tracks can be programmed.
- The programmed tracks are shown on the calendar.

(1) Programming




- Press the PROG/DIRECT button so that the PROGRAM indicator lights, then use the number buttons and the +10 button to program the tracks. For example, to program tracks 3, 12, and 7, press PROG/DIRECT, [3], [+10], [2], and [7]. The corresponding track number lights on the calendar each time a track is programmed, the track number is displayed in the TRACK NO. display, the number of tracks programmed is displayed in the INDEX display, and the total playing time of the programmed tracks is displayed in the TIME display. A few seconds after the last track has been programmed, the total number of tracks programmed is displayed in the TRACK NO. display and the total playing time of the programmed tracks is displayed in the TIME display.
- The program will remain in the memory for approximately 2 days, even if the power is turned off after setting the program or during program playback.

NOTE:


- Leave the power on for at least 10 minutes to fully charge the memory power supply. If the power is only left on a short while, the memory will be cleared that much sooner.
- It is not possible to program more than 20 tracks.
- The remaining time per track will only be displayed for the first 20 tracks on the disc.
- The total programmed time and the remaining time for the program will also not be displayed if track number 21 or greater is programmed.

(2) Checking Programmed Tracks



- Press the CALL button. The programmed tracks are displayed in order in the TRACK NO. display each time the CALL button is pressed.

(3) Correcting Programs



- To correct a programmed track, press the CLEAR button, then program the correct track. The last programmed track will be cleared and the correct track will take its place.
- To erase a programmed track, recall it with the CALL button, then press the CLEAR button and the STOP button, in that order. The track will be erased.

(4) Playing the Programmed Tracks

- Press the (▶ PLAY) button to play the tracks in the programmed order.


(5) Clearing the Program

- The entire program is cleared when the PROG/DIRECT button is pressed again. The program is also cleared when the (▲ OPEN/CLOSE) button is pressed.
- If the PROG/DIRECT button is pressed during programmed play, the program is cleared and playback continues normally through to the last track on the disc.

NOTES

- If programming is done in the play or pause mode, the track currently playing is programmed at the first position. Other tracks can be added to the program, but the number of programmed tracks and the playing time will not be displayed.
- Direct search is not possible during programmed play. If the number buttons are pressed, that track is added to the end of the program.
- Programming is possible with the disc holder open. Track numbers greater than the number of tracks recorded on the disc can be programmed, but will be automatically cleared before playback begins.

(6) Pausing playback at any point Pause




- Playback can be temporarily halted and then continued from the same point in the track.
1. Press the pause button (|| PAUSE) during playback.
 2. To continue playback, press the play button (▶ PLAY) or the pause button (|| PAUSE) once more.

(7) Searching and Pausing at the Beginning of the Track Pause

(1) With Direct Search

- In this case, the set pauses at the beginning of the track found with the direct search operation.




- 1 Press the (|| PAUSE) button.
 - 2 Press the number button(s) for the desired track.
- To start playback, press the (▶ PLAY) or (|| PAUSE) button.

(2) With Program Search

- Press the (|| PAUSE) button after the program search operation is completed. The set will pause at the beginning of the first programmed track.

(8) Finding Sections Within a Track Index Search

- With this function, you can find and play from the beginning of sections within the track marked by index numbers.




- (1) "--" appears on the TRACK NO. display when the INDEX button is pressed.
- (2) Input the track number using the number buttons. Next, "--" appears on the INDEX display. Input the desired index number, and playback will start from that index number. For example, to start from index 2 on track number 3, press INDEX, 3, then 2.

Indexes

- Indexes are numbers which are assigned to sections within a track. Check the disc's explanatory notes for the index numbers.
- If you input an index number not on the disc, playback will start from the last index number on the track.


(9) Repeating playback of all tracks Repeat All



- (1) Press the repeat all button (ALL).
 - (2) Press the play button (▶ PLAY).
- When pressing the repeat all tracks button (ALL), [ALL] is displayed.
 - Steps (1) and (2) above may be reversed.
 - To cancel repeat playback of all tracks, press the repeat all button (ALL) once more.
 - Pressing the repeat all button (ALL) during programmed playback, playback of the tracks entered into the memory will be repeated.

(10) Repeating a Single Track 1-track Repeat

- Press this button if you want to hear a track repeatedly.



- When the 1-track repeat button (REPEAT-1) is pressed during playback, only the number of the track currently playing will remain lit on the calendar, as long as the track number is not over 20, and that track will be repeated.
- If the track number is 21 or over, the 1-track repeat function will work, but nothing will be lit on the calendar.

- When the 1-track repeat button (REPEAT-1) is pressed in the stop mode, track number 1 lights on the calendar and the 1 track repeat function is possible. To start, press the (▶) PLAY button.
- To cancel 1-track repeat, press the 1-track repeat button (REPEAT-1) once again. Normal playback will resume.

① Playing a desired time or interval Time Search

- With this function you can specify the starting time and/or ending time in seconds, allowing playback of a very specific section of a track.

■ In the Stop Mode

- Specifying the starting time

- ① Press the TIME SEARCH button. The [TIME SEARCH] indicator will flash on the display, and the TRACK display will read "--".
- ② Use the number buttons to set in order the track number and the time (minutes and seconds).

Example: Starting from 2 minutes 34 seconds into track 3

Press the following buttons in order: [TIME SEARCH], [0], [3], [0], [2], [3], [4].

NOTE: If a track number or time not on the disc is set, the unit will return to the mode it was in before the first buttons were pressed.

- ③ Press the (▶) PLAY button to begin playback from the specified time.

- Specifying the ending time

The ending time can be set before pressing the play button while the [TIME SEARCH] indicator is flashing using the following procedure:

- ④ Press the TIME SEARCH button. The [TIME SEARCH] indicator will stop flashing and the TRACK display will read "--".
- ⑤ Use the number buttons to set in order the track number and the time (minutes and seconds).

NOTE: It is not possible to set an ending time at a point before (or the same as) the starting time.

- ⑥ After specifying the ending time, press the (▶) PLAY button to begin repeated playback between the two specified points. (A-B repeat by specifying the time)

■ In the Play Mode

- ① When the TIME SEARCH button is pressed, the current track number and time (minutes and seconds) are stored in the memory and the [TIME SEARCH] indicator begins flashing.

- ② When the (▶) PLAY button is pressed, playback starts from the starting point stored in the memory. To start playback over from the specified point, press the (▶) PLAY button again.

- ③ If the TIME SEARCH button is pressed again, the ending time is stored in the memory, the [TIME SEARCH] indicator stops flashing, and the interval between the starting point and ending point is played repeatedly. (A-B repeat)

To cancel the time search function, press one of the following buttons:


- (1) PROGRAM/DIRECT
- (2) DIRECT (on remote control unit)
- (3) OPEN/CLOSE

NOTE:

- If the search function is used after a track number and time (minutes and seconds) are specified with the disc holder open and no disc set, playback will start from the beginning of the first track on the disc.
- If a time over the time on the disc is specified, playback will start from the beginning of the track following the specified track.

⑫ Inserting blanks between tracks Auto Space

- This is convenient feature that will insert 4-second blanks between tracks, which can be used when recording compact discs on tape.



1. Pressing the auto space button (AUTO SPACE) will cause the [AUTO SPACE] indicator to light.
2. Press the play button (▶) PLAY to start playback. When a track has been played to its end, a 4-second silence is made before the next track starts playing.
3. Press the auto space button (AUTO SPACE) again to cancel the function.

TIMER-CONTROLLED PLAYBACK


■ Operation

1. Turn on the power of all system components.
2. Set the input selector on the amplifier to correspond to the input the CD player is connected to.
3. Make sure a disc has been loaded in the disc holder.
4. Check the time on the timer and then set the desired turn-on time.
5. Turn the audio timer ON. Power is turned off automatically in all components connected to the timer.
6. When the preset turn-on time is reached, power is turned on in the system components, and CD playback starts from the first track.

NOTE:

The program will remain in the memory even if the power is turned off after setting the program or during program playback. After approximately two days, however, the program memory is cleared, reset the program, as necessary.

■ Connection



THE COMPACT DISC

1. Precautions on handling compact discs

- Do not allow fingerprints, oil or dust on the surface of the compact disc. If the signal surface is dirty, wipe it off with a soft, dry cloth. Wipe in circular motions from the center to the outside edge.
Use of DENON's AMC-20/21 CD cleaner is recommended.
- Do not use water, benzene, thinner, record sprays, electrostatic proof chemicals, or silicone-treated cloth to clean discs.
- When handling discs always take care to prevent damaging the surface, in particular when removing a disc from the case and returning it.
- Do not bend compact discs.
- Do not apply heat to compact discs.
- Do not enlarge the hole in the center of the disc.
- Do not write on the disc and do not attach any labels.

- Condensation will form on the disc surface if it is brought into a warm room from a cold area, such as outdoors during winter. Wait until the condensation disappears. Never dry discs with hair dryers, etc.


2. Precautions on storage

- After playing a disc, always return it to its case.
- Keep discs in the cases when they are not to be played. This will protect them from dust and dirt and prolong their service life.
- Do not store discs in the following places:
 - 1) Places exposed to direct sunlight for a considerable time.
 - 2) Places subject to accumulation of dust or high humidity.
 - 3) Places exposed to high temperatures, such as close to heater outlets.


INSTALLATION PRECAUTIONS

The CD player uses a microcomputer for controlling internal electronic circuits. In the event that the player is used while a near-by tuner or TV is turned on, although unlikely, interference could occur either in the sound from the tuner or the picture of the TV. To avoid this, please take the following precautions.

- Keep the CD player as far away from the tuner or TV set as possible.
- Keep the power cable and connecting cable of the CD player separate from the antenna wires of the tuner and TV.
- Interference is particular likely to occur when an indoor antenna or a 300-ohm feeder cable is used. Thus, use of an outdoor antenna and 75-ohm coaxial cable is strongly recommended.



300-ohm feeder cable




75-ohm coaxial cable

PLAYBACK USING THE REMOTE CONTROL UNIT


The accessory RC-222 remote control unit can be used to control the CD player from a convenient distance.

(1) Inserting the dry cell batteries


1. Remove the battery cover on the back of the remote control unit.



2. Insert two R03 (standard size AAA) dry cell batteries with correct polarity as indicated inside the battery compartment.




3. Replace the battery cover.



(2) Directions for Use

- Operate the remote control unit while pointing it towards the remote control sensor on the CD player (see below).



Notes on the Batteries


- The remote control unit uses standard size AAA dry cell batteries.
- The batteries will need to be replaced approximately once a year. Replacement may be necessary earlier depending on how much the remote control unit is used.
- If, in less than a year from the time new batteries were inserted, the remote control fails to operate the CD player from a near-by position, it is time to replace the batteries.
- Insert the batteries properly, following the polarity diagram inside the battery compartment, in other words make sure (+) and (-) terminals are properly aligned.
- Batteries are prone to damage and leakage. Therefore:
 - Do not combine new batteries with used ones.
 - Do not combine different types of batteries.
 - Do not jumper opposite poles of the batteries, expose them to heat, break them open nor expose of them in open fire.
- If the remote control unit is not to be used for a long period of time, remove the batteries from the unit.
- If the batteries have leaked, remove any traces of battery fluid from the battery compartment, wiping thoroughly with a dry cloth. Then insert new batteries.

When a remote control signal is received, the remote control indicator on front of the CD player lights briefly.

- The remote control unit can be used at a distance up to 8 meters in a straight line from the CD player. This distance is decreased if there are obstructions blocking the signal path or when the remote control unit is operated at an angle from the remote control sensor.
- The buttons on the remote control unit have identical functions with those on the CD player. However, the following functions cannot be remote controlled: Power ON/OFF, Digital output switching and Trap door opening.

Cautions on Use

- Do not press the operation buttons on the main unit and on the remote control unit simultaneously, as this will result in malfunction.
- The remote control unit may not operate properly if the remote control sensor is exposed to direct sunlight or strong artificial lighting, or if there is an object between the remote control unit and the remote control sensor.



• **Direct Search**

Normally, direct search is possible simply by pressing the desired number buttons.

• **Program Search (programming is not possible during playback)**

Press the PROGRAM button, then press the number buttons.

For example, to program tracks number 3, 11, and 5, press PROGRAM → 3 → +10 and 1 → 5.

To cancel the program, press the DIRECT button.

• **Inputting the Track Numbers**

For track numbers below 9, simply press the corresponding button. For track numbers of 10 and greater, press the +10 then the number buttons.

For example, for track number 22 press +10 twice then 2.

• **Volume**

The volume control on the unit will operate when the volume buttons are pressed. The volume can be checked by looking at the position of the control.

• **Auto Edit Button (AUTO EDIT)**

* The tracks on a CD are automatically split into two halves, Side A and Side B, like an analog disc, with the division at the place between tracks which is closest to 1/2 the total playing time, and with the tracks remaining in the same order.

* When this button is pressed in the stop mode, the total playing time for the first half and the track numbers on the calendar are displayed for approximately 2 seconds. Next, the same is done for the second half, after which the unit is automatically set to the pause mode at the beginning of the first track. When the PLAY or PAUSE button is pressed, playback begins, and the unit is automatically set to the pause mode at the beginning of the first track of the second half which was previously displayed. When the PLAY or PAUSE button is pressed again, playback begins, and the unit is automatically set to the stop mode at the end of the last track on the disc.

* This function will only work for discs with a total of 20 tracks or less. Also, when this function is used the mode is automatically set to the program mode, so direct search is not possible.

* The auto edit function is cleared when the STOP or DIRECT button is pressed.

* The data for the total playing time recorded on the disc and the actual total playing time of the tracks differ, so there may be a difference between the time displayed in the stop mode (the total playing time) and the total of the times of the first and second halves in the auto edit mode (about 2 seconds).

TROUBLESHOOTING

If the CD player does not seem to be functioning properly, check the following:

Disc holder does not open or close.

- Is the power on?

When a disc is loaded, 00 00 0000 is displayed.

- Is the disc loaded properly? See page 7
- Has the shipping lock been released? See page 6

When the play button (▶ PLAY) is pressed, playback does not start.

- Is the disc dirty or scratched? See page 11

There is no sound, or it is distorted.

- Is the output cord properly connected to the amplifier? See page 6
- Have the amplifier controls been set correctly?

A specific section of the disc will not play.

- Is the disc dirty or scratched? See page 11

Programmed playback does not work.

- Have programming been properly done? See pages 8 and 12

Index search does not work. (only 1 displayed)

- Is the index search option proper? See page 9
- Check whether there are 2 or more index numbers for that track.

Incorrect operation when buttons on the remote control are pressed.

- Is the remote control unit being operated too far from the CD player? See page 11
- Are there obstacles blocking the ray?
- Is the remote control sensor exposed to strong light?
- Are the batteries exhausted?

SPECIFICATIONS

AUDIO SECTION

Number of channels:	2
Frequency response:	2~20,000 Hz, ±0.2 dB
Dynamic range:	100 dB or greater
S/N ratio:	120 dB (1 kHz)
Harmonic distortion:	0.0015% (1 kHz)
Separation:	110 dB (1 kHz)
Wow/flicker:	Below measurable limits (±0.001% W peak)
Output voltage:	Fixed: 2.0 Vrms Balanced type: 2 Vrms/10 kΩ load Variable: 2.0Vrms/line out volume max. (Variable output voltage with no 600Ω load on balanced type output)

DISC

Diameter:	120mm/80mm
-----------	------------

SIGNAL FORMAT

Sampling frequency:	44.1 kHz
Quantization bit:	16-bit linear/bi-phase
Transfer bit rate:	4.3218 Mb/sec.

DIGITAL OUTPUT SIGNAL FORMAT

Format:	Digital audio interface AES EBU
Coaxial output voltage:	0.5 Vpp, 75Ω
Optical power:	-12 dBm
Light wavelength:	650 nm

PICKUP

Type:	Objective lens driving type optical pickup
Objective lens driving method:	Two-dimensional parallel driving
Light source:	Semiconductor laser
Wavelength:	780 nm

GENERAL

Power supply:	50/60 Hz voltage is shown on rating label.
Power consumption:	32 W
External dimensions:	434 (17-3/32") (W) × 135 (5-5/16") (H) × 390 (15-23/64") (D) mm
Weight:	17 kg

FUNCTIONS AND DISPLAYS

Functions:	Direct search, automatic search, program search, repeat play, manual search, index search, time search
Displays:	Track number, index, time, program
Others:	Headphones jack (variable level), digital output terminals (three systems—2 coaxial, 1 optical), fixed level output terminals (unbalanced/diaphone), variable level output terminals (unbalanced)

REMOTE CONTROL UNIT RC-222

Remote control method:	Infrared pulse type
Power supply:	DC3V, two R03/AAA batteries
External dimensions:	60 (W) × 164 (H) × 16 (D) mm
Weight:	98 g (including batteries)

ADDITIONAL ACCESSORIES


Wood side panels ACA-58.

Please contact your local DENON dealer for any additional accessories you may need.



* For improvement purposes, specifications and design are subject to change without prior notice.

NOTE FOR HANDLING OF LASER PICK-UP

• **NAMES OF PARTS**




• **NAME PLATE**



• **CONNECTION DIAGRAM OF CONECTOR (1)**
KSS 151A Accessory flexible wire terminals.


No.	Description	No.	Description
1	Linear motor	11	PD
2	Linear motor	12	VR
3	2-axis -F	13	GND
4	-T	14	PD D
5	+T	15	C
6	+F	16	A
7	Senser	17	B
8	Senser	18	K
9	LD GND	19	F
10	LD	20	E

Soldered Short Circuit Portion (A)



• **CONNECTION DIAGRAM OF CONECTOR (2)**

KSS-151A → SERVO AMP P.W.B → MAIN P.W.B.



NOTE:
In case of either detaching the SERVO AMP P.W.B., or disconnecting the 23P FFC CABLE out of the P.W.B., be sure to make bridge soldered for both soldered point (A), and the soldered point (B), respectively, in both case.

Cautions for Handling the Laser Pick-up

The laser pick-up KSS-151A is assembled and precisely adjusted using a sophisticated manufacturing process in our plant. Do not disassemble or attempt to readjust it. Please keep the following instructions carefully in handling pick-up.

1. Handle with Care

- (1) Storage
Do not store the pick-up in dusty, high-temperature or high-humidity environments.
- (2) Please take care for preventing from shock by falling down or careless handling.

2. Laser Diode (LD)

- (1) Protect your eyes
The laser beam may damage the human eye, since the intensity of the focused spot may reach $7 \times 10^3 \text{ W/cm}^2$ even if the intensity at the objective lens is $400 \mu\text{W}$ maximum. As the light beam spreads after focused through the objective lens, it does not effect you in the place as far as more than 30 cms. However, do not look at the laser light beam either through the objective lens directly nor another lens or a mirror.
- (2) Poison of As
Since the LD chip contains As (Arsenic), as GaAs + GaAlAs, as known as the poison, although the poison is relatively weak, in comparing with others, e.g. As_2O_3 , AsCl_3 etc., and the amount is small, avoid putting the chip in acid or an alkali solution, heating it over 200°C or putting it into your mouth.
- (3) Avoid surge current or electrostatic discharge
The LD may be damaged or deteriorated by its own strong light if a large current is supplied to it, even if only a short pulse.
Make sure that there is no surge current in the LD driving circuit by switches or else. Be careful to handle pick-up as it may be damaged in a moment by human electrostatic discharge. The pins of the LD are short-circuited by solder for protection during shipment.
For safety handling of an LD, grounding the human body, measuring equipments and jig is strongly recommended. And still it is further desirable to make use of mat on the platform and floor for handling the LD.
To open the short circuit, remove the soldering quickly with a soldering iron whose metal part is grounded. The temperature of the soldering iron should be less than 320°C (30W).

3. Actuator

- (1) The performance of the actuator may be effected if magnetic material is located nearby, since the actuator has a strong magnetic circuit. Do not permit dust to enter through the clearance of the cover.

(2) Cleaning the lens

It may change the specifications by attaching dust or ash on the object lens. Clean the lens with a cleaning paper dampened a little water, not pressing lens with so much strength by the cleaning paper.

4. Metal Bearing

As the metal bearing of Cu-compound sintered alloy is impregnated with FROIL946P (*Part No. 529 0054 007), never fail to supply the bushing with the same lubricant at the time of replacing the pick-up.

5. Handling

Please handle the laser pick-up with holding the slide base (rosin molded part).

When either a part of human body or some other things may happen to touch directly with the circuit part of P.W. Board, it may cause deterioration, take careful attention in handling this base.

6. Deterioration

When difficulty occurs either in focus or tracking adjustment nor able to adjust the focus or tracking, it seems that the laser pick-up is deteriorated. In these cases, check a value of laser diode current and give a decision for deterioration.


7. Fundamental Deterioration Decision of Laser Pick-up

- (1) If a voltage value in between No. 2 and No. 6 pins of TP102 of the servo and signal processor unit, the value of laser diode current "iop" can be found by a formula
$$\text{"iop1"} = \frac{V1}{22}$$
- (2) If an "iop" exceeds $\pm 10\%$ compared with the IOP indication on the laser pick-up nameplate, there is a fair chance for deterioration when it is checked under a circumambient temperature 23°C .
- (3) When the circumambient temperature changes $\pm 10^\circ\text{C}$, "iop1" will change $\pm 5\%$. The "iop1" will also be changed by the passage of time.
- (4) In case of the above conditions taking into consideration and performed the adjustment in proper way, if the HF level at pin No. ① of TP102 on Main Unit, and in between GND4 becomes 1V or lesser values; or ajitter occurs great, the laser pick-up may be deteriorated.

DISASSEMBLY


1. Top Covers (A) (B) Removal

Remove 6 screws on the top and detach the Top Covers (A) (B) as per the arrow shows.




2. Side Panels (L) (R) Removal

Unfasten 4 screws from the both sides and remove the Side Panels (L) (R) as per the arrow shows.



3. Front Panel Removal

Remove the loader and unfasten 2 screws and remove the loader panel as indicated by the arrow. Unfasten 6 screws on the top and bottom and detach the Front Panel as per the arrow shows.





● **Housing Ass'y Removal**

- Removing 4 screws (A) 1, (A) 2 enables detaching the laser pick-up magnet, yoke, turntable, and spindle motor as one assembly.
- Unfastening screws (A) 1, (A) 2 permits disassembling the parts for floating as illustration shows.
- A common type are used for F cover and H damper, but the 2 different types are utilized for coil spring and collar to keep balance. Remind this at the time of assembling.


A -1	463 0515 000 Coil spring (D)	433 0485 100 Collar (B)
A -2	463 0514 001 Coil spring (C)	433 0514 007 Collar (C)

- Coil Spring (D) (utilizing 3 each) is marked in red.
- Coil Spring (C) (utilizing 1 each) is without marking.
- Collar (C) (utilizing 1 each) is nickel plated brass.
- Collar (B) (utilizing 3 each) is black plated brass.



● **Laser Pick-up KSS-151A Removal**


- (1) Remove the housing ass'y in the first place, then loosen the screw (refer to "Mechanism Exploded View" (59)) mounting the turntable, and detach the turntable.
- (2) Unfasten 2 screws (F) and detach the spindle motor ass'y.
- (3) Remove 6 screws (B) as indicated in the illustration of "Housing Ass'y Removal".
- (4) Unsecure 2 screws (A) and unsolder 2 places (B) and detach the speed detection coil.
- (5) Remove 2 screws (C) and unsolder 2 places (D) and detach the drive coil.
- (6) Pulling out the shaft in the portion (E) permits detaching the Laser Pick-up.



MECHANISM UNIT ADJUSTMENT


• Turntable Height Adjustment

- (1) Mount the spindle motor ass'y to the housing with 2 screws. (Refer to the illustration of "Laser Pick-up KSS-151A Removal")
- (2) Set the Turntable to the shaft and insert the 2 mm spacer (jig) between the Turntable and the housing as illustration shows.
- (3) While lightly pressing the Turntable from the top side, tighten screw ⑥ with a hex. wrench.




• Spindle Motor Adjustment

- (1) Disassemble Mechanism Unit in the first place, then detach the Spindle Motor Ass'y.
- (2) Connect the adjustment wire connector (6P) to the measuring equipments as per illustration shows.



- (3) Adjust the balance volume control VR1 and obtain even amplitude for vertical (A) and horizontal (B). (Rotating the VR causes shifting (B) amplitude.)
- (4) In case using a dual mode oscilloscope to execute adjustment, set it to ALTER or CHOPPER mode and apply a signal to CH1 and CH2. Then adjust the balance volume control VR1 and obtain even amplitude for both waveforms as illustration shows.



Note: Be noted that a greater input signal causing the saturation of waveform.

ADJUSTMENT

Microcomputer built in the unit, comprises service program to facilitate servo adjustment by pushing operation button.

1. Start service program

- (1) Turn power switch OFF.
- (2) Shortcircuit jumpers J37, J39 on servo P.W.B. (2U-2007)
(Caution) Do not touch other jumpers.
- (3) Turn power switch ON.
(Service program starts, and displays track number 01)

(Caution)

- When service program started normal operation of buttons will be defeated.

2. Service program function

Button	Function	Description
▲ OPEN/CLOSE	Opens or closes the disc holder.	<ul style="list-style-type: none"> • Opens or closes only when disc is stopped. • Operate other keys after open or close..
■ STOP	Stops system function.	<ul style="list-style-type: none"> • Displays track number 01. • Push when adjustment completed, or do it again.
▶ PLAY	Starts focus servo and disc turns.	<ul style="list-style-type: none"> • Push when adjust tracking offset. • When completed, displays track number 02.
PAUSE	Starts focus servo, tracking servo, slide servo, spindle servo.	<ul style="list-style-type: none"> • When PLAY button is pushed, starts tracking servo and slide servo. • When completed, track number 03.
Other button	No normal operation.	<ul style="list-style-type: none"> • Do not operate buttons other than above. • If misoperated, immediately turn power switch OFF..

(Caution)

- Do not use remote control during service program mode.


3. Adjustment

(1) Prior to start adjustment


Before adjusting laser P.U. and spindle motor, be sure adjust turntable height at the time of turntable assembly.

(2) Necessary equipment for adjustment

- 1 Dual trace oscilloscope
- 2 Reference disk (CA-0094) 富田靖子
- 3 Oscillator (10 Hz ~ 10 kHz, 0 ~ 3 Vp-p)
- 4 Frequency counter (readable more than 5 MHz)
- 5 Filter for measurement are provided in servo P.W.B. (2U-2007)




(3) Location




(4) Preset

1.	Start service program.	
2.	Preset VR101 ~ 104, 201, 202 as per left figure.	
3.	Step.	<ol style="list-style-type: none"> 1. PLL 2. Slide offset 3. Tracking offset 4. Focus gain 5. Focus offset 6. Tracking gain 7. Tracking offset recheck

4. PLL Adjust

Connection		
		
<ul style="list-style-type: none"> • Ground Test point [ASY] to GND. 		
Adjust	Check	Step
(Volume)	(Counter)	<ul style="list-style-type: none"> • Turn PLL volume VR 103 so that frequency counter reads 4.32 MHz.
VR103	4.32 MHz \pm 10 kHz	


5. Slide offset

Connection Diagram		
		
Adjustment Point	Confirming Matter	Adjustment Procedure
Volume Control	(VTVM)	Rotate the volume control VR104 (SLIDE OFFSET) and adjust the value to 0V on the VTVM. (Disc in the stop mode.)
VR104	0V \pm 50 mV	

6. Tracking offset


Connection				
<div style="text-align: center;"> <p style="text-align: center;">2U-2007 P.W.B. Oscilloscope</p> </div>				
Oscilloscope (DC range)		Adjust	Check	Step
V	H	(Volume)	(Oscilloscope)	<ol style="list-style-type: none"> 1. Push ▲ OPEN/CLOSE and load disc holder reference disk. 2. Push ▲ OPEN/CLOSE and close disc holder. 3. Push ▶ PLAY to turn disc. (Displays track number 02) 4. Short (+) (-) of oscilloscope and check the base line. 5. Adjust VR201 [T-OFFSET] to equalizer upper and lower amplitude of the waveform.
0.1V/div	1~2 ms/div	VR201 [2U-1631 Servo Amp unit]	<p style="text-align: center;">A=B</p>	

7. Focus gain



Oscillator	Counter	Oscilloscope		Adjust (Volume)	Check (Oscilloscope)	Step
		V	H			
580 Hz 1 Vp-p (±0.1 V)	580 Hz	<ul style="list-style-type: none"> • DC range • X-Y mode 		VR102	<p style="text-align: center;">Y axis</p> <p style="text-align: center;">Phase 90°</p> <p style="text-align: center;">X axis</p> <p style="text-align: center;">Y axis</p> <p style="text-align: center;">Waveform not right</p> <p style="text-align: center;">X axis</p> <p style="text-align: center;">Y axis</p>	<ol style="list-style-type: none"> 1. Push II PAUSE (Displays track number 03) 2. Set oscillator to 580 Hz/1 Vp-p. 3. Switch oscilloscope input to X-Y mode. 4. Adjust VR102 [F-GAIN] to symmetrize Lissajous figures to X and Y axes.

8. Focus offset



Oscillator	Counter	Oscilloscope		Adjust	Check
580 Hz 1 Vp-p (±0.1 V)	580 Hz	V	H	(Volume)	(Oscilloscope)
		50 mV/div or 20 mV/div	0.2 μs/div or 0.5 μs/div	VR202	<p>Adjust to minimize pattern jitter.</p>
		<ul style="list-style-type: none"> Set input mode to ALTERNATE or CHOPPER. 		[2U-1631 Servo Amp unit]	

Step

1. Push **PAUSE**.
2. Set oscillator to 580 Hz, 1 Vp-p (±0.5 V).
3. VR202 [F-OFFSET] to minimize pattern jitter.

9. Tracking gain

Connection

• Caution: Connect oscillator after **|| PAUSE** pushed and servo function started.

Oscillator	Counter	Oscilloscope	Adjust	Check	Step		
<ul style="list-style-type: none"> • 1.8 HkHz • 3 V_{p-p} (±0.1V) 	1.8 kHz	<table border="1"> <tr> <td>V</td> <td>H</td> </tr> </table> <ul style="list-style-type: none"> • DC range • X-Y mode 	V	H	VR101 (Volume)	(Oscilloscope) 	<ol style="list-style-type: none"> 1. Push PAUSE. (Displays track number 03) 2. Connect oscillator. 3. Set oscillator to 1.8 kHz/3 V_{p-p}. 4. Switch oscilloscope input to X-Y mode. 5. Adjust VR104 [T-GAIN] to symmetrize Lissajous figures to X-Y axes.
V	H						

10. Tracking offset adjustment check

- (1) Adjust tracking offset again.
- (2) Push **■ STOP** and stop disc.
- (3) Push **▶ PLAY** and check disc turns.
Note: If disc does not turn, push **▶ PLAY** again and check track number **02** is displayed.
- (4) Check oscilloscope waveform upper and lower amplitude are same to base line.
- (5) Push **■ STOP** and stop disc.
- (6) Push **▲ OPEN/CLOSE** and remove the reference disc.

HEAT RUN MODE FUNCTION

Heat Run Mode

1) To activate

While hold pushing AUTO EDIT, A-B and ◀ keys simultaneously, turn the unit power on. The remote control sensor indicator will light to show that the unit is shifted in Heat Run mode.

Be sure to load the disc previously.

Press the disc holder open/close button (▲ OPEN/CLOSE) to cancel Heat Run mode.

- ★ This mode functions only for a disc with 21 pieces of music or more. For a disc with 20 pieces of music or lesser, please do not use.

2) Operation

During the Heat Run mode to shift the unit in Play mode makes the unit replays from the first music after opens the loader once and re-closes it when finish playing the last track (comes into lead out).

Hereafter, operates open/close of loader, servo on, reading of TOC, and playing repeatedly, and repeats playing the two tracks; the first and the last ones.

3) Error Message

When the system error occurs while in Heat Run mode, the following error message will display on the Track No. indicator and stops operation.

1. E1

At the time of Focus Servo does not activate.

2. E2

When unable to detect synchronous pattern however the disc is in rotating. (GFS does not drive.)

3. E3

No synchronous pattern can be detected while in Play mode. (No GFS drives.)

4. E4

When TOC is unreadable in despite of servo is activated.

5. E5

In case of loader malfunctions. (Unable to turn on the switch))

6. E6

The inner circle switch of Pick-up does not turn off.


7. E7

The inner circle switch of Pick-up does not turn on.

- ★ The number of operation up to the stop will be displayed on the minute and second portion of the indicator.

IC TERMINAL FUNCTION LIST

CXA10B1S




CXA1081S Terminal Function

Terminal No.	Terminal Symbol	I/O	DC voltage (V)	Terminal Function
1	RFI	I	0	Input terminal of capacitance coupled RF summing amplifier output.
2	RFO	O	VRFO	Terminal for RF summing amplifier output. Check point of Eye pattern.
3	RF(-)	I	0	Feedback input terminal of RF summing amplifier.
4	P/N	I	0 (VC)	P-sub/N-sub shifting terminal for Laser Diode (LD). (DC voltage: at N-sub.)
5	LD	O	-1.8	Output terminal of APC (Automatic Power Control) LD amplifier. (DC voltage: at N-sub, PD opened.)
6	PD	I	0	Input terminal of APC (Automatic Power Control) PD amplifier. (DC voltage: opened.)
7	PD1	I	0	Reverse input terminal of RF I-V amplifier (1). Receives a input current through A + C terminals of photo diode.
8	PD2	I	0	Reverse input terminal of RF IV amplifier (2). Receives a input current through B + D terminals of photo diode.
9	VC	-	0	At ± dual-power supply: Becomes GND. At mono-power supply: Becomes VR. (connect to pin 14.)
10	F	I	0	Reverse input terminal of F I-V amplifier. Receives a input current through F terminal of photo diode.
11	E	I	0	Reverse input terminal of E I-V amplifier. Receives a input current through E terminal of photo diode.
12	EO	O	0	Output terminal of E I-V amplifier.
13	EI	I	0	Feedback input terminal of E I-V amplifier. For gain controlling of E I-V amplifier.
14	VR	O	VC/2	Output terminal of DC voltages $(V_{CC} + V_{EE})/2$.
15	CC2	I	1.0	Input terminal of capacitance coupled defect bottom hold output.
16	CC1	O	1.2	Output terminal of defect bottom hold.
17	V _{EE}	-	-2.5	At ± dual-power supply: Becomes negative power supply terminal. At mono-power supply: Becomes GND.
18	FE BIAS	I	0	Bias terminal for non-reverse side of focus error amplifier. For CMR controlling of focus error amplifier.
19	FE	O	VFE0	Output terminal of focus error amplifier.
20	TE	O	VTE0	Output terminal of tracking error amplifier.
21	DEFECT	O	VDFCTL	Output terminal of defect comparator. (DC voltage: Connect a 10 kΩ load resistance.)
22	MIRR	O	VMIRL	Output terminal of MIRR comparator. (DC voltage: Connect a 10 kΩ load resistance.)
23	CP	I	-1.3	Connecting terminal for MIRR hold capacitor. Non-reverse input terminal of MIRR comparator.
24	CB	I	0	Connecting terminal for defect bottom hold capacitor.
25	D GND	-	-2.5	At ± dual-power supply: GND. At mono-power supply: GND (V _{EE}).
26	ASY	I	-	Input terminal of auto-asymmetry control.
27	EFM	O	VEFMH	Output terminal of EFM comparator. (DC voltage: Connect a 10 kΩ load resistance.)
28	FOK	O	VFOKL	Output terminal of focus OK comparator. (DC voltage: Connect a 10kΩ load resistance.)
29	LD ON	I	-2.5 (D GND)	ON/OFF shifting terminal for laser diode (LD). (DC voltage: At LD ON.)
30	V _{CC}	-	2.5	Positive power supply terminal.


CXA1082AS/1182S Terminal Function

Terminal No.	Terminal Symbol	Terminal Function
2	DFCT	Defect signal input terminal. Defect measure circuit activates at "H".
3	TE	Tracking error signal input terminal.
4	TZC	Tracking zero cross comparator input terminal.
5	ATSC	Input terminal of ATSC detecting window comparator.
6	FE	Focus error signal input terminal.
8	FGD	In case of reducing higher range gain of focus servo, connect a capacitor between this terminal and terminal number (9).
9	FS3	Shifts higher range gain of focus servo by FS3 ON/OFF.
10	FLB	Terminal for external time constant to increase lower range of focus servo.
11	FEO	Focus drive output.
12	FE(-)	Reverse input terminal for focus amplifier.
13	SRCH	Terminal for external time constant to make focus search waveform.
14	TGU	Terminal for external time constant to shift higher range gain of tracking.
15	TG2	Terminal for external time constant to shift higher range gain of tracking.
17	TAO	Tracking drive output.
18	TA(-)	Reverse input terminal for tracking amplifier.
19	SL(+)	Non-reverse input terminal of sled amplifier.
20	SLO	Sled drive output.
21	SL(-)	Reverse input terminal of sled amplifier.
22	SSTOP	Terminal for limit switch ON/OFF to detect disc inner most circle.
23	FSET	Terminal to compensate peak in focus tracking phase, and for setting F_0 in CLV LPF.
24	SENS	Terminal to output FZC, AS, TZC, SSTOP, BUSY by command from CPU.
26	C. OUT	Terminal to output signal for track number count.
27	DIRC	Terminal is used at the time of 1 track jump. A 47 k Ω pull up resistor is included.
28	XRST	Reset input terminal. Resets at "L".
29	DATA	Serial data input from CPU.
30	XLT	Latch input from CPU.
31	CLK	Serial data transfer clock input from CPU.
33	BW	Terminal for external time constant of loop filter.
34	PDI	Input terminal of PDO for CXD1125 phase comparator.
35	ISET	Delivers a current to set the height of focus search, track jump, and sled kick.
36	VCOF	Resistance value between this terminal and terminal (37) is nearly proportion to VCO free-run frequency.
38	C864	Output terminal of 8.64 MHz VCO.
39	LOCK	Reckless drive protection circuit activates at "L". A 47 k Ω pull up resistor is included.
40	MDP	Terminal to connect MDP terminal of CXD1125.
41	MON	Terminal to connect MON terminal of CXD1125.
42	FSW	Terminal for external LPF time constant of CLV servo error signal.
44	SPDL(-)	Reverse input terminal for spindle drive amplifier.
45	SPDLO	Spindle drive output.
46	WDCK	Clock input for auto-sequence. Normally applied 88.2 kHz.
47	FOK	FOK signal input terminal.
48	MIRR	MIRR signal input terminal.

CXA1082AS/1182S



CXD1125Q



CXD1125Q Terminal Function

Terminal No.	Terminal Symbol	I/O	Terminal Function
1	FSW	O	Output to shift time constant of output filter for spindle motor.
2	MON	O	ON/OFF control output for spindle motor.
3	MDP	O	Drive output for spindle motor. Rough control at CLV-S mode and phase control at CLV-P mode.
4	MDS	O	Drive output for spindle motor. Speed control at CLV-P mode.
5	EFM	I	Input of EFM signal from RF amplifier.
6	ASY	O	Output to control slice level of EFM signal.
7	LOCK	O	Sampling GFS signal by WFCK/16 and if it is "H", delivers "H"; if it is continuously "L" 8 times, delivers "L".
8	VCOO	O	VCO output. When EFM signal is locked, $f=8.6436$ MHz.
9	VCOI	I	VCO input.
10	TEST	I	(0V).
11	PDO	O	Phase comparing output for EFM signal and VCO/2.
12	V _{ss}	-	GND (0V).
13	CLK	I	Serial data transfer clock input from CPU. Latches data by rising edge of clock.
14	XLT	I	Input of Latch from CPU. Latches 8-bit shift register data (serial data from CPU) to each register.
15	DATA	I	Input of serial data from CPU.
16	XRST	I	System reset input. Resets at "L".
17	CNIN	I	Input of tracking pulse.
18	SENS	O	Answer to address, output internal condition.
19	MUTG	I	Input of muting. When internal register A's ATTM is in "L", and MUTG is in "L" for normal condition; "H" for no sound condition.
20	CRCF	O	Output of CRC check result of sub-code Q.
21	EXCK	I	Clock input for serial output of sub-code.
22	SBSO	O	Serial output of sub-code.
23	SUBQ	O	Q output of sub-code.
24	SCOR	O	Output of sub-code sync. S0 + S1.
25	SQCK	I/O	Reading clock of sub-code Q.
26	SQEX	I	Selection input of SQCK.
27	DOTX	O	Digital out output. (When CXD1130Q or DO is OFF, output WFCK.)
28	GFS	O	Output of indication for frame sync lock condition.
29	DB08	I/O	Data terminal of external RAM. DATA8 (MSB).
30	DB07	I/O	Data terminal of external RAM. DATA7.
31	DB06	I/O	Data terminal of external RAM. DATA6.
32	DB05	I/O	Data terminal of external RAM. DATA5.
33	V _{DD}	-	Power supply (+5V).
34	DB04	I/O	Data terminal of external RAM. DATA4.
35	DB03	I/O	Data terminal of external RAM. DATA3.
36	DB02	I/O	Data terminal of external RAM. DATA2.
37	DB01	I/O	Data terminal of external RAM. DATA1 (LSB).
38	RA01	O	Address output of external RAM. ADDR01 (LSB).
39	RA02	O	Address output of external RAM. ADDR02.
40	RA03	O	Address output of external RAM. ADDR03.
41	RA04	O	Address output of external RAM. ADDR04.
42	RA05	O	Address output of external RAM. ADDR05.
43	RA06	O	Address output of external RAM. ADDR06.
44	RA07	O	Address output of external RAM. ADDR07.
45	RA08	O	Address output of external RAM. ADDR08.

Terminal No.	Terminal Symbol	I/O	Terminal Function
46	RA09	O	Address output of external RAM. ADDR09.
47	RA10	O	Address output of external RAM. ADDR10.
48	RA11	O	Address output of external RAM. ADDR11.
49	RAWE	O	Write enable signal output for external RAM. (Active at "L".)
50	RACS	O	Chip select signal output for external RAM. (Active at "L".)
51	C4M	O	Dividing output of X'tal. f = 4.2336 MHz.
52	V _{SS}	-	GND (0V).
53	XTAI	I	X'tal oscillation circuit input. By selecting of mode, f = 8.4672 MHz or 16.9344 MHz.
54	XTAO	O	X'tal oscillation circuit output. By selecting of mode, f = 8.4672 MHz or 16.9344 MHz.
55	MD1	I	Mode selection input 1.
56	MD2	I	Mode selection input 2.
57	MD3	I	Mode selection input 3.
58	SLOB	I	Code switching input for audio data output. At "L" for 2's compliment output; at "H" for offset binary output.
59	PSSL	I	Mode switching input for audio data output. At "L" for serial output; at "H" for parallel output.
60	APTR	O	Control output for aperture compensation. In "H" for R-ch.
61	APTL	O	Control output for aperture compensation. In "H" for L-ch.
62	DA01	O	At PSSL = "H" for DA01 (LSB of parallel voice data) output. At PSSL = "L" for C1F1 output.
63	DA02	O	At PSSL = "H" for DA02 output; PSSL = "L" for C1F2 output.
64	DA03	O	At PSSL = "H" for DA03 output; PSSL = "L" for C2F1 output.
65	DA04	O	At PSSL = "H" for DA04 output; PSSL = "L" for C2F2 output.
66	DA05	O	At PSSL = "H" for DA05 output; PSSL = "L" for C2FL output.
67	DA06	O	At PSSL = "H" for DA06 output; PSSL = "L" for C2PO output.
68	DA07	O	At PSSL = "H" for DA07 output; PSSL = "L" for RFCK output.
69	DA08	O	At PSSL = "H" for DA08 output; PSSL = "L" for WFCK output.
70	DA09	O	At PSSL = "H" for DA09 output; PSSL = "L" for PLCK output.
71	DA10	O	At PSSL = "H" for DA10 output; PSSL = "L" for UGFS output.
72	DA11	O	At PSSL = "H" for DA11 output; PSSL = "L" for GTOP output.
73	V _{DD}	-	Power supply (+5V).
74	DA12	O	At PSSL = "H" for DA12 output; PSSL = "L" for RAOV output.
75	DA13	O	At PSSL = "H" for DA13 output; PSSL = "L" for C4LR output.
76	DA14	O	At PSSL = "H" for DA14 output; PSSL = "L" for C21O output.
77	DA15	O	At PSSL = "H" for DA15 output; PSSL = "L" for C21O output.
78	DA16	O	At PSSL = "H" for DA16 (MSB of parallel voice data) output. At PSSL = "L" for DATA output.
79	WDCK	O	Strobe signal output. At DF ON, 176.4 kHz. At CXD1125Q or DF OFF, 88.2 kHz.
80	LRCK	O	Strobe signal output. At DF ON, 88.2 kHz. At CXD1125Q or DF OFF, 44.1 kHz.

Note:

C1F1: Monitor output for error correction state what C1 is at decode.
 C2F1: Monitor output for error correction state what C2 is at decode.
 C2FL: Correction state output. Becomes "H" when C2 system in which presently under correction is unable to correct.
 C2PO: C2 pointer indication output. Synchronizes with audio data output.
 RFCK: Read frame clock output. 7.35 kHz of X'tal system.
 WFCK: Write frame clock output. 7.35 kHz when locked on to X'tal system.
 PLCK: VCO/2 output. When locked to EFM signal, f = 4.3218 MHz.

UGFS: Output of unprotected frame sync pattern.
 GTOP: Indication output of frame synchrony in protected condition.
 RAOV: Overflow and underflow indication outputs of ± 4 frame jitter absorbing RAM.
 C4LR: Strobe signal. At DF ON, 352.8 kHz. At CXD1125Q or DF OFF, 176.4 kHz.
 C21O: Reverse output of C210.
 C21O: Bit clock output. At DF ON, 4.2336 MHz. At CXD1125Q or DF OFF, 2.1168 MHz.
 DATA: Serial data output of audio signal.

PARTS LIST OF P.W.BOARD

2U-2007 SERVO/SIG. UNIT

Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTOR GROUP			
IC001	26207360088	CXD1125	
IC002	26208540022	HM6116P/LP-4/3/2	
IC098	26205910007	HD74HC00P	
IC099,100	26211265002	TC74HCU04P	
IC101	26211008007	CXA1182S	
IC103	2630244 001	NJM082D	
IC104	26302570001	M5218P	
IC106	26207290022	HD74HC08P	
IC301	262112550099	M50957-211SP	
IC302	26304230000	M51953B	
IC303	26206820065	BA6208A	
IC398,399	26800720003	ICP-N10	
IC401	26304329007	NJM78L05AT	
IC402	26305670065	NJM78M05FA	
IC403	26305580066	NJM7805FA	
IC404	26305540065	NJM7905FA	
IC405-407	26800749904	ICP-N20	
TR001,002 201	26900269900	RN2202 (10k-10k)T	
TR101,103 107	274011230099	2SD1985 (P/Q)	
TR102,104 108	27200850002	2SB941A (Q)/(P)	
TR105	27400860022	2SD468 (C)	
TR106,401	27200250004	2SB582 (C)	
TR109,110	273011780099	2SC1740 (S)	
TR112,202	26900259901	RN1202 (10k-10k)T	
TR113	27101019925	2SA933 (Q)T-70	
D201,406	276041179902	1SS270	
D301-306 370,371	27604320000	1SS270A	
D401	27604059901	S1WB (A) 10	
D402,403	27604339902	DSM1A2 TYPE 2	
D404	27603030003	HZ6C-2	
D405	27602240014	HZ30-2	
RESISTOR GROUP			
R107	24420519945	RS14B3A010JST(S)	1ohm, 1W
VR101,102	211 6064051	V06PB203	20kohm B
VR103	211 6064064	V06PB102	1kohm B
VR104	211 6064019	V06PB473	47kohm B
CAPACITOR GROUP			
(Ceramic)			
C102,131 135,143 304,320 321	25311146907	CK45F1H103Z	0.01µF/50V
C104,105 154-156 303 510-512	253 9028 904	CK45=1E104M	0.1µF/25V
C110	253 4412 900	CC45SL1H100D	10pF/50V
C123	253 4454 900	CC45SL1H561J	560pF/50V
C141	253 1112 902	CK45B1H102K	0.001µF/50V

Ref. No.	Part No.	Part Name	Remarks
C148,149 151	25336270000	CC45SL1H101J	100pF/50V
C157	25336330007	CC45SL1H181J	180pF/50V
(Electrolytic)			
C002	25442549999	CE04W1C100M	10µF/16V
C101	254 4289 738	CE04W1H101MC(AWF)	100µF/50V
C103,115 116,132	254 4260 948	CE04W1H010M	1µF/50V
C113,114	254 4260 951	CE04W1H2R2M	2.2µF/50V
C117,118 140	254 4254 912	CE04W1C220M	22µF/16V
C127	254 4260 980	CE04W1H100M	10µF/50V
C130,134 305-307	254 4252 930	CE04W1A101M	100µF/10V
C146,147	254 4254 925	CE04W1C330M	33µF/16V
C153	254 4288 001	CE04W1E101MC(AWF)	100µF/25V
402-404			
C201	254 4254 954	CE04W1C221M	220µF/16V
C301	254 4260 919	CE04W1HR22M	0.22µF/50V
C302	259 0005 005	EESCS5R5V104	0.1µF/5.5V
C310	254 4254 967	CE04W1C331M	330µF/16V
C370	254 4260 977	CE04W1H4R7M	4.7µF/50V
C371	254 3056 917	CE04D1H010MBP	1µF/50V
C401	254 4254 941	CE04W1C101M	100µF/16V
C407	254 4261 921	CE04W1H101M	100µF/50V
C409	254 4262 946	CE04W1J470M	47µF/63V
C410,411	254 4261 905	CE04W1H330M	33µF/50V
C504-509	254 4314 771	CE04W1E102MC(AVF)	1000µF/25V
(Film)			
C109	255 1209 905	CQ93M1H562J	0.0056µF/50V
C111	255 1214 903	CQ93M1H153J	0.015µF/50V
C119,120	255 1206 908	CQ93M1H332J	0.0033µF/50V
C121,129 137	255 1212 905	CQ93M1H103J	0.01µF/50V
C122	255 1204 900	CQ93M1H222J	0.0022µF/50V
C133	255 1208 906	CQ93M1H472J	0.0047µF/50V
C138	255 1200 904	CQ93M1H102J	0.001µF/50V
(Metalized)			
C112	256 1034 940	CF93A1H563J	0.053µF/50V
C124,136	256 1034 979	CF93A1H104J	0.1µF/50V
C125	256 1034 911	CF93A1H333J	0.033µF/50V
C128	256 1035 910	CF93A1H224J	0.22µF/50V
OTHER PARTS			
PT151,152	231 8060 002	PULSE TRANS	
CB101	205 0190 065	6P NH CONN. BASE	
CB102	205 0298 006	23P FFC BASE (S)	
CB103,313	205 0343 061	6P CONN. BASE (KR-PH)	

2U-1631 SERVO AMP UNIT

Ref. No.	Part No.	Part Name	Remarks
CB104,311	20503230036	3P CONN. BASE (BLK)	
CB105	20503210038	3P CONN. BASE (RED)	
CB106	20503430032	3P CONN. BASE (KR-PH)	
CB301	20503750033	11P CONN. BASE (KR-PH)	
CB302	20503750000	10P CONN. BASE (KR-PH)	
CB303	20503430068	5P CONN. BASE (KR-PH)	
CB304	20503230049	4P CONN. BASE (BLK)	
CB309	20503230052	5P CONN. BASE (BLK)	
CB701	20503430074	7P CONN. BASE (KR-PH)	
*	41702530000	RADIATOR	IC402-404
*	20488510007	2P RCA PIN JACK (EMI)	
*	26900680007	TOTX174	
*	20304240023	1P CONTACT ASSY	

Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTOR GROUP			
IC201	26208420002	CXA-1081S	
TR201	27200250044	2SB562 (C)	
TR202	273001780099	2SC1740 (S)	
RESISTOR GROUP			
R202	24520330068	RN14K2E360GT	36ohm,1/4W
R203	24520330093	RN14K2E560GT	56ohm,1/4W
VR201	21160570026	V08PB203	20kohm B
VR202	21160570013	V08PB103	10kohm B
CAPACITOR GROUP			
C201	25442600061	CE04W1H3R3M (SME)	3.3μF 50V
C202	25442540048	CE04W1C101M (SME)	100μF 16V
C203	25336170007	CC45SL1H390J	39pF 50V
C204	25511200055	CQ93M1H272J	0.0027μF 50V
C205	25310240003	CK45F1H103Z	0.01μF 50V
C206	25442520037	CE04W1A101M (SME)	100μF 10V
C207	25442600032	CE04W1HR47M (SME)	0.47μF 50V
C208,209	25511210025	CQ93M1H103J	0.01μF 50V
C210,211	25610340018	CF93A1H333J	0.033μF 50V
OTHER PARTS			
	20502980051	20P FFC CONN. BASE (S)	
	20502980006	23P FFC BASE (S)	

2U-1688 DISPLAY UNIT

Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTOR GROUP			
D307-312	27600490011	1S2076A	
OTHER PARTS			
	21243880004	TACT SWITCH	
	49900880002	QH3031H0	
	39340650008	FIP11BHM7	
CC301	20462000008	11P KR-DA CONN. CORD	
CC302	20422970002	10P KR-DA CONN. CORD	
CC303	20382280001	5P KR-DA CONN. CORD	
CC304	20503230049	4P CONN. BASE (BLK)	

2U-2008 AUDIO UNIT

Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTOR GROUP			
IC102	262 1063 000	SM5803AP	
IC501,601	262 1180 006	CF37606	
IC502,503 602,603	262 0904 005	HD74HC164P	
IC504,505 518,604 605,618	262 0594 004	HD74HC74P	
IC506,507 606,607	262 1253 001	PCM58KP	
IC508,510 608,610	263 0710 001	TC74HC4066AP	
IC509,511 609,611	262 0864 006	μPC4570C	
IC512,514 612,614	263 0127 005	NE5534AN	
IC513,515 613,615	263 0360 008	NE5532	
IC517,617	262 1265 002	TC74HCU04AP	
IC519,520 619,620	263 0432 907	NJM78L05AT	
IC702	263 0198 005	NJM4556D	
IC710	263 0554 005	NJM7905FA	
IC711	263 0553 006	NJM7805FA	
TR504-508 604-608	273 0253 918	2SC2878 (A/B)	
TR701	271 0101 925	2SA933 (Q)T-70	

RESISTOR GROUP			
R521,522 525,526 529,530 533,534 570,571 574,575 620,621 624,625 628,629 632,633 670,671 674,675	254 2375 912	RN14K2E102GT(5)	1kohm, 1/4W (Metal Film)
R537,538 562,636 637,661	241 0209 004	RD14B2H1103U	10kohm, 1/2W
R539,540 638,639	241 0200 003	RD14B2H1132U	4.3kohm, 1/2W
R541,542 640,641	241 0193 000	RD14B2H1222U	2.2kohm, 1/2W
R543,642	241 0205 008	RD14B2H1632U	6.8kohm, 1/2W
R544,643	241 0198 005	RD14B2H1362U	3.6kohm, 1/2W
R545,644	241 0195 008	RD14B2H1272U	2.7kohm, 1/2W
R546,547 645,646	241 0201 002	RD14B2H1472U	4.7kohm, 1/2W
R548,647	241 0188 002	RD14B2H1132U	1.3kohm, 1/2W

Ref. No.	Part No.	Part Name	Remarks
R554,555 558,559 653,654 657,658 R563,568 662,663	241 0172 005	RD14B2H301J	300ohm, 1/2W
VR501,502 505,506 601,602 605,606	241 0185 009	RD14B2H1151U	150ohm, 1/2W
VR151	211 6075 008	V06PB104(CERMET)	100kohm B
	211 0540 005	V1620V25FA103M	10kohm A

CAPACITOR GROUP

(Ceramic)			
C500 C501,504 567,601 603,604 667,713 800,801 C502,602 C505,605 C574,674	253 1112 902 253 1118 901	CK45B1H102KT CK93E1H104WT(TCO)	0.001μF/50V 0.1μF/50V
	253 4423 902	CC45SL1H300JT	30pF/50V
	253 4535 955	CC45SL1H050CT(DD-3)	5pF/50V
	253 4428 907	CC45SL1H470JT	47pF/50V

(Electrolytic)			
C507,514 515,517 518,607 614,615 C505 509-512 516-518 605 609-612 616-618 C519,522 524,527 538,539 544,547 619,622 624,627 638,639 644,647 C750,850 ★	254 4289 738 254 4356 001	CE04W1H101MC(AWF) CE04W1H100(ARS)	100μF/50V 10μF/50V
	254 4289 068	CE04W1H471M(AWF)	470μF/50V
	254 4256 907	CE04W1E100M	10μF/25V
	254 4256 088	CE04W1E102M	1000μF/25V

(Film)			
C520,525 620,625	255 4235 727	CQ93P2A271JC(NH)	270pF/100V
C521,526 621,626	255 4235 714	CQ93P2A101JTC(NH)	100pF/100V
C529,629	255 4232 018	CQ93P2A181JC(NH)	180pF/100V

2U-1632 POWER SUPPLY UNIT

Ref. No.	Part No.	Part Name	Remarks
C530,630	255 4232 005	CQ93P2A821JC(NH)	0.0082μF/100V
C533,535	255 4235 060	CQ93P2A272JC(NH)	0.0027μF/100V
536,633			
635,636			
C542,642	255 6167 000	CQ09S2B103K(B)	0.1μF/125V
C543,546	255 4232 021	CQ93P2A390JC(NH)	39pF/100V
643,646			
C545,548	255 4232 937	CQ93P2A102JT(NH)	0.001μF/100V
645,648			
OTHER PARTS			
X500	399 0036 013	X'TAL (16,9344MHz)	
RE501(601)	214 0097 007	RELAY	
CB302	205 0323 052	5P CONN. BASE (BLK)	
CB311	205 0343 032	3P CONN. BASE (KR-PH)	
703,707			
CB700,702	205 0343 061	6P CONN. BASE (KR-PH)	
706,709			
CB701	205 0343 074	7P CONN. BASE (KR-PH)	
CB705	205 0343 049	4P NH CONN. BASE	
CB708	205 0343 045	4P CONN. BASE (KR-PH)	
*	204 8265 099	4P RCA PIN JACK	
*	204 8264 000	H/P JACK (AU)	
*	205 0428 099	3P CANNON CONN.	
*	212 4691 065	ROTARY SWITCH	
*	212 4708 003	SLIDE SWITCH	
*	001 0006 007	BUS BAR	
*	203 0294 017	1P BOARD IN WIRE	
*	203 0424 007	1P CONTACT ASS	
*	203 0424 000	1P CONTACT ASS	

Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTOR GROUP			
IC811	276 0405 008	SIWB (A) 10	
IC812,813	263 0361 001	NJM7915FA	
IC814	268 0360 002	NJM7815FA	
CAPACITOR GROUP			
△ C801-803	253 8014 003	CK45F2GA103M	0.01μF 400V
C810,814	254 4289 068	CE04W1H101MC (AWF)	100μF 50V
815			
C811,812	254 6138 007	CE64W1H472M	4700μF 50V
OTHER PARTS GROUP			
△ CH801	239 8019 002	LINE FILTER COIL	
	415 0299 000	CONDENSER COVER	
△ F801	206 1015 045	FUSE (315MA)	Europe, U.K. Australia U.S.A., Canada
△ F801	206 1039 018	FUSE (800MA)	
△ *	202 0022 008	FUSE HOLDER	
*	513 1451 002	FUSE LABEL (315MA)	Europe, U.K. Australia U.S.A., Canada
*	513 0637 092	FUSE LABEL (800MA)	
*	417 0253 000	RADIATOR	IC813, 814
△ SW801	212 0286 003	POWER SWITCH	
△ SW801, 802	205 0217 032	3P CONN. BASE (ULTR)	
CB811	205 0190 065	6P NH CONN. BASE	
CB812	205 0190 049	4P NH CONN. BASE	
*	205 0190 036	3P NH CONN. BASE	

2U-1644 MOTOR DRIVE UNIT

Ref. No.	Part No.	Part Name	Remarks
SEMICONDUCTOR GROUP			
IC1	263 0424 002	M5218FP (TAPE)	
TR1,4	272 0081 999	2SB766S (TAPE)	
TR2,5	274 0114 998	2SD874R (TAPE)	
T3,6	279 0024 999	FMY1-T99	
H1,2	268 0360 022	HW-101C (Q,R)	
RESISTOR GROUP			
VR1	211 8003 913	K05=B202	
R1,8	247 1006 961	RM73B2B471JT	470ohm
R2	247 0006 904	RM73B--271JT	270ohm
R3	247 0009 985	RM73B--103JT	10kohm
R4,11	247 1012 926	RM73B2B104JT	100kohm
R5,12	247 0012 927	RM73B--104JT	100kohm
R6,7,13,14	247 1008 985	RM73B392JT	3.9kohm
R9	247 1006 903	RM73B2B271JT	270ohm
R10	247 1009 984	RM73B2B103JT	10kohm
R15	247 1007 902	RM73B2B681JT	680ohm
CAPACITOR GROUP			
C1	257 0006 927	CC73SL1H471JT	470pF 50V
C3	257 1006 926	CC73SL1H471JT	470pF 50V
C5,7	257 0014 935	CK73F1E104ZT	0.1μF 25V
OTHER PARTS			
	346 0070 004	ROTOR COIL	

NOTE FOR PARTS LIST

- Part indicated with the mark "⊙" are not always in stock and possibly to take a long period of time for supplying, or in some case supplying of part may be refused.
 - When ordering of part, clearly indicate "1" and "I" (i) to avoid mis-supplying.
 - Ordering part without stating its part number can not be supplied.
 - Part indicated with the mark "*" is not illustrated in the exploded view.
 - Not including Carbon Film ±5%, 1/4W Type in the P.W.Board parts list. (Refer to the Schematic Diagram for those parts.)
- WARNING:**
Parts marked with this symbol △ have critical characteristics.
Use ONLY replacement parts recommended by the manufacturer.

Resistors

Ex.: RN 14K 2E 182 G FR
Type Shape and performance Power Resistance Allowable error Others

RD : Carbon	2B : 1/4W	F : ±1%	P : Pulse-resistant type
RC : Fixed	2E : 1/2W	G : ±2%	NL : Low noise type
RS : Metallic film	2H : 3/4W	J : ±5%	NB : Non-burning type
RW : Winding	3A : 1W	K : ±10%	FR : Fuse resistor
RN : Metal film	3D : 2W	M : ±20%	F : Lead wire forming
RK : Metal mixture	3F : 3W		
	3H : 5W		

Resistance
1 8 2 → 1800Ω = 1.8kΩ
Indicates number of zeros after effective number
2-digit effective number, decimal point indicated by R.
Units: Ω

Capacitors

Ex.: CE 04W 1H 2R2 M BP
Type Shape and performance Dielectric strength Capacity Allowable error Others


CE : Aluminum foil electrolyte	0J : 6.3V	F : ±1%	HS : High stability type
CA : Aluminum solid electrolyte	1A : 10V	G : ±2%	BP : Non-polar type
CS : Tantalum electrolyte	1C : 16V	J : ±5%	HR : Ripple-resistant type
CO : Film	1E : 25V	K : ±10%	DL : For charge and discharge
CK : Ceramic	1V : 35V	M : ±20%	HF : For assuring high frequency
CC : Ceramic	1H : 50V	Z : +80%	U : UL part
CP : Oil	2A : 100V	-20%	C : CSA part
CM : Mica	2B : 125V	P : +100%	W : UL-CSA type
CF : Metallized	2C : 160V	-0%	F : Lead wire forming
CH : Metallized	2D : 200V	C : ±0.25pF	
	2E : 250V	D : ±0.5pF	
	2H : 500V	= : Others	
	2J : 630V		

Capacity
2 R 2 → 2.2μF
1-digit effective number, decimal point indicated by R.
2-digit effective number, decimal point indicated by R.

- Units: μF, (for P, pF (μμF))
- When the dielectric strength is indicated in AC, "AC" is included after the dielectric strength value.

EXPLODED VIEW


1 2 3 4 5 6 7 8




WARNING:
 Parts marked with this symbol  have critical characteristics.
 Use ONLY replacement parts recommended by the manufacturer.


EXPLODED VIEW OF FG-621 MECHANISM UNIT

PARTS LIST OF FG-621 MECHA UNIT




Ref. No.	Part No.	Part Name	Remarks	Ref. No.	Part No.	Part Name	Remarks
1	3150338022	P.U. HOUSING		62	4737508017	3x10 CBTS (P)-B	
2	4610409000	P.U. STOPPER		63	4737002005	3x6 CBTS(S)-Z	
3	PMO1A15	MAGNET SUB ASS'Y		64	4751105004	4W	
4	PMO1A20	MAGNET SUB ASS'Y		65	4122296002	COVER	
5	PMO1A21	MAGNET SUB ASS'Y (C)		66	3460067386	MOTOR HOUSING ASS'Y	
6	4990078009	PICK-UP KSS151A		67	PRO1A93	ROTOR ASS'Y	
7	2390014209	M. COIL ASS'Y		68	4310271004	THRUST METAL	
8	2390015208	G. COIL ASS'Y		69	2U-1644	MOTOR DRIVE UNIT	
9	4330480008	YOKE (B)		70	4713302017	3x5 CBS	
10	4430617302	P.W. SHAFT		71	—	—	
11	42104313800	STOPPER COLLAR		72	4410857001	P. RING	
12	3150451003	FRICTION WASHER		73	4610269114	DAMP SHEET	
14	4210423224	TURNTABLE ASS'Y		74	2124650004	LEAF SW	
15	4620083005	H. DAMPER		75	2U-1631	SERVO AMP UNIT	
16	4330513108	COLLAR (D)		76	20901117008	23P FFC	
17	4330514107	COLLAR (C)		77	—	—	
18	4630514001	COIL SPRING (C)		78	4410993004	YOKE HOLDER	
19	4630515000	COIL SPRING (D)		79	4770298038	CUT WASHER	
21	4110715304	BASE PLATE GEN. ASS'Y					
22	PLO1A34	LOADING M.SUB ASS'Y					
23	4210439108	GEAR PULLEY ASS'Y					
24	4620084020	TUBE (φ5.5)					
25	4210425002	MOTOR PULLEY					
26	4250170003	SLIDER ROLLER					
27	4230046209	BELT (A)					
28	4310267416	LOADER FRAME					
29	4122177105	LOADER BRACKET					
30	4110831000	LOADER GUIDE					
31	1220110083	HIMERON SHEET					
32	4310284114	DISC TRAY ASS'Y					
33	4630574009	D. TRAY SPRING					
34	4430874006	LOADER RAIL					
35	4620084004	TUBE (φ5)					
36	4610449002	LOADER CUSHION					
37	4122512003	BRACKET					
38	4630505104	CLAMPER SPRING					
39	4330477406	CLAMPER ARM					
40	PCO1A27	CLAMP PRESS SUB ASS'Y					
41	2124650004	LEAF SW.					
42	4230047004	BELT (B)					
43	1220110096	HIMERON SHEET					
44	2030240032	1P CONTACT CORD					
45	4111007008	LOADER STOPPER					
46	1250042008	GUIDE SPACER					
47	1250039008	STOPPER SPACER					
48	1220168014	SPACER (M)					
49	1220168001	SPACER (M)					
50	4122589007	LOADER SPACER					
51	4738010009	M1.7x4#(M)ZNB					
52	4738014005	3x8 CBTS (H-L) ZNB					
53	4751114008	3 WASHER					
54	4770086007	PUSH RIVET					
55	4751108006	3 WASHER					
56	4751105017	4WBKNI					
57	4410856002	GFRING					
58	4713812002	2x8 CBS B					
59	4744380004	2.6x4 BSS (A)					
60	47118807022	3x18 CPS BK					
61	47443800033	2.6x6 BSS (A)					







2U-1688 DISPLAY UNIT




2U-1632 POWER SUPPLY UNIT




2U-1631 SERVO AMP UNIT



2U-1644 MOTOR DRIVE UNIT




WIRING DIAGRAM



SEMICONDUCTORS


• IC's





NJM7805A
NJM7815A
NJM78M05A

NJM7905A
NJM7915A


NJM78L05A




M51953B





NJM082D
NJM4556D
NE5532
M5218P
μPC4570C




NE5534




BA6208A




HD74HCU04P




HD74HC08P




TC74HC02P




TC74HC4066





HD74HC74P





HD74HC164P





HM6116P-4




CF37606





CXA1182AS




CXA1081S




PCM58KP






SM5803AP-1




M50957




CXD1125

• IC PROTECTORS



ICP-N10
ICP-N20

• TRANSISTORS



2SB941A(P/Q)
2SD1985(P/Q)





2SA933(Q)
2SC1740(R/S)
2SD1504(E/F)



2SB562(C)
2SD468(C)



RN1202(10K-10K)NPN
RN2202(10K-10K)PNP
RN1210(4.7K-)NPN





2SB766
2SD874

• DIODES




1S2076A
1SS270A
DSM1A2


HZ5C-1
HZ6C-1
HZ30-2



S1WB(A)10



DENON



NIPPON COLUMBIA CO., LTD.

14-14, 4-CHOME AKASAKA,
MINATO-KU, TOKYO 107 JAPAN
TEL: 03-584-8111
TLX: JAPANOLA J22591
CABLE: NIPPONCOLUMBIA TOKYO