




## CSMA 5 - SMA Right Angle Connectors, Direct Solder Type for Semi-Rigid Cable




### STEP 1



### STEP 2



### STEP 3



1. Remove cable outer conductor and dielectric to the dimension shown, being careful not to fracture the center conductor. Tin center conductor (DO NOT OVER TIN).
2. Slide cable into body and solder into place.
3. Solder center conductor to contact (do not over solder), then locate the cap in rear of body and press flush to outer body to ensure it is locked in position.

www.DataSheet4U.com