

# AN34044A-VF

|    |             |               |    |
|----|-------------|---------------|----|
| 1  | DTV15V      | SD_VCC        | 32 |
| 2  | SUB9V       | SUB5V         | 31 |
| 3  | MON_DTV15V  | STB5V         | 30 |
| 4  | DCDC_CTL    | STB3.3V       | 29 |
| 5  | DTV_RST     | STB1.2V       | 28 |
| 6  | SD_UHS      | STBRST        | 27 |
| 7  | SOS_PPIO5   | CD            | 26 |
| 8  | SOS_PPIO4   | MUTE_VCC      | 25 |
| 9  | SOS_PPIO3   | MONITOR_MUTE  | 24 |
| 10 | SOS_PPIO2   | AUDIO_MUTE_IN | 23 |
| 11 | SOS_PPIO1   | A_MUTE        | 22 |
| 12 | PANEL_SOS   | SP_MUTE       | 21 |
| 13 | DRVRST_OUT  | BUFF_EN       | 20 |
| 14 | DRVRST_IN   | GND           | 19 |
| 15 | POWER_DET   | BUFF_3.3V_OUT | 18 |
| 16 | STB5V_SW_ON | BUFF_5V_IN    | 17 |