


EDS801



PIN#	1	2	3	4	5	6	7	8	9
SYM.	COM	←	1BC	↖	↘	↖	↘	1DP	2E
PIN#	10	11	12	13	14	15	16	17	18
SYM.	2D	2C	2DP	3E	3D	3C	3DP	4E	4D
PIN#	19	20	21	22	23	24	25	26	27
SYM.	4C	4B	4A	4F	4G	3B	3A	3F	3G
PIN#	28	29	30	31	32	33	34	35	36
SYM.	COL	2B	2A	2F	2G	↖	↘	↖	↘
PIN#	37	38	39	40					
SYM.	↖	←	↘	COM					

EDS801

SCALE: 0.9:1

: 40