

LCD		英德斯Board		斯泰基Board
Pin NO	Function	Pin-NO	Function	Pin NO
1	DL4	16	P7	17
2	VSS	3	GND	4
3	DL5	15	P6	16
4	YD	36	FLM	7
5	DL6	14	P5	15
6	LP	38	LP	6
7	DL7	13	P4	14
8	VSS	4	GND	4
9	VSS	4	GND	9
10	XCK	35	SHFCLK	8
11	DL0	24	P15	26
12	VCON		VCON	接可调
13	DL1	23	P14	25
14	VCC	5	VCC	1
15	VSS	8	GND	接可调
16	VCC	6	VCC	接可调
17	DL2	22	P13	24
18	DISP	7	ENVEE	2
19	DL3	21	P12	23
20	NC		NC	
21	VSS	39	VSS	18
22	DU3	17	P8	19
23	DU4	12	P3	13
24	DU2	18	P9	20
25	DU5	11	P2	12
26	DU1	19	P10	18
27	VSS	39	GND	19
28	DU0	20	P1	22
29	DU6	10	GND	11
30	VSS	39	GND	18
31	DU7	9	P0	10

Part NO: _____

Sanyo LM-CD53-22NTK

液晶之友 电话: 020-33819057
[Http://www.lcdfriends.com](http://www.lcdfriends.com)

接电位器控制端

接电位器两端