

Small-sized Pressure Sensor

Package: 1 pc. in a bag

Sensor Heads

- Small-sized 24.5-mm pressure sensors (width: 10mm × height, 10mm × total length).
- "Union," "Nipple," and "Male screw" are prepared.
- Use of an analog output type and indicator (SED30-series) has made a separate display system possible.
- Our small-sized pressure sensors can handle "positive pressure," "negative pressure" and "Compound pressure". Concerning output, a total of six different specifications are prepared.
- Standard cable length is 3m.

Indicators

- A large 31.4mm square size indicator is used, realizing a high level of visibility with its large-sized LED display.
- All settings can be made using just three push buttons.
- For indication units, you can choose from among 11 different types.
- Two different kinds of output methods are offered - analog output and switch output.
- Four (4) different kinds of installation stays are available depending on installation form. - for installation in the rear, on a flat surface, panel-buried, and for protection of display components.

Specifications

■ Sensor Heads (Switch type)

Specification	SEU 11 series	VUS 11 series	VUS 11-R series
Fluid admitted	Air, inert gas		
Pressure detection	Proliferated semiconductor pressure switch		
Power requirements	DC10.8 ~ 30V (ripples included)		
Power consumption	20mA or less (DC24V at no-load)		
Service pressure range	0 ~ 150psi (0 ~ 1MPa)	0 ~ 30in. Hg (-100 ~ 0kPa)	89 ~ 30in. Hg (-100 ~ 300kPa)
Proof pressure	218psi (1.5MPa)	29psi (200kPa)	87psi (600kPa)
Storage temperature range	-4 ~ 158°F (-20 ~ 70°C) (Atmospheric pressure, humidity less than 60%RH)		
Operating temperature range	32 ~ 140°F (0 ~ 60°C) (No freezing)		
Operating humidity range	35 ~ 85%RH (No freezing)		
Protective structure	IEC standard IP40 equiv.		
Switch output	No. of pressure setting	1	
	Switch output	NPN Open collector output: 30V 80mA max. Residual voltage 0.8V max.	
	Display of action	N.O. (red LED lights up when set pressure exceeded)	
	Differential response	Fixed (2%F.S. max.)	
	Operating accuracy	±3%F.S. max. (at Ta=25°C/77°F)	
	Response	Approx. 1msec	
Pressure setting range	0 ~ 150psi (0 ~ 1MPa)	0 ~ 30in. Hg (-100 ~ 0kPa)	89 ~ 30in. Hg (-100 ~ 300kPa)

■ Sensor Heads (Analog type)

Specification	SEU 11 series	VUS 11 series	VUS 11-R series
Fluid admitted	Air, inert gas		
Pressure detection	Proliferated semiconductor pressure switch		
Power requirements	DC10.8 ~ 30V (ripples included)		
Power consumption	20mA or less (DC24V at no-load)		
Service pressure range	0 ~ 150psi (0 ~ 1MPa)	0 ~ 30in. Hg (-100 ~ 0kPa)	89 ~ 30in. Hg (-100 ~ 300kPa)
Proof pressure	218psi (1.5MPa)	29psi (200kPa)	87psi (600kPa)
Storage temperature range	-4 ~ 158°F (-20 ~ 70°C) (Atmospheric pressure, humidity less than 60%RH)		
Operating temperature range	32 ~ 140°F (0 ~ 60°C) (No freezing)		
Operating humidity range	35 ~ 85%RH (No freezing)		
Protective structure	IEC standard IP40 equiv.		
Analog output	Output voltage	1 ~ 5V	
	Zero-point voltage	1 ±0.1V	
	Max. rated pressure voltage	5 ±0.1V	
	Output current	1mA max. (Load Resistance 5kΩ min.)	
	Linearity	±0.5%F.S. max.	

Small-sized Pressure Sensor

Specifications

Indicator

Specification		SED-30	
Power requirements		DC10.8 ~ 30V	
Consumption current		50mA max. (supply voltage: DC10BV when a 2-point switch is turned ON for output)	
Storage temperature range		-4 ~ 158°F (-20 ~ 70°C) (Atmospheric pressure, humidity less than 60%RH)	
Operating temperature range		32 ~ 122°F (0 ~ 50°C) (No freezing)	
Operating humidity range		35 ~ 85%RH (No freezing)	
Protective structure		IEC standard IP40 equiv.	
Pressure indication method	No. of indications	4 times/sec	
	Response	Variable with a digital filter, about 5, 25, 250, 2500msec	
	Indication accuracy	±1%F.S.	
	Temperature characteristics	±0.5F.S. (32 ~ 122°F (0 ~ 50°C), reference temperature: 25°C/77°F)	
	Monitoring function	Beyond indicated numbers of digits	"9 9 9" flashes
		Beyond detection range	"- - -" flashes (rated pressure: 110% or more)
		Detection of output overloads	"E - 1" flashes/overloads detected, output indication lamp flashes
	'0' adjustment function		Panel switch-operated pressure indication (zero clear)
		Monitoring of adjustment error	Monitors '0' adjustment operation when residual pressure is impressed beyond (10%F.S.). "Error Warning E-2" flashes (cancelled using a panel switch)
	Resolution	1 digit	
	Pressure indication element	3-digit 7-segmented LED (character height: 8mm), colored red	
	Code indication element	LED lamp (illuminates at "minus", colored red)	
Rated pressure indication range	Pressure indication units and rated pressure ranges are selected via the panel switches listed in the table given below.		
Switch output	Number of output point	2-point outputs (SW1, Sw2)	
	Switch output method	NPN Open collector	
	Switch capacity	DC30V 100mA max.	
	Residual voltage	1.2V max. (with load current at 100mA)	
	Pressure setting method	Using a panel switch	
	Pressure setting range	999 ~ 999 count (decimal points are to conform to the range of rated voltage as given in the tabulated specifications).	
	Operational indication	Two LEDs light up (SW1: green, SW2: red, when output is switched ON)	
	Repetitiveness	±0.2%F.S. ±1count	
	Temperature characteristics	±0.5F.S. (32 ~ 122°F (0 ~ 50°C), reference temperature: 25°C/77°F)	
	Response	Can be adjusted by setting digital filters, 5, 25, 250, 2500msec	
	Setting differential responses	0 ~ 300 counts (canbe adjusted via a panel switch)	
	Protection against overloads	2-point output switches (SW1, SW2) are switched OFF (overload current: "200mA or beyond" or "beyond 200mA")	
Analog output	Output voltage	1 ~ 5V	
	Output current	1mA (Load resistance: 5kΩ min.)	
Sensor input specifications	Voltage input signal	1 ±0.1 ~ 5 ±0.1V	

Pressure sensors used		VUS11-□A	VUS11-□AR	SEU11-□A
Magnification (Unit)	Units of pressure	kPa		
	Pressure range setting code	-12P	32r	13P
×1 (kPa)	Rated pressure indication range (PL ~ PH)	0.0 ~ -99.9	-100 ~ 300	0 ~ 999
×0.0102 (kgf/cm²)		0.00 ~ -1.02	-1.02 ~ 3.06	0.00 ~ (9.99)
×10.2 (gf/cm²)		0 ~ (-999)	—	—
×7.501 (mmHg)		0 ~ -750	—	—
×102 (mmH.O)		—	—	—
×0.01 (bar)		0.00 ~ -1.02	-1.00 ~ 3.00	0.0 ~ 9.99
×10 (mbar)		0 ~ -999	—	—
×0.145 (psi)		0.0 ~ -14.5	-14.5 ~ 43.5	0 ~ 145
×0.000145 (kpsi)		—	—	—
×0.001 (MPa)		—	-0.10 ~ 0.30	0.00 ~ 1.00
×0.2953 (In.Hg)		0.0 ~ -29.5	-29.5 ~ -88.5	0 ~ 295
Analog output mode indicated		3	1	2

Model Designation of Sensor Heads (Example)



- Type**
SEU11 : Positive pressure sensor
VUS11 : Negative pressure sensor
- Pressure introduction configuration**
4: ø4mm nipple
6: ø6mm nipple
M5: M5×0.8 male screw
O1: R1/8 male screw
4U: ø4mm quick-fitting joint (fitted with an in-line installation holder)
6U: ø6mm quick-fitting joint (fitted with an in-line installation holder)
- Switch output**
A: Analog output
AR: Compound pressure type analog output
S: NPN open collector output
SR: Compound pressure type NPN open collector output
 *Compound pressure type (□R) is only accepted when ① "VUS11" is selected.

Model Designation of Indicators (Example)

SED - 30

Model Designation of Individual Indicator accessories (Example)



- Configuration of accessories (installation stay)**
O11: Rear angles (rear angles, two M3×4 male screws)
O12: Flat surface angles (two M3×4 male screws)
004: Holder cover set (a panel holder cover, a panel holder)
003: Panel holder set (a panel cover, a panel holder and panel stopper)
007: Holder stopper set (a panel holder and panel stopper)

➡ In case of ordering, please apply Model code in the following chart.

Detailed Safety Instructions

Before using the PISCO device, be sure to read the "Safety Instructions", "Common Safety Instructions for Products Listed in This Manual" on page 15 to 17 and "Common Safety Instructions for Control Series" on page 59 and "Common Safety Instructions for LED Digital Pressure Sensors, Digital Pressure Sensors & Pressure Sensors" on page 77.

⚠ Caution

- For power, use stable direct currents.
- Insert surge-absorbing circuits into relays, valves, etc. Do not arbitrarily use these units at currents that exceed rated levels.
- When using unit power sources, such as switching power sources, be sure to ground their FG terminals.
- Take the utmost care to avoid short-circuiting the output terminal with other terminals.
- Do not apply excessive loads to pressure sensors. Subjecting them to excessive loads can damage them.
- Do not wire nozzles and other components in a way that will impress them with noises, etc. Do not use them in any arbitrary manner, either. Doing so can cause malfunctions.
- When conducting pressure adjustments for units fitted with switch output sensors, use small screwdrivers (included). Do not apply excessive force to these screwdrivers, and turn them slowly. Applying excessive force may damage the units.
- Our indicator (SED-30) is not constructed to be drip- or dust-proof. As such, do not use indicators that have been exposed to water or oil and/or dust.
- For the SED-30 indicator's sensor heads, use either a "VUS 11...A." or an "SEU 11...A." type head. Using different specifications with these sensor heads will not achieve the required level of accuracy.
- Do not pull or bend vacuum switch lead wires excessively. Doing so may result in lead wires being snapped off and connector components broken.

Sensor heads (Switch type)				
SEU Positive pressure type VUS Negative pressure type	SEU Positive pressure type VUS Negative pressure type	SEU Positive pressure type VUS Negative pressure type		
				
Model	Model	Model		
SEU11-4US	SEU11-4S	SEU11-M5S		
SEU11-6US	SEU11-6S	SEU11-01S		
VUS11-4US	VUS11-4S	VUS11-M5S		
VUS11-6US	VUS11-6S	VUS11-01S		
VUS11-4USR	VUS11-4SR	VUS11-M5SR		
VUS11-6USR	VUS11-6SR	VUS11-01SR		
Sensor heads (Analog type)				
SEU Positive pressure type VUS Negative pressure type	SEU Positive pressure type VUS Negative pressure type	SEU Positive pressure type VUS Negative pressure type		
				
Model	Model	Model		
SEU11-4UA	SEU11-4A	SEU11-M5A		
SEU11-6UA	SEU11-6A	SEU11-01A		
VUS11-4UA	VUS11-4A	VUS11-M5A		
VUS11-6UA	VUS11-6A	VUS11-01A		
VUS11-4UAR	VUS11-4AR	VUS11-M5AR		
VUS11-6UAR	VUS11-6AR	VUS11-01AR		
Indicator				
SED Indicators				
				
Model				
SED-30				
Accessories for indicators				
ACPG-003 Panel-holder set	ACPG-004 Holder-cover set	ACPG-007 Holder-stopper set	ACPG-011 Rear angles	ACPG-012 Plain angles
				
Model	Model	Model	Model	Model
ACPG-003	ACPG-004	ACPG-007	ACPG-011	ACPG-012
			*It is equipped with two screws for fixing the sensor.	*It is equipped with two screws for fixing the sensor.