

**125/220 Watt Full Bandwidth Class D Amplifier**



The HCA125ACREF reference design delivers 125W RMS power into a 8Ω load and 220 watts into a 4Ω load. Since the efficiency is greater than 90%, no expensive, bulky heatsinks are required.

The design is part of Intersil's Cool Audio program that supports customers to achieve a minimum time-to-market for audio end products. As part of this program, this design is offered after execution of a Licensing Agreement. At that time, Intersil provides to the licensee a documentation package containing: 1) Circuit Description, 2) Schematics, 3) Test and Manufacturing Information, 4) A Bill of Materials with all vendors and vendor part numbers, 5) Intersil's Engineering Support Contacts, 6) and One Evaluation Unit.


For more information, see us on the web, home page <http://www.intersil.com>. For technical assistance, call Central Applications at 1-800-442-7747, or email us at [centapp@intersil.com](mailto:centapp@intersil.com).

**Ordering Information**  
Contact Intersil licensing agents, Continental Far East or International Operations. See contact information provided in this document.

**Ordering Information**

Contact Intersil licensing agents, Continental Far East or International Operations. See contact information provided in this document.

**Reference Design Block Diagram**




**Features**

- 125 Watts RMS Power into 8Ω
- 220 Watts RMS Power into 4Ω
- THD <0.07% at 1kHz and 110W into 8Ω
- SNR 110dB Relative to Full Power
- Output Noise, 10Hz to 22kHz. . . . . 110μV
- Constant Group Delay
- DC to 80kHz Small Signal Bandwidth
- Power Bandwidth . . . . . 28kHz
- Slew Rate . . . . . 8V/μs
- Efficiency >90% at 100W into 8Ω
- Meets FCC and EN55013 Requirements for EMC
- Based On the Intersil HCA8001, Audio Specific IC
- Modular Design
- Differential Input
- Over-Current, Over-Voltage and Thermal Protection
- Soft Clipping
- Bridgeable up to 800W

**Applications**

- Powered Speakers
- Professional Audio
- Home Theater
- Hi-Fi Stereo



# HCA125ACREF

## Absolute Maximum Ratings

Bus Voltage,  $V_{BUS}$  .....  $\pm 70V$   
 Audio Inputs ..... 12V Differential Peak to Peak Voltage  
 Bias Supply,  $12V_{FLT} = 12V$  Floating ..... 15V

## Operating Conditions

Bus Voltage,  $V_{BUS}$  .....  $\pm 60V$   
 Ambient Temperature Range .....  $0^{\circ}C$  to  $50^{\circ}C$

*CAUTION: Stresses above those listed in "Absolute Maximum Ratings" may cause permanent damage to the device. This is a stress only rating and operation of the device at these or any other conditions above those indicated in the operational sections of this specification is not implied.*

**Electrical Specifications**  $R_{LOAD} = 8\Omega$ ,  $V_{BUS} = 60V$  Supply Source Resistance  $< 2.5\Omega$ , Storage Capacitor  $> 22,000\mu F$ ,  
 $12V_{FLT} = 12V$  Floating Bias Supply

PARAMETER	SYMBOL	TEST CONDITIONS	$T_A = 25^{\circ}C$	
			TYP	UNITS
<b>SUPPLY SPECIFICATION</b>				
Minimum Bus Voltage	$V_{S\ MIN}$	Full Output Power	$\pm 48$	V
$\pm V_{BUS}$ RMS Current	$I_{V\ BUS}$	1kHz Sine Wave, Full Output Power ( $8\Omega$ Load)	1.2	A
$\pm V_{BUS}$ RMS Current	$I_{V\ BUS}$	1kHz Sine Wave, Full Output Power ( $4\Omega$ Load)	2.0	A
$\pm V_S$ Average Current	$I_{V_S}$	Idle Current, No Signal	30	mA
12V Floating Bias Supply Current	$I_{BIAS}$	Current supplied to power output gate driver circuitry.	120	mA
Rising Under Voltage Lock Out Voltage	$V_{UV\ Rising}$	Bus voltage that activates the amplifier.	$\pm 50$	V
Falling Under Voltage Lock Out Voltage	$V_{UV\ Falling}$	Bus voltage that shuts down the amplifier.	$\pm 42$	V
ENABLE Threshold Voltage	$V_{ENABLE1}$	Amplifier starts at this voltage, input amplifier muted.	1	V
ENABLE Threshold Voltage	$V_{ENABLE2}$	Input amplifiers active and entire amplifier active.	2	V
ENABLE Internal Source Current	$I_{ENABLE}$	Internal "Pull Up" Current	25	$\mu A$
<b>OUTPUT POWER AND EFFICIENCY</b>				
Maximum Output Power (Note 1)	$P_{MAX8\Omega}$	THD = 1%, 1kHz, $R_{LOAD} = 8\Omega$	125	W
Maximum Output Power (Note 1)	$10\%THD_{8\Omega}$	THD = 10%, 1kHz, $R_{LOAD} = 8\Omega$	160	W
Maximum Output Power (Note 1)	$P_{MAX4\Omega}$	THD = 1%, 1kHz, $R_{LOAD} = 4\Omega$	220	W
Maximum Output Power (Note 1)	$10\%THD_{4\Omega}$	THD = 10%, 1kHz, $R_{LOAD} = 4\Omega$	300	W
Efficiency	$P_{MAXEFF}$	$P_{OUT} = 10W$	63	%
	$P_{MAXEFF}$	$P_{OUT} = 25W$	76	%
	$P_{MAXEFF}$	$P_{OUT} = 50W$	85	%
	$P_{MAXEFF}$	$P_{OUT} = 100W$	90	%
<b>AMPLIFIER PERFORMANCE</b>				
Total Harmonic Distortion + Noise	THD+N	$P_{OUT} = 100W$ , $R_{LOAD} = 8\Omega$ , 1kHz	0.05	%
Signal to Noise Ratio	$V_{SNR}$	Relative to full scale output, 125W into $8\Omega$ .	110	dB
Output Noise	$V_N$	10Hz to 22kHz	110	$\mu V$
Intermodulation Distortion	IMD	SMPTE, 60Hz and 7kHz, 4:1, $R_{LOAD} = 4\Omega$ at 10W Output	0.03	%
PSRR ( $\Delta V_{OUT}/\Delta V_{BUS}$ )	PSRR	DC	300	$\mu V/V$
PSRR ( $\Delta V_{OUT}/\Delta V_{BUS}$ )	PSRRac	120Hz	-65	dB
Amplifier Output Offset Voltage	$ V_{OS} $	DC voltage across the speaker, load = $8\Omega$	50	mV
Amplifier Output Impedance	$Z_{OUT}$	Measured at 1kHz and 10W Output	22	$m\Omega$
Damping Factor	DF	Measured at 1kHz and 10W Output	350	
<b>ADDITIONAL CHARACTERISTICS</b>				
Cutoff Frequency, Referenced to 1kHz	$F_{UPPER8}$	-3dB, $R_{LOAD} = 8\Omega$ at 10W Output	80	kHz



**TABLE 1. HCA125ACREF BOARD TERMINAL DESIGNATIONS**

TERMINAL	DESIGNATION	FUNCTION
1	Analog Ground	Input Ground
2	Ground	Power Ground
3	- Input	Signal Input
4	Ground	Power Ground
5	Analog Ground	Input Ground
6	Ground	Power Ground
7	+ Input	Signal Input
8	Ground	Power Ground
9	Analog Ground	Input Ground
10	Ground	Power Ground
11	ENABLE	Chip Enable
12	Ground	Power Ground
13	FAN	Driver Signal
14	Ground	Power Ground
15	+ BUS	Pos. Supply
16	Ground	Power Ground
17	+ BUS	Pos. Supply
18	Ground	Power Ground
19	+ BUS	Pos. Supply
20	Ground	Power Ground
21	+ BUS	Pos. Supply
22	CL	Drive Signal
23	+ BUS	Pos. Supply
24	SFCL	Drive Signal
25	12V <sub>FLT</sub>	Floating Supply
26	Ground	Power Ground
27	- BUS	Neg. Supply
28	Ground	Power Ground
29	- BUS	Neg. Supply
30	Ground	Power Ground
31	- BUS	Neg. Supply
32	Ground	Power Ground
33	- BUS	Neg. Supply
34	Ground	Power Ground
35	- BUS	Neg. Supply
36	Ground	Power Ground

NOTE: The + and - terminals indicate phasing of the input operational amplifier and not signal phasing of the amplifier input to output. The signal from the amplifier input is 180 degrees out of phase with this nomenclature. Therefore, a positive going signal on the + input will result in a negative going signal on the output. Conversely, a positive going input on the - input will result in a positive going output signal.

### Typical Performance Curves




FIGURE 2. THD + N(%) vs FREQUENCY LOAD = 8Ω




FIGURE 3. AMPLIFIER FREQUENCY RESPONSE AT 10W - LOAD = 8Ω




FIGURE 4. AMPLIFIER TRANSFER CHARACTERISTIC WITH VARIOUS SETTINGS OF SOFT CLIPPING RESISTOR




FIGURE 5. OSCILLOSCOPE DISPLAY OF AMPLIFIER OUTPUT WITH SOFT CLIPPING CIRCUIT ENABLED

### Soft Clipping

Figures 4, 5 and 6 show the effects of the soft clipping circuitry within the amplifier. Figure 4 shows the transfer characteristic of the amplifier for various values of the soft clipping programming resistor. An important aspect of soft clipping is the apparent increase in sound level. As soft clipping is reached, the upper and lower envelope of the sinewave is gradually reduced. The “soft” clipping or rounding reduces the higher harmonics that would result if hard clipping as shown in Figure 6 was enabled. Soft clipping also results in an amplifier with a more pleasing sound. Figure 5 shows the rounding of the output with soft clipping, while Figure 6 shows the amplifier output without soft clipping.





FIGURE 6. OSCILLOSCOPE DISPLAY OF AMPLIFIER OUTPUT WITH SOFT CLIPPING CIRCUIT DISABLED


Full Size Outline of HCA125ACREF Board

TOP VIEW



NOTE: The + and - terminals indicate phasing of the input operational amplifier and not signal phasing of the amplifier input to output. The signal from the amplifier input is 180 degrees out of phase with this nomenclature. Therefore, a positive going signal on the + input will result in a negative going signal on the output. Conversely, a positive going input on the - input will result in a positive going output signal

## Schematic Diagram of HCA125ACREF Board Test Setup



**CAUTION:** Remove all POWER when INSERTING or REMOVING the AMPLIFIER board. MAKE SURE POWER SUPPLY CAPACITORS are DISCHARGED or DAMAGE to the AMPLIFIER may RESULT.

### Board Test Equipment and Test Procedure for Intersil HCA125ACREF Amplifier

Equipment required for evaluation of the Intersil HCA125ACREF Amplifier is as follows:

1. Two 60V, 10A Power Supplies - Please read the next section, Test Procedure for Evaluation of HCA125ACREF, Item 1.
2. One 12V, 200mA Power Supply.
3. Distortion Analyzer such as the Audio Precision System One or System Two or equivalent.
4. Load resistors, 8 $\Omega$ , 200W and 4 $\Omega$ , 350W.
5. Associated connectors and cables.
6. HCA125ACREF Amplifier Board.

#### Test Procedure for Evaluation of HCA125ACREF

1. With no audio input signal, and the  $\pm 60\text{V}$  supplies current limit set at 1A and 10,000 $\mu\text{F}$  capacitors not connected, turn on the 12V amplifier floating power supply first. Next turn on both 60V supplies. The supply current with no input signal should be approximately 30mA. The 12V floating supply current should be about 120mA. After verifying that the supply current is normal, increase the current limit setting of the  $\pm 60\text{V}$  supplies to 3A and connect the 10,000 $\mu\text{F}$  capacitors (the actual amplifier current draw should remain constant with the

supplies at  $\pm 60\text{V}$  at this point). For safety, turn off 60V supplies before connecting capacitors.


It is important to note that many linear power supplies do not function properly with the peak current demands of these amplifiers at low frequencies. This is the reason for the 10,000 $\mu\text{F}$  capacitors applied across the two supplies. It is also important to make sure the supplies are stable with these capacitors.

A strong indicator of inadequate supply capacity is rising distortion at low frequencies. The amplifier distortion does not increase at low frequency. Transformer supplies with 10,000 $\mu\text{F}$  capacitors, for a single amplifier, are the most stable, providing the transformer can provide the required current.

2. Depending on the type of testing to be conducted (Output Power, Frequency Response, THD, etc.) select the menu and control panel settings on the Audio Precision Analyzer or other distortion analyzer to conduct the test. Input frequency should be set between 20Hz and 20kHz and input voltage level should be increased until desired output power is achieved. Conduct the desired tests in accordance with the Audio Precision or other analyzer test procedures. Power levels of 10W, 20W, 50W and 100W should be selected.
3. Power down audio signal input and turn off the  $\pm 60\text{V}$  power supplies before turning off the 12V floating supply.

# HCA125ACREF


## Block Diagram of HCA125ACREF Test Setup



NOTE: The +60V and -60V supplies must be capable of supplying peak currents up to 13A.



**Amplifier Test PC Board Interface Connector**



INTERFACE PC BOARD COMPONENTS		
COMPONENT	VALUE	FOOTPRINT
R1	200Ω, 5%, 0.25W	1206
R2	200Ω, 5%, 0.25W	1206
R3	13K, 5%, 0.25W	1206
R4	13K, 5%, 0.25W	1206
R5	0Ω	1206
R5A	0Ω	1206
R6	0Ω	1206
R7	0Ω	1206
C1	0.1μF, 50V, 10%	1206
LED1	LED	T1
LED2	LED	T1
D2	Not Populated	-
D3	12V, 5%, 0.25W	1206
J1	36 Pin Connector	-
J2	RCA Connector	-


**SCHEMATIC DIAGRAM OF PC INTERFACE BOARD**

**PC BOARD CONNECTIONS FOR AUDIO INPUT**

FUNCTION	R5	R5A	R6	R7
Inverting	Open	0Ω	Open	0Ω
Non-Inverting	0Ω	Open	0Ω	Open

The above tables show the method of connecting the amplifier audio input interface PC board connector, J2, to either the positive or negative input of the amplifier board. Note not all components need to be populated. For example, only two resistors are used for connection to the input amplifier. If the LEDs are not used, then the zener diode and associated resistors are not needed. The FAN output is available for an optional fan controller.

Holding the ENABLE terminal low by sinking the internal 25μA pull up current to ground will disable the amplifier output stage. Removing this ground shunt will restore normal amplifier operation. Both the ENABLE and FAN terminals may be left open.



Not Shown on Silk Screen  
Component side looking towards end of amplifier module.

NOTE: Not all parts are populated. 12V = 12V<sub>FLT</sub> Supply. Refer to tables for components and options.

NOTE: The + and - terminals indicate phasing of the input operational amplifier and not signal phasing of the amplifier input to output. The signal from the amplifier input is 180 degrees out of phase with this nomenclature. Therefore, a positive going signal on the + input will result in a negative going signal on the output. Conversely, a positive going input on the - input will result in a positive going output signal

## **Authorized Intersil Licensing Agents**

### **Asia**

Continental Far East, Inc.  
3-1-5 Azabudai, Minato-ku  
Tokyo 106, Japan  
Tel: 03-3584-0339  
FAX: 03-3588-0930

### **North America and Europe**

International Operations, Inc.  
15 Oakdale Manor  
Suffern, New York 10901  
USA  
Tel: 914-369-3532  
FAX: 914-369-1607

All Intersil semiconductor products are manufactured, assembled and tested under **ISO9000** quality systems certification.

*Intersil semiconductor products are sold by description only. Intersil Corporation reserves the right to make changes in circuit design and/or specifications at any time without notice. Accordingly, the reader is cautioned to verify that data sheets are current before placing orders. Information furnished by Intersil is believed to be accurate and reliable. However, no responsibility is assumed by Intersil or its subsidiaries for its use; nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of Intersil or its subsidiaries.*

For information regarding Intersil Corporation and its products, see web site <http://www.intersil.com>

## **Sales Office Headquarters**

### **NORTH AMERICA**

Intersil Corporation  
P. O. Box 883, Mail Stop 53-204  
Melbourne, FL 32902  
TEL: (407) 724-7000  
FAX: (407) 724-7240

### **EUROPE**

Intersil SA  
Mercure Center  
100, Rue de la Fusee  
1130 Brussels, Belgium  
TEL: (32) 2.724.2111  
FAX: (32) 2.724.22.05

### **ASIA**

Intersil (Taiwan) Ltd.  
7F-6, No. 101 Fu Hsing North Road  
Taipei, Taiwan  
Republic of China  
TEL: (886) 2 2716 9310  
FAX: (886) 2 2715 3029