

Service Manual

Compact Disc Player

Compact Disc Player

COMPACT
disc
DIGITAL AUDIO

DIGITAL

SL-PG360A


MASH
multi-stage noise shaping

Colour

(K) Black Type

Area

Suffix for Model No.	Area	Colour
(E)	Europe	(K)
(EB)	Great Britain	
(EG)	Germany and Italy	



New Traverse Deck (RAE1100Z) Specifications

■ Audio

No. of channels	2 (left and right, stereo)
Frequency response	2–20,000 Hz, ± 0.5 dB
Output voltage	2 V (at 0 dB)
Dynamic range	96 dB
S/N	100 dB
Harmonic distortion	0.0035% (1 kHz, 0 dB)
Total harmonic distortion	0.004% (1 kHz, 0 dB)
Wow and flutter	Below measurable limit
DA converter	MASH (1 bit)
Output impedance	600 Ω
Load impedance	More than 10 k Ω

■ Pickup

Wavelength	780 nm
Laser Power	No hazardous radiation is emitted (with safety protection)

■ General

Power consumption	13 W
Power supply	AC 50/60 Hz, 230–240 V
Dimensions (W×H×D)	430×92×283 mm
Weight	3.3 kg

Note:

Specifications are subject to change without notice.
Weight and dimensions are approximate.

For United Kingdom only:

This apparatus was produced to BS 800.

- Technics (or Panasonic) developed the world's first MASH type DAC and ADC. MASH technology was invented by NTT (LSI Labs).
- MASH is a trademark of NTT.

Technics

Contents

	Page		Page
● Handling Precautions for Traverse Deck	2	● Schematic Diagram	17~22
● Precaution of Laser Diode	2, 3	● Printed Circuit Board Diagram	23~25
● Accessories	3	● Wiring Connection Diagram	26
● Connections	3	● Display Function of Automatically-Adjusted Results	27
● Caution for AC Mains Lead (For United Kingdom)	4	● Digital Servo System	28
● Location of Controls	5	● Troubleshooting Guide	29, 30
● Basic Operating Procedure	6	● Functions of IC Terminals	31~33
● Disassembly Instructions	7~12	● Replacement Parts List	34~40
● Installing Disc Tray	13	● Cabinet Parts Location	37
● How to Check the Main P.C.B.	14	● Loading Unit Parts Location	39
● How to Check the Servo P.C.B.	14	● Packaging	40
● Block Diagram	15, 16		

Handling Precautions for Traverse Deck

The laser diode in the traverse deck (optical pickup) may break down due to potential difference caused by static electricity of clothes or human body.

So, be careful of electrostatic breakdown during repair of the traverse deck (optical pickup).

● Handling of traverse deck (optical pickup)


1. Do not subject the traverse deck (optical pickup) to static electricity as it is extremely sensitive to electrical shock.
2. To prevent the breakdown of the laser diode, an anti-static shorting pin is inserted into the flexible board (FPC board). When removing or connecting the short pin, finish the job in as short time as possible.
3. Take care not to apply excessive stress to the flexible board (FPC board).
4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.

● Grounding for electrostatic breakdown prevention

1. Human body grounding
Use the anti-static wrist strap to discharge the static electricity from your body.
2. Work table grounding
Put a conductive material (sheet) or steel sheet on the area where the traverse deck (optical pickup) is placed, and ground the sheet.

Caution:

The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).



Precaution of Laser Diode

CAUTION: This product utilizes a laser diode with the unit turned "on", invisible laser radiation is emitted from the pick up lens.
Wave length: 780 nm
Maximum output radiation power from pick up: 100 μ W/VDE

Laser radiation from the pick up unit is safety level, but be sure the followings:

1. Do not disassemble the optical pick up unit, since radiation from exposed laser diode is dangerous.
2. Do not adjust the variable resistor on the pickup unit. It was already adjusted.
3. Do not look at the focus lens using optical instruments.
4. Recommend not to look at pick up lens for a long time.

ACHTUNG: Dieses produkt enthält eine laserdiode. Im eingeschalteten zustand wird unsichtbare laserstrahlung von der lasereinheit abgestrahlt.

Wellenlänge: 780 nm
Maximale strahlungsleistung der lasereinheit: 100 μ W/VDE

Die strahlung an der lasereinheit ist ungefährlich, wenn folgende punkte beachtet werden:

1. Die lasereinheit nicht zerlegen, da die strahlung an der freigelegten laserdiode gefährlich ist.
2. Den werkseitig justierten einstellregler der lasereinheit nicht verstellen.
3. Nicht mit optischen instrumenten in die fokussierlinse blicken.
4. Nicht über längere zeit in die fokussierlinse blicken.

■Caution for AC Mains Lead (For United Kingdom)

("EB" area code model only)

For your safety, please read the following text carefully.

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.

A 5-ampere fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 5-ampere and that it is approved by ASTA or BSI to BS1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local dealer.

CAUTION!

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13-AMPERE SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician.

IMPORTANT

If the socket outlets in the home are not suitable for the plug supplied with this appliance it should be cut off and an appropriate three pin plug fitted.

The wires in this mains lead are coloured in accordance with the following code:

Blue: Neutral

Brown: Live


Do not connect either wire to the earth terminal in the plug which is marked by the letter "E" or by the safety earth symbol  or coloured green or green-and-yellow.

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows. The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED.


Before use

Remove the connector cover as follows.




How to replace the fuse


1. Open the fuse cover with a screwdriver.



2. Replace the fuse and close or attach the fuse cover.



■ Location of Controls




No.	Name
①	Power “STANDBY /ON” switch (POWER, STANDBY /ON) Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.
②	Disc tray
④	Standby indicator (STANDBY) When the unit is connected to the AC mains supply, this indicator lights up in standby mode and goes out when the unit is turned on.
⑤	Display panel
⑥	Numeric buttons (1–10, 0, >10)
⑦	Random play button (RANDOM)
⑧	CD edit record buttons (EDIT GUIDE)
	•Tape length button (TAPE LENGTH)
	•Tape side switch button (SIDE A/B)
	•Disc link button (DISC LINK)
	•Time fade button (TIME FADE)
⑨	Peak search button (PEAK SEARCH)
⑩	Auto cue button (AUTO CUE)

No.	Name
⑪	Disc tray open/close button ( OPEN/CLOSE)
⑫	Program play buttons
	•Program button (PROGRAM)
	•Clear button (CLEAR)
	•Recall button (RECALL)
⑬	Repeat button (REPEAT)
⑭	Skip buttons (, )
⑮	Stop button ()
⑯	Pause button ()
⑰	Play button ()
⑱	Time mode select button (TIME MODE)
⑳	Search buttons ( SEARCH )

Basic Operating Procedure

With this function, a disc is played from the first track to the last track and then stops automatically.




1 Press **POWER** (Power goes on).
If a compact disc is already in the disc tray, it automatically begins playing from the first track.

2 Press **▲ OPEN/CLOSE** to open the tray and insert a disc.



Label must face upward


3 Press **▲ OPEN/CLOSE** to close the tray.



Displayed if there are 21 or more tracks on the disc


On SL-PG360A, this indicator appears when there are 17 or more tracks on the disc.

4 Press **▶** (Play begins).
Play stops automatically after all tracks have been played.




■ To stop disc play

Press ■.



■ To pause disc play

Press ■■.













To continue playback, press ▶.



Notes

- The displayed total playing time includes the time between tracks. For this reason, the time may be several seconds longer than that which appears on song cards and the like.
- When you use the timer with other unit, be sure to turn this unit on.

For your reference:

If you skip step 3 and press ▶, the tray automatically closes and play begins from the first track.

Ref. No. 5	Removal of the operation P.C.B.	Ref. No. 6	Removal of the clamber plate and clamber ass'y
Procedure 1→2→5		Procedure 1→6	
Step 2 Release the 4 claws.  Step 3 Remove the operation P.C.B. in the direction of arrow.	 Step 1 Remove the 8 screws.	 Step 1 Remove the 2 screws. Step 2 Remove the clamber plate.	 Step 1 Remove the 2 screws.
Ref. No. 7	Removal of the loading unit		
Procedure 1→2→7			
 Step 3 Remove the 4 screws.	 Step 2 Remove the connector (CN402). Step 1 Pull out the flexible cable from connector (CN401).	 Step 3 Release the 3 claws in the direction of arrow.	 Step 3 Release the 3 claws in the direction of arrow.
Ref. No. 8	Removal of the power supply P.C.B.	Ref. No. 9	Removal of the spacer
Procedure 1→2→7→8		Procedure 1→2→7→9	
Step 1 Remove the 4 screws.  Step 2 Remove the flat cable from connector (CN21).	 Step 2 Remove the flat cable from connector (CN21).	 Step 1 Remove the 4 screws.	 Step 1 Remove the 4 screws.


Ref. No. 10	Removal of the foots	Ref. No. 11	Removal of the disc tray
Procedure 1→2→7→9→10	Step 1 Remove the 4 screws.	Procedure 1→2→6→7→11	Step 1 Push the 2 levels fully in the direction of the arrows ①. (Traverse unit in moved down.)
			
	Step 2 Release the 8 claws.		Step 2 Move the disc tray slightly in the direction of arrow ②.

Ref. No.
12


Removal of the servo P.C.B.
Procedure
1→2→7→12

Step 1


Remove the 3 screws.


Removal of the flexible cable

- Push the top of the connector in the direction of arrow ①, and then pull out the flexible cable in the direction of arrow ②.


Step 2


Remove the connector (CN703).












Step 3

Remove the flexible cable from connector (CN701).

Note:

Insert a shorting pin into the traverse unit flexible cable. (Refer to Handling Precautions for Traverse Deck on page 2.)




Ref. No. 13 Procedure 1→2→6→7→ 11→12→13	Removal of the converter lever and traverse deck ass'y	Note: Be careful not to damage the claw (A) or (B) because the claw (A) or (B) is breakable.
Step 1 Remove the spring. 	Step 2 Push the claw (A) in the direction of arrow ①, and then move the slide plate (1) in the direction of arrow ②.  Step 3 Push the claw (B) in the direction of arrow ③, and then move the slide plate (2) in the direction of arrow ④.  Step 4 Remove the converter lever in the direction of arrow ⑤.  Step 5 Remove the traverse deck ass'y in the direction of arrow ⑥. 	Step 1 Release the 2 claws in the direction of arrow ①.  Step 2 Remove the gear cover in the direction of arrow ②. 
Ref. No. 14 Procedure 1→2→6→7 →11→14	Removal of the lock lever Step 1 Remove the spring.  Step 2 Push the claw in the direction of arrow ① and then lift up the lock lever in the direction of arrow ②. 	Ref. No. 15 Procedure 1→2→6→7 →11→15 Removal of the gear cover Step 1 Release the 2 claws in the direction of arrow ①.  Step 2 Remove the gear cover in the direction of arrow ②. 

Ref. No. 16	Removal of the loading motor P.C.B. and loading motor ass'y	Polarity of loading motor ass'y terminals Step 1 Remove the 2 screws. Step 3 Remove the 1 screw. Step 4 Unsolder the loading motor ass'y terminals (2 points).	
Ref. No. 17	Removal of the slide plate (1)	Ref. No. 18	Removal of the slide plate (2)
Procedure 1→2→6→7→ 11→12→13→ 14→17	Step 1 Move the slide plate (1) in the direction of arrow ①, and lift up the slide plate (1) in the direction of arrow ②.	Procedure 1→2→6→7→11 →12→13→18	Step 1 Move the slide plate (2) in the direction of arrow ①, and lift up the slide plate (2) in the direction of arrow ②.
Ref. No. 19	Removal of the disc tray ornament	Step 1 Release the 2 claws, and then remove the disc tray ornament in the direction of arrow.	

Ref. No. 20	Removal of the traverse deck
Procedure 1→2→6→7→ 11→12→13→ 20	Step 1 Remove the 2 screws.


Step 2

Remove the traverse stopper




Step 3

Remove the lead wire from clamber.



Step 4

Push the damping rubber in the direction of arrow ①, and then remove it from traverse chassis.




Ref. No. 21	Removal of the drive rack
Procedure 1→2→6→7→ →11→21	(1 screw) Tapping screw 2 × 5 (Black)

Step 1

Remove the 1 screw.


Drive rack




- (1 screw) ①
Tapping screw
2.6 × 8 (Black)
- (1 screw) ②
Tapping screw
3 × 8

Step 5

Remove the traverse deck in the direction of arrow ②.




■Installing Disc Tray




Step 1

Slide the drive rack fully in the direction of arrow ①.




Step 2

Slide the conversion lever in the direction of arrow ②, and then leave the traverse deck ass'y falling.



Step 3

Align the disc tray groove with the mechanism chassis rib.



Step 4


Slide the disc tray in the direction of arrow ③. Then, put the drive rack manually so that the drive gear (1) engages with the drive rack gear.

Step 5

After the drive gear (1) engaged with the drive rack gear, slide the disc tray in the direction of arrow ③.



■Dispose of Wire

1. Dispose of wire in due order **a** to **f**.
2. Slacken off the each wire between solder part and each claw.



■How to Check the Main P.C.B.

1. Remove the cabinet referring to Procedure 1 "Removal of the cabinet" on page 7.
2. Remove the front panel ass'y referring to Procedure 2 "Removal of the front panel ass'y" on page 7.
3. Remove the operation P.C.B. referring to Procedure 5 "Removal of the operation P.C.B." on page 8.






4. Remove the 3 screws (1 ~ 3).
5. Remove the main P.C.B. and then stand the main P.C.B. at the side of unit.

6. Reinstall the operation P.C.B. to the main P.C.B.
7. Connect the GND terminal to the rear panel by the lead wire.
8. When checking the soldered surface of the main P.C.B., do as shown above.

■How to Check the Servo P.C.B.


1. Remove the cabinet referring to Procedure 1 "Removal of the cabinet" on page 7.



2. Turn on the power and press the OPEN/CLOSE switch to open the disc tray.
3. Load the test disc and press the OPEN/CLOSE switch again to close the disc tray.

4. Turn the power switch "OFF".
5. Remove the 2 screws (1, 2).
6. Draw the front panel ass'y in the direction of arrow.


7. Remove the 4 screws (3 ~ 6).



8. Place the loading unit sideways as shown in the figure left.
9. Attach the front panel ass'y to the unit.
10. After placing the unit as shown left, perform check and adjustment of the foil on the servo P.C.B.


■Block Diagram

Note: — AUDIO SIGNAL




■Schematic Diagram ●Optical Pickup/Servo Circuit (Parts list on pages 34~36.)

A SERVO CIRCUIT



To **E** MAIN
CIRCUIT
(CN401)
(Page 20)


Main/Operation/Loading Motor/Power Supply Circuit (Parts list on page 34~36.)




■Printed Circuit Board Diagram

●This circuit board diagram may be modified at any time with the development of new technology.


B OPERATION P.C.B. (REP1779B-S)




A SERVO P.C.B. (REP1755A-N)




C POWER SWITCH P.C.B. (REP1779B-S)




D LOADING MOTOR P.C.B. (REP1755A-N)



F POWER SUPPLY P.C.B. (REP1781A-P)



E MAIN P.C.B. (REP1777B-M)




●Terminal guide of IC's, transistors and diodes

BA4580FE1 	AN8389SE1 	AN8805SBE1 	MN682713RG1 	UPD78042G0G3 	TA7291SA
LM2940T5 	RCDHC-212 	2SA933SQSTA 2SC1740SQSTA DTA114ESTP DTA124ESTP DTC124ESTP 	2SA1309QRSTA 2SC3311QRSTA 2SD1450RSTA 	2SD2037EFTA 	2SB1238QSTV6 2SD1862-P
1SS254TA 	1D3-E 	MA4330MTA 	SLR-305LC 	MA4035MTA MA4056MTA MA4082MTA 	

■Wiring Connection Diagram

NOTES:
BLK Black
BLU Blue
BRN Brown
GRY Gray
GRN Green
L.BLU... Light Blue
ORG Orange
PNK Pink
RED Red
SLD Shield Wire
VLT Violet
WHT White
YEL Yellow



Display Function of Automatically-Adjusted Results

(Self-Check Function)

The unit contains a function which displays the result of the automatically adjustment of the servo circuits (tracking, focus servo, etc.) as an error code on the FL display. The error code display serves as a repair guide showing the automatically adjustment circuit is at fault. The procedures for displaying the error codes are given below.

• Procedures to display the error code

(1) Procedure to display the error code before disassembly (finished unit)

1. When the [POWER] key is pressed while holding down the [STOP] [■], [PAUSE] [■] and [PLAY] [▶] keys simultaneously, the FL display illuminates, release the power turns on.
2. When the FL display illuminates, release the [STOP] [■], [PAUSE] [■] and [PLAY] [▶] keys.
3. Press the [OPEN/CLOSE] [▲] key to open the disc tray and load the test disc (SZZP1054C).
4. Press the [PLAY] [▶] key to start the play operation.
5. After the time display appears, press the [STOP] [■] key to display the error code. (e.g. E-0)
6. The error code display can be used as a repair guide showing which servo circuit is at fault. (See Error Code Based Troubleshooting.)

• Error code based troubleshooting

※ The unit is satisfactory if the error code is E-0 of E-2.


※ Before testing, check that the test disc is free of scratches and dirt and optical pickup is clean.

FL error code display	Symptom	Probable cause	Signal to check		Normal the values of voltage and waveform	
			Signal name	Location	PLAY	STOP
E-1	Focus and tracking offset adjustments did not complete in the specified time period.	① Clocks X1 and X2, power supply VDD, and reset/RST, all on IC702 ② MDATA, MCLK, MLD, and SENSE signals to/from the mechanism controller	MDATA	IC702 ⑩ pin		4.8V
			MCLK	IC702 ⑩ pin		4.8V
			MLD	IC702 ⑩ pin		0V
			SENSE	IC702 ⑩ pin		4.9V
			/RST	IC702 ⑩ pin		4.9V
			X1	IC702 ⑩ pin		4.8V
			X2	IC702 ⑩ pin		4.8V
E-3 E-5 E-7 E-8 E-D E-F	Disc play unstable	① Scratches or contaminants on disc surface ② Focus and tracking servo circuits (check waveforms, voltages, and part constants.) ③ Spindle driver circuit ④ Optical pickup	FE	IC702 ⑩ pin		2.4V
			TE	IC702 ⑩ pin		2.4V
			FOD	IC702 ⑩ pin		2.4V
			TRD	IC702 ⑩ pin		2.4V
			KICK	IC702 ⑩ pin		2.4V
			/FLOCK	IC702 ⑩ pin		0V
			/RF DET	IC702 ⑩ pin		0V
			RF	TJ701		3.4V
			STAT	IC702 ⑩ pin		3.5V
E-4 E-6 E-C E-E	Best Eye (PD Balance) adjustment diode not complete in the specified time period.	① Scratches or contaminants on disc surface ② Focus and Tracking servo circuit (check waveforms, voltages, and part constants.) ③ Optical pickup	FBAL	IC702 ⑩ pin		2.5 ± 1.25V
			RF	TJ701		3.4V
			FE	IC702 ⑩ pin		0V
			/TLOCK	IC702 ⑩ pin		0V
			OFT	IC702 ⑩ pin		0V
			E-8 E-A	Focus or Tracking gain adjustment did not complete in the specified time period.	① Scratches or contaminants on disc surface ② Focus and Tracking servo circuit (check waveforms, voltages, and part constants.) ③ Optical pickup	FE
TE	IC702 ⑩ pin					2.4V
/TLOCK	IC702 ⑩ pin					0V
OFT	IC702 ⑩ pin					0V

Digital Servo System


DIGITAL SERVO SYSTEM

This servo system has no adjustment VRs.




The following flow chart shows the sequence of automatic adjustments.

• Flow chart on automatic adjustment sequence



* Because the microcomputer precisely performs automatic adjustments as shown in the flow chart, it will take approx. 5 seconds to finish reading TCC data if a used disc is eccentric one or its surface is warped.

Troubleshooting Guide



■Function of IC Terminals

●IC401 (UPD78042G063)

Pin No.	Terminal Name	I/O	Function
1	7G	O	FL grid drive signal output
5	1G	O	FL grid drive signal output
8	VDD	—	Power supply
9	MCLK	O	Microprocessor command clock
10	MDATA	O	Microprocessor command data
11	POWER SW	I	Power key switch signal input
12	SYNC REC	O	Synchro REC signal output
13	/MLD	O	Microprocessor command load signal
14	SQCK	O	External clock for subcode Q register
15	NC	—	No used, open
16	SUBQ	I	Subcode Q input
17	RST	I	Reset signal input
18	/OPEN SW	I	Disc tray "open" sense switch status
19	/CLOSE SW	I	Disc tray "close" sense switch status
20	GND	—	GND
21	/OPEN	O	Open Disc Tray command output
22	/CLOSE	O	Close Disc Tray command output
23	REST SW	I	Innermost track sense switch status
24	/RST	O	Reset signal output
25	STAT	I	Status signal input
26	/TLOCK	I	Tracking servo pull-in signal
27	/FLOCK	I	Focus servo pull-in signal
28	SENSE	I	Sense signal input
29	AVDD	—	Power supply (for A/D convert)
30	GND	—	GND
31	GND	—	GND
32	NC	—	No used, open
33	GND	—	GND
34	X1	I	Main clock (4.2336 MHz) input
35	X2	O	Main clock output

●IC703 (AN8389SE1)

Pin No.	Terminal Name	I/O	Function
1	Vcc	—	Power supply
2	VREF	I	VREF input
3	IN4	I	Motor driver (4) input
4	IN3	I	Motor driver (3) input
5	GND	—	Ground connection
6	NC	—	Ground connection
7	NRESET	—	Reset input (no used, open)
8	GND	—	Ground connection
9	IN2	I	Motor driver (2) input
10	PC2	I	PC2 (power cut) input
11	IN1	I	Motor driver (1) input
12	PC1	I	PC1 (power cut) input

Pin No.	Terminal Name	I/O	Function
36	P37	I	No used, open
36	P36	I	No used, open
39	P34	I	No used, open
40	P33	I	GND
41	P32	I	No used, open
42	P31	I	No used, open
43	P30	I	No used, open
44	MRST	O	Reset signal for MASH (No used, open)
45	EMPH	O	Emphasis signal (No used, open)
46	/DMUTE	O	Muting signal output
47	REMOCON	I	Remote control signal input
48	GND	—	GND
49	/POWER OFF	O	Power key switch signal output
50	/STANDBY LED	O	STANDBY LED control signal
51	REC ENABLE	I	REC control signal
52	VDD	—	Power supply
53	P127	I	Key return signal
57	P123	I	Key return signal
58	12G	I	Connect FL Display 12G
59	P16	O	FL anode drive signal
60	P15	O	FL anode drive signal
61	P14	O	FL anode drive signal and key scan signal
68	P7	O	FL anode drive signal
69	P6	O	FL anode drive signal
70	P5	O	FL anode drive signal
71	VPP	—	Power supply terminal for FL drive
72	P4	O	FL anode drive signal
75	P1	O	FL anode drive signal
76	12G	O	FL grid drive signal
80	8G	O	FL grid drive signal

Pin No.	Terminal Name	I/O	Function
13	PVcc1	—	Power supply (1) for driver
14	PGND1	—	Ground connection (1) for driver
15	D1-	O	Motor driver (1) reverse-action output
16	D1+	O	Motor driver (1) forward-action output
17	D2-	O	Motor driver (2) reverse-action output
18	D2+	O	Motor driver (2) forward-action output
19	D3-	O	Motor driver (3) reverse-action output
20	D3+	O	Motor driver (3) forward-action output
21	D4-	O	Motor driver (4) reverse-action output
22	D4+	O	Motor driver (4) forward-action output
23	PGND2	—	Ground connection (2) for driver
24	PVcc2	—	Power supply (2) for driver

●IC701 (AN8805SBE1)

Pin No.	Terminal Name	I/O	Function
1	PD	I	APC amplifier input
2	LD	O	APC amplifier output (No used, open)
3	LD ON/OFF	I	APC ON/OFF control signal
4	REFSW	I	Capacitor connection for CROSS
5	VCC	—	Power supply
6	RF-	I	RF amplifier inversion signal input
7	RF	O	RF amplifier signal output
8	RFIN	I	AGC signal input
9	CAGC	I	AGC loop filter connection
10	ARF	O	AGC signal output
11	CENV	I	Capacitor connection for RF detection
12	CEA	I	Capacitor connection for HPF amplifier
13	CSBDO	I	Capacitor connection for -RF envelope detection
14	EDO	O	BDO signal output
15	CSBRT	I	Capacitor connection for RF envelope detection
16	OFTR	O	OFTR signal output
17	/RFDET	O	RFDET signal output
18	Vss	—	GND
19	ENV	O	3TENV signal output
20	VREF	O	VREF signal output
21	LD OFF	—	APC OFF signal control
22	VDET	O	VDET signal output
23	TEBPF	I	VDET signal input
24	CROSS	O	CROSS signal output
25	TEOUT	O	TE amplifier signal output
26	TE-	I	TE amplifier inversion signal input
27	FEOUT	O	FE amplifier signal output
28	FE-	I	FE amplifier inversion signal input
29	FBAL	I	F BAL control signal
30	TBAL	I	T BAL control signal
31	PDFR	—	Adjustment for I-V amplifier conversion resistor
32	PDER	—	Adjustment for I-V amplifier conversion resistor
33	E	I	I-V amplifier signal input
34	F	I	I-V amplifier signal input
35	B+D	I	I-V amplifier signal input
36	A+C	I	I-V amplifier signal input

●IC702 (MN662713RG1)

Pin No.	Terminal Name	I/O	Function
1	BLCK	O	Bit clock output for serial data
2	LACK	—	L.R identification signal output
3	SRDATA	—	Serial data output
4	DVdd1	—	Power supply input (for digital circuit)
5	DVss1	—	GND (for digital circuit)
6	TX	O	Digital audio interface signal output
7	MCLK	I	Microprocessor command clock signal input (Latches data at first transition)
8	MDATA	I	Microprocessor command data signal input
9	MLD	I	Microprocessor command load signal input
10	SENSE	O	Sense signal output (OFT, FESL, MAGEND, NAJEND, POSAD, SFG)
11	/FLOCK	O	Focus servo feeding signal output ("L": Feed)
12	/TLOCK	O	Tracking servo feeding signal output ("L": Feed)
13	BLCK	O	Sub-code block clock signal output (BLCK = 75 Hz during normal playback) (no used, open)
14	SQCK	I	External clock signal input for sub-code Q register
15	SUBQ	O	Sub-code Q code output
16	DMUTE	I	Muting input ("H": Mute)
17	STAT	O	Status signal output (CRC, CUE, CLVS, TTSTVP, FCLV, SQCK)
18	/RST	I	Reset input
19	SMCK	—	1/2-divided clock signal of crystal oscillating at MSEL = "H" (SMCK = 8.4672 MHz) 1/4-divided clock signal of crystal oscillating at MSEL = "L" (SMCK = 4.2336 MHz) (no used, open)
20	PMCK	—	1/192-divided clock signal of crystal oscillating (PMCK = 88.2 kHz) (no used, open)
21	TRV	O	Traverse forced feed output
22	TVD	O	Traverse drive output
23	PC	O	Spindle motor ON signal output ("L": ON)
24	ECM	O	Spindle motor drive signal output (forced mode output)
25	ECS	O	Spindle motor drive signal output (servo error signal output)
26	KICK	O	Kick pulse output
27	TRD	O	Tracking drive output
28	FOD	O	Focus drive output
29	VREF	I	D/A (drive) output (TVD, ECS, TRD, FOD, FBAL, TBAL) reference voltage input
30	FBAL	O	Focus balance adjustment output
31	TBAL	O	Tracking balance adjustment output

●IC702 Continued

Pin No.	Terminal Name	I/O	Function
32	FE	I	Focus error signal input (analog input)
33	TE	I	Tracking error signal input (analog input)
34	RFENV	I	RF envelope signal input
35	VDET	I	Vibration detection signal input ("H": detection)
36	OFT	I	Off-track signal input ("H": off track)
37	TRCRS	I	Track cross signal input
38	/RFDET	I	RF detection signal input ("L": detection)
39	BDO	I	Dropout signal input ("H": Dropout)
40	LDON	O	Laser on signal output ("H": ON)
41	TES	O	Tracking error shunt signal output ("H": shunt) (no used, open)
42	PLAY	O	Play signal output ("H": PLAY) (no used, open)
43	WVEL	O	Double speed status signal output ("H": Double speed) (no used, open)
44	ARF	I	RF signal input
45	IREF	I	Reference current input
46	DRF	—	DSL bias (no used, open)
47	DSLIF	I/O	DSL loop filter
48	PLLIF	I/O	PLL loop filter
49	VCOF	I/O	VCO loop filter
50	AVdd2	—	Power supply input (for analog circuit)
51	AVss2	—	GND (for analog circuit)
52	EFM	—	EFM signal output (not used, open)
53	PCK	—	PLL extraction clock output (PCK = 4.321 MHz during normal playback) (no used, open)
54	PDO	—	Phase comparison signal of EFM and PCK signals (no used, open)
55	SUBC	O	Sub-code serial data output (no used, open)
56	SBCK	I	Clock input for sub-code serial data
57	Vss	—	GND
58	X1	I	Crystal oscillating circuit input (f = 16.9344 MHz)
59	X2	O	Crystal oscillating circuit output (f = 16.9344 MHz)
60	Vdd	—	Power supply input (for oscillating circuit)
61	BYTCK	—	Byte clock output (no used, open)
62	/CLDCK	O	Sub-code frame clock signal output (CLDCK = 7.35 kHz during normal playback)
63	FCLK	—	Crystal frame clock signal output (FCLK = 7.35 kHz, double = 14.7 kHz)
64	IPFLAG	O	Interpolation flag output ("H": Interpolation) (no used, open)
65	FLAG	O	Flag output (no used, open)

■Replacement Parts List


Notes: *Important safety notice: Components identified by Δ mark have special characteristics important for safety. Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used. When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list. *The parenthesized indications in the Remarks column specify the areas. (Refer to the cover page for area.) Parts without these indications can be used for all areas. *MBV indicates in Remarks column parts that are supplied by MBV. *Warning: This product uses a laser diode. Refer to caution statements on page 2. *ACHTUNG: Die Lasereinheit nicht zerlegen. Die Lasereinheit darf nur gegen eine vom Hersteller spezifizierte Einheit ausgetauscht werden. *The "(SF)" mark denotes the standard part.							
Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
				D052	1SS254TA	DIODE	
		(INTEGRATED CIRCUIT(S))				TRANSFORMER(S)	
IC11	LM2940TS	I. C. REGULATOR	Δ				
IC401	UPD78042G063	I. C. SYSTEM CONTROL	[MB]	PT1	KTP1K48020	POWER TRANSFORMER	Δ [MB]
IC601	RCM6-212	I. C. REMOTE SENSOR	[MB]				
IC701	AN8805SBE1	I. C. SERVO AMP.	[MB]			OSCILLATOR(S)	
IC702	MN662713RG1	I. C. SERVO PROCESSOR	[MB]				
IC703	AN8389SE1	I. C. MOTOR DRIVE		X401	RSX402001T	OSCILLATOR (4.23MHz)	
IC701	TA7291SA	I. C. MOTOR DRIVE		X701	RSX210001T	OSCILLATOR (16.9MHz)	
IC802, 803	BA4560FE1	I. C. DIFFERENTIAL P. F. AMP	[MB]			DISPLAY TUBE	
		TRANSISTOR(S)					
				FL601	RSJ1030-F	DISPLAY TUBE	[MB]
Q11	2SD2037EFA	TRANSISTOR	Δ				
Q12	2SC3311A-Q	TRANSISTOR	Δ			SWITCHES	
Q13-14	2SA1309A-R	TRANSISTOR	Δ				
Q15	2SA1309A-R	TRANSISTOR		S601	EVQ21405R	SW. 0	
Q16	2SB1238QSV6	TRANSISTOR	Δ	S602	EVQ21405R	SW. 1	
Q19, 20	2SD1450MTA	TRANSISTOR		S603	EVQ21405R	SW. 2	
Q21	DTA124ESTP	TRANSISTOR		S604	EVQ21405R	SW. 3	
Q22	2SC3311A-Q	TRANSISTOR		S605	EVQ21405R	SW. 4	
Q23	2SD2037EFA	TRANSISTOR	Δ	S606	EVQ21405R	SW. 5	
Q51, 52	2SC3311A-Q	TRANSISTOR		S607	EVQ21405R	SW. 10	
Q401, 402	2SD1862-P	TRANSISTOR	Δ	S608	EVQ21405R	SW. 10	
Q751	2SA933QR	TRANSISTOR		S609	EVQ21405R	SW. 9	
Q752	2SC1740SQ	TRANSISTOR		S610	EVQ21405R	SW. 8	
Q802, 804	2SD1450MTA	TRANSISTOR		S611	EVQ21405R	SW. 7	
Q851	DTA124EST	TRANSISTOR		S612	EVQ21405R	SW. 6	
Q853	DTA124ESTP	TRANSISTOR		S613	EVQ21405R	SW. PLAY	
				S614	EVQ21405R	SW. R. SKIP	
				S615	EVQ21405R	SW. F. SEARCH	
				S616	EVQ21405R	SW. PROGRAM	
D11-18	1D3-E	DIODE	Δ [MB]	S617	EVQ21405R	SW. DISC LINK	
D19	MA4330MTA	DIODE	Δ	S619	EVQ21405R	SW. STOP	
D20	1SS254TA	DIODE		S620	EVQ21405R	SW. F. SKIP	
D21, 22	MA4082MTA	DIODE	Δ	S621	EVQ21405R	SW. R. SEARCH	
D25, 26	1SS254TA	DIODE		S622	EVQ21405R	SW. RECALL	
D51	MA4039MTA	DIODE		S623	EVQ21405R	SW. SIDE A/B	
D401	MA4059MTA	DIODE		S624	EVQ21405R	SW. RANDOM	
D601-607	1SS254TA	DIODE		S625	EVQ21405R	SW. TIME FADE	
D651	SLN-305LC	LED		S626	EVQ21405R	SW. OPEN/CLOSE	
D701	1SS254TA	DIODE		S627	EVQ21405R	SW. PAUSE	
D801, 802	1SS254TA	DIODE		S628	EVQ21405R	SW. REPEAT	
D851	1D3-E	DIODE	[MB]	S629	EVQ21405R	SW. CLEAR	

[illegible]

Notes : * Capacity values are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
			R761, 762	ERDS2TJ103	1/4W 10K	C714	ECEA0JKA1011	6. 3V 100U
		RESISTORS	R763	ERDS2TJ823T	1/4W 82K	C716	ECBT1H561KB5	50V 560P
			R764	ERDS2TJ393	1/4W 39K	C717	ECFR1E104ZF5	25V 0. 1U
R1	ERQ16NKNR15E	1W 0. 15	R765	ERDS2TJ224T	1/4W 220K	C718	ECQV1H224JM3	50V 0. 22U
R12, 13	ERDS2TJ102	1/4W 1K	R766	ERDS2TJ104	1/4W 100K	C721, 722	ECBT1H270J5	50V 27P
R14	ERDS2TJ103	1/4W 10K	R772, 773	ERDS2TJ220T	1/4W 22	C723	ECEA0JKA221B	6. 3V 220U
R15	ERDS2TJ822	1/4W 8. 2K	R775, 776	ERDS2TJ392T	1/4W 3. 9K	C724	ECFR1E104ZF5	25V 0. 1U
R16	ERDS2TJ680T	1/4W 68	R777	ERDS2TJ102	1/4W 1K	C725, 726	ECBT1H102KB5	50V 1000P
R17	ERDS2TJ471	1/4W 470	R801, 802	ERDS2TJ104	1/4W 100K	C727, 728	ECEA1HKA0101	50V 1U
R18	ERDS2TJ473	1/4W 47K	R803	ERDS2TJ472	1/4W 4. 7K	C730	ECFR1E104ZF5	25V 0. 1U
R19	ERDS2TJ472	1/4W 4. 7K	R804	ERDS2TJ470	1/4W 47	C731, 732	ECEA0JKA221B	6. 3V 220U
R23	ERDS2TJ103	1/4W 10K	R805	ERDS2TJ472	1/4W 4. 7K	C733	ECFR1E104ZF5	25V 0. 1U
R24-27	ERDS2TJ1R0	1/4W 1. 0	R807, 808	ERDS2TJ104	1/4W 100K	C734	ECEA1AKA2211	10V 220U
R28, 29	ERDS2TJ103	1/4W 10K	R809-812	ERDS2TJ224T	1/4W 220K	C735-737	ECBT1E223ZF	25V 0. 022U
R30, 31	ERDS2TJ223	1/4W 22K	R813, 814	ERDS2TJ153	1/4W 15K	C738	FCFR1C183KR	16V 0. 018U
R51	ERDS2TJ331	1/4W 330	R815, 816	ERDS2TJ183T	1/4W 18K	C739	ECBT1C152MR5	16V 1500P
R52	ERDS2TJ272T	1/4W 2. 7K	R817, 818	ERDS2TJ153	1/4W 15K	C740	ECBT1C272MR5	16V 2700P
R53, 54	ERDS2TJ472	1/4W 4. 7K	R819, 820	ERDS2TJ471	1/4W 470	C742	ECFR1C273KR	16V 0. 027U
R401	ERDS2TJ102	1/4W 1K	R821, 822	ERDS2TJ473	1/4W 47K	C743	ECBT1E223ZF	25V 0. 022U
R402	ERDS2TJ473	1/4W 47K	R823, 824	ERDS2TJ331	1/4W 330	C744	ECBT1C822MS5	16V 8200P
R403, 404	ERDS2TJ103	1/4W 10K	R825, 826	ERDS2TJ102	1/4W 1K	C747, 748	ECBT1C103NS5	16V 0. 01U
R405, 406	ERDS2TJ471	1/4W 470	R851	ERDS2TJ471	1/4W 470	C751	ECEA1CKA1001	16V 10U
R407	ERDS2TJ101	1/4W 100	R852	ERDS2TJ222	1/4W 2. 2K	C752	ECFR1E104ZF5	25V 0. 1U
R408-411	ERDS2TJ103	1/4W 10K				C765	ECBT1H331KB5	50V 330P
R601	ERDS2TJ120T	1/4W 12			CAPACITORS	C766	ECBT1H391KB5	50V 390P
R651	ERDS2TJ221	1/4W 220				C767	ECEA1HKN0101	50V 1U
R701	ERDS2TJ561	1/4W 560	C1	ECFTD103KXL	50V 0. 01U	C768	ECFR1E682KR	25V 6800P
R703	ERDS2TJ823T	1/4W 82K	C10	ECFR1E104ZF5	25V 0. 1U	C769	ECBT1C222MR5	16V 2200P
R707, 708	ERDS2TJ334	1/4W 330K	C11	ECA1CM222B	16V 2200U Δ	C772-775	ECFR1E104ZF5	25V 0. 1U
R709	ERDS2TJ683	1/4W 68K	C12	ECBT1C103NS5	16V 0. 01U	C776	ECBT1H180J5	50V 18P
R711	ERDS2TJ154	1/4W 150K	C13	ECEA1AKA330B	10V 33U	C777	ECBT1H680J5	50V 68P
R712	ERDS2TJ221	1/4W 220	C14	ECEA0JKA470B	6. 3V 47U	C781	ECEA1AKA1011	10V 100U
R717, 718	ERDS2TJ102	1/4W 1K	C15	ECEA1EU101	25V 100U Δ	C801, 802	ECBT1H180J5	50V 18P
R721	ERDS2TJ101	1/4W 100	C16	ECEA1EU331	25V 330U Δ	C803, 804	ECBT1H102KB5	50V 1000P
R722	ERDS2TJ683	1/4W 68K	C17, 18	ECEA1HJ101	50V 100U	C805, 806	ECBT1H121KB5	50V 120P
R723	ERDS2TJ183T	1/4W 18K	C19	ECEA1EU101	25V 100U	C811, 812	ECEA1HKA010B	50V 1U
R724	ERDS2TJ393	1/4W 39K	C22	ECEA1AU331	10V 330U	C813, 814	ECEA0JKA470B	6. 3V 47U
R725	ERDS2TJ472	1/4W 4. 7K	C51	ECEA1AKA220B	10V 22U	C815, 816	ECBT1H102KB5	50V 1000P
R726	ERDS2TJ474	1/4W 470K	C401	ECFR1E104ZF5	25V 0. 1U	C817	ECFR1E104ZF5	25V 0. 1U
R727	ERDS2TJ153	1/4W 15K	C402	ECEA0JU102	6. 3V 1000U	C831	ECEA0JKA470B	6. 3V 47U
R728	ERDS2TJ822	1/4W 8. 2K	C404	ECFR1E104ZF5	25V 0. 1U	C833	ECFR1E104ZF5	25V 0. 1U
R731	ERDS2TJ223	1/4W 22K	C405	ECEA0JKA101B	6. 3V 100U	C851	ECEA0JU471	6. 3V 470U
R732	ERDS2TJ183T	1/4W 18K	C703	ECEA0JKA1011	6. 3V 100U			
R733	ERDS2TJ822	1/4W 8. 2K	C704	ECFR1E104ZF5	25V 0. 1U			
R735, 736	ERDS2TJ101	1/4W 100	C705	ECEA1HKA0101	50V 1U			
R745	ERDS2TJ155	1/4W 1. 5M	C706	ECBT1H101KB5	50V 100P			
R751	ERDS2TJ681	1/4W 680	C707	ECFR1C273KR	16V 0. 027U			
R752, 753	ERDS2TJ392T	1/4W 3. 9K	C708	ECBT1C472MR5	16V 4700P			
R754	ERDS2TJ103	1/4W 10K	C709	ECFR1C473KR	16V 0. 047U			

■Cabinet Parts Location



Loading Unit Parts Location

Note:

When changing mechanism parts, apply the specified grease to areas marked "xx" as shown in the drawing.

Ref No.	Part No.
①	RFKXEM30L

A


B

C

D

E


F



Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET PARTS	
1	RKMO098-K	CABINET	[MB]
2	RFKGLPG360AE	FRONT PANEL ASS'Y	[MB]
2-1	RKWO245D-R	WINDOW	[MB]
2-2	RGU1029-K	POWER BUTTON	[MB]
2-3	RFKNLPG460AD	MAIN BUTTON A	[MB]
2-4	RFKNLPG460AE	MAIN BUTTON B	[MB]
2-5	RGU0808-K	SUB BUTTON	[MB]
3	RFKHLPG360AE	REAR PANEL ASS'Y	[MB] (E) (EG)
3	RFKHLPG360AB	REAR PANEL ASS'Y	[MB] (EB)
4	RMKO178-1	BOTTOM CHASSIS	[MB]
5	RHD30035-K	SCREW	
6	XTBS3+8JFZ1	SCREW	
7	EYF52BC	FUSE HOLDER	
8	SJS9236	AC INLET (JK1)	△
9	REX0577	CABLE ASS'Y	[MB]
10	RGK0616-K	TRAY LID	[MB]
11	RKA0040B	FOOT	[MB]
12	RMRO377-1	PCB SUPPORT	[MB]
13	RMRO718-W	MECHANISM SPACER	[MB]
14	RWJ5223180EE	FPC	[MB]
15	RWJ6406180XX	FLAT CABLE	[MB]
16	RMRO659-K	FL HOLDER	[MB]
17	RGLO228-Q	LED INDICATOR	[MB]
18	XTBS26+8J	SCREW	
19	XTB3+20JFR	SCREW	
20	XTB3+8JFZ	SCREW	
21	RWJ6403200XX	FLAT CABLE (FC651)	[MB]
		LOADING UNIT PARTS	
101	RGQ0130-K	TRAY	[MB]
102	RFKJLPG460AE	MECHANISM CHASSIS ASS'Y	[MB]
103	RMRO719-W	MID. CHASSIS	[MB]
104	RAE1100Z	TRAVERSE UNIT	[MB]
105	REX0576	CABLE ASS'Y	[MB]
106	RHD30047	SCREW	[MB]
107	RMGO337-K	DAMPING RUBBER	[MB]
108	RMGO337-Q	DAMPING RUBBER	[MB]
109	RMRO750-W	STOPPER	[MB]
110	XTBS26+8J	SCREW	
111	RDGO142	RELAY GEAR	
112	RDGO259	DRIVE GEAR	[MB]
113	RDPO065	RELAY PULLY	
114	REM0047	MOTOR ASS'Y	[MB]
115	RMEO063	LOCK LEVER SPRING	
116	RMEO087	ASSIST SPRING	
117	RMGO158	BELT	
118	RMGO338-Q	STOPPER RUBBER	[MB]
119	RML0177	CHANGE LEVER	

Ref. No.	Part No.	Part Name & Description	Remarks
120	RML0178-1	LOCK LEVER	
121	RMMO112	SLIDER 1	[MB]
122	RMMO113	SLIDER 2	[MB]
123	RMRO721-K	GEAR COVER	[MB]
124	RHD20009-1	SCREW	
125	RFKNLPG460AA	DRIVE RACK ASS'Y	[MB]
126	XTB3+8JFZ	SCREW	
127	XYN2+F6FZ	SCREW	
128	RFKNLPG460AB	CLAMP BASE ASS'Y	[MB]
129	RFKNLPG460AC	CLAMPER ASS'Y	[MB]
		PACKING MATERIALS	
P1	RPG1906	PACKING CASE	[MB]
P2	RPNO647	CUSHION	[MB]
P3	XZB23X35C03	PROTECTION BAG	
P4	XZB60X65A01Z	PROTECTION BAG	
		ACCESSORIES	
A1	RJA0043-C	AC POWER CORD	△ (E, EG) [MB]
A1	RJA0034-P	AC POWER CORD	△ (EB) [MB]
A2	RFKSLPG360AE	INSTRUCTIONS MANUAL	(E) [MB]
A2	RQT2226-B	INSTRUCTIONS MANUAL	(EB) [MB]
A2	RFKSLPG360AG	INSTRUCTIONS MANUAL	(EG) [MB]
A3	SJP2249-3	STEREO PIN CORD	
A4	RQA0013	WARRANTY CARD	
A5	RQCB0169	SERVICE CENTER LIST	

■Packaging



Printed in Germany

MBV F9402 TW/HH/TN