

# Multi Line Sensor Heads for narrow-width scanners

## LSH2004-AA10A

Equipped with the sensor chips that have built-in analog memory, this compact color multi line sensor head is suitable for any scanning applications that require rapid scanning of widths of up to A6. It best fits into the photo graphic applications.


#### • Applications

Check readers, card scanners, and a variety of other image input devices.

#### Features

- 1) By integrating the signal amplifier on the sensor chip, external noise is shut out. Additionally, newly developed analog memory circuit and realizes high speed scanning.
- 2) The LED light source is mounted on the same substrate as the sensor chip which makes it possible to package the device with lighter weight and an extremely small size.
- 3) With the proprietary prism(reflectors), the output signal is maintained uniformly.
- 4) The ceramic substrate is used for excellent dimensional accuracy and thermal stability. Variation and maximize the image re-productivity.

### •Dimensions (Unit : mm)




#### Characteristics

Parameter	Symbol	Тур.	Unit
Effective scanning width	-	104	mm
Primary scan dot density	-	203	dpi
Total dot number	-	864	dots
Power supply voltage	Vdd	5	V
Scanning speed	SLT	0.4	ms / line *
Clock frequency	CLK	1.25	MHz
Maximum dynamic range	VRMax.	0.75	V
Minimum dynamic range	VRMin.	0.375	V
Dark output	Vod	1.7±0.2	V
Operating temperature	-	5 to 45	°C

Analogue signals are produced output at double rate of clock frequency.

#### Pin assignments


No.	Circuit	1/0	Functions	
1	Ao	0	Analog output	
2	GND	I	Ground	
3	SI	I	Serial-in	
4	CLK	I	Clock	
5	Vdd	I	Power supply	
6	G-LED	I	LED ground	
7	V-LED	I	LED power supply	




www.DataSheet4U.com

(b) Data Output Timing Chart

After turning on the SI pulse, the analog output shape starts from the setting up point of 27 clock pulse.



Note) Output blank part cannot be used as the analog output standard level.



\*R1, R2=500

C1=47μF C3=100μF

\*Please adjust the value of resistance to fit your interface circuit.

	Notes
	g or reproduction of this document, in part or in whole, is permitted without the ROHM Co.,Ltd.
The conter	nt specified herein is subject to change for improvement without notice.
"Products'	nt specified herein is for the purpose of introducing ROHM's products (hereinafte ). If you wish to use any such Product, please be sure to refer to the specifications be obtained from ROHM upon request.
illustrate th	of application circuits, circuit constants and any other information contained hereir ne standard usage and operations of the Products. The peripheral conditions mus nto account when designing circuits for mass production.
However,	was taken in ensuring the accuracy of the information specified in this document should you incur any damage arising from any inaccuracy or misprint of such n, ROHM shall bear no responsibility for such damage.
examples implicitly, a other parti	cal information specified herein is intended only to show the typical functions of and of application circuits for the Products. ROHM does not grant you, explicitly o any license to use or exercise intellectual property or other rights held by ROHM and es. ROHM shall bear no responsibility whatsoever for any dispute arising from the in technical information.
equipment	cts specified in this document are intended to be used with general-use electronic or devices (such as audio visual equipment, office-automation equipment, commu- evices, electronic appliances and amusement devices).
The Produ	cts specified in this document are not designed to be radiation tolerant.
	IM always makes efforts to enhance the quality and reliability of its Products, a ay fail or malfunction for a variety of reasons.
against the failure of a shall bear	sure to implement in your equipment using the Products safety measures to guard e possibility of physical injury, fire or any other damage caused in the event of the ny Product, such as derating, redundancy, fire control and fail-safe designs. ROHM no responsibility whatsoever for your use of any Product outside of the prescribed ot in accordance with the instruction manual.
system wh may result instrument fuel-contro any of the	cts are not designed or manufactured to be used with any equipment, device o ich requires an extremely high level of reliability the failure or malfunction of which in a direct threat to human life or create a risk of human injury (such as a medica t, transportation equipment, aerospace machinery, nuclear-reactor controller oller or other safety device). ROHM shall bear no responsibility in any way for use o Products for the above special purposes. If a Product is intended to be used for any ial purpose, please contact a ROHM sales representative before purchasing.
be control	nd to export or ship overseas any Product or technology specified herein that may ed under the Foreign Exchange and the Foreign Trade Law, you will be required to sense or permit under the Law.



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/