

# SANYO Semiconductors

DATA SHEET

An ON Semiconductor Company

# 

#### Overview

The LV5747NTT is a 1-channel step-down switching regulator.

#### Functions

- 1 channel step-down switching regulator controller.
- Frequency decrease function at pendent.
- Load-independent soft start circuit.
- ON/OFF function.
- Built-in pulse-by-pulse OCP circuit. It is detected by using ON resistance of an external MOS.

#### **Specifications**

#### Absolute Maximum Ratings at $Ta = 25^{\circ}C$

Parameter		Symbol	Conditions	Ratings	Unit	
Supply voltage		V <sub>IN</sub> max		45	V	
-	V <sub>IN</sub> , SW			45	V	
	HDRV, CBOOT			52	V	
tage	LDRV			6.0	V	
Allowable pin voltage	Between CBOOT to SW Between CBOOT to HDRV			6.0	V	
	EN, ILIM			V <sub>IN</sub> +0.3	V	
	Between VIN to ILIM			1.0	V	
4	V <sub>DD</sub>			6.0	V	
	SS, FB, COMP			V <sub>DD</sub> +0.3	V	
Allowable Power dissipation		Pd max	Mounted on a specified board. *	0.75	W	
Operating temperature		Topr		-40 to +85	°C	
Storage temperature		Tstg		-55 to +150	°C	

\* Specified board : 35mm × 32mm × 1.6mm, glass epoxy 2-layer board.

Any and all SANYO Semiconductor Co.,Ltd. products described or contained herein are, with regard to "standard application", intended for the use as general electronics equipment (home appliances, AV equipment, communication device, office equipment, industrial equipment etc.). The products mentioned herein shall not be intended for use for any "special application" (medical equipment whose purpose is to sustain life, aerospace instrument, nuclear control device, burning appliances, transportation machine, traffic signal system, safety equipment etc.) that shall require extremely high level of reliability and can directly threaten human lives in case of failure or malfunction of the product or may cause harm to human bodies, nor shall they grant any guarantee thereof. If you should intend to use our products for applications outside the standard applications, please consult with us prior to the intended use. If there is no consultation or inquiry before the intended use, our customer shall be solely responsible for the use.

Specifications of any and all SANYO Semiconductor Co.,Ltd. products described or contained herein stipulate the performance, characteristics, and functions of the described products in the independent state, and are not guarantees of the performance, characteristics, and functions of the described products as mounted in the customer's products or equipment. To verify symptoms and states that cannot be evaluated in an independent device, the customer should always evaluate and test devices mounted in the customer's products or equipment.

> SANYO Semiconductor Co., Ltd. http://semicon.sanyo.com/en/network

### LV5747NTT

### Recommended Operating Range at $Ta = 25^{\circ}C$


Parameter	Symbol	Conditions	Ratings	Unit
Supply voltage range	VIN		8.0 to 42	V
Error amplifier input voltage	V <sub>FB</sub>		0 to 1.6	V


# Electrical Characteristics at Ta = 25°C, $V_{IN}$ = 24V

Parameter	Symbol	Conditions	Ratings			Unit
	Cymbol		min	typ	max	0111
Reference voltage block		1				
Internal reference voltage	Vref	Including offset of E/A	0.698	0.708	0.718	V
5V power supply	V <sub>DD</sub>	I <sub>OUT</sub> = 0 to 5mA	4.7	5.2	5.7	V
Triangular waveform oscillator bloc	:k					
Oscillation frequency	FOSC		260	300	340	kH:
Frequency variation	FOSC DV	V <sub>IN</sub> = 8 to 42V		1		%
Oscillation frequency fold back detection voltage	VOSC FB	FB voltage detection after SS ends		0.5		V
Oscillation frequency after fold back	FOSC FB	V <sub>FB</sub> = 0V	25	45	60	kH
ON/OFF circuit block			· · ·			
IC start-up EN voltage	V <sub>EN</sub> on	V <sub>IN</sub> = 8 to 42V		3.4	4.3	V
IC off EN voltage	V <sub>EN</sub> off		1.1	1.3		V
Soft start circuit block						
Soft start source current	I <sub>SS</sub> SC	EN > 4.3V	4	5	6	μA
Soft start sink current	I <sub>SS</sub> SK	EN < 1V, V <sub>DD</sub> = 5V		2		mA
Soft start end voltage	V <sub>SS</sub> END		0.9	1.1	1.3	V
UVLO circuit block	00	1				
UVLO lock release voltage	VUVLO		7.0	7.4	7.8	V
UVLO hysteresis			1.0	0.6	7.0	v
Error amplifier	VUVLO H			0.0		v
•	1-1-11				100	
Input bias current			4000	1 400	100	nA
Error amplifier gain	G <sub>EA</sub>		1000	1400	1800	μA/
Common mode input range	V <sub>EA</sub> R	V <sub>IN</sub> = 8 to 42V	0.0		1.6	V
Sink output current	IEA OSK	FB = 1.0V		-100		μA
Source output current	IEA OSC	FB = 0V		100		μA
Current detection amplifier gain	GISNS			1.3		
over current limiter circuit block						
Reference current	ILIM		-10%	20	+10%	μA
Over current detection comparator offset voltage	V <sub>LIM OFS</sub>		-5		+5	m\
Over current detection comparator			V <sub>IN</sub> -0.45		$v_{IN}$	V
common mode input range						
PWM comparator	1			r		
Input threshold voltage	Vt max	Duty cycle = DMAX, SW = V <sub>IN</sub>	1.0	1.1	1.2	V
	Vt0	Duty cycle = 0%, SW = V <sub>IN</sub>	0.4	0.5	0.6	V
Maximum ON duty	DMAX		92			%
Output block		1				
Output stage ON resistance (the upper side)	R <sub>ONH</sub>			5		Ω
Output stage ON resistance (the under side)	R <sub>ONL</sub>			5		Ω
Output stage ON current (the upper side)	IONH		240			mA
Output stage ON current (the under side)	IONL		240			m/
The whole device						
Standby current	ICCS	EN < 1V			60	μA
Mean consumption current	ICCA	EN > 4.3V		3.3		m/


# Package Dimensions

unit : mm (typ) 3375






### **Pin Assignment**




## **Block Diagram**



#### **Pin Function**

Pin No.	Pin name	Description
1	FB	Error amplifier reverse input pin. By operating the converter, the voltage of this pin becomes 0.708V. The voltage in which the output voltage is divided by an external resistance is applied to this pin. Moreover, when this pin voltage becomes 0.5V or less after a soft start ends, the frequency fold back function operations, and the oscillating frequency is falling with the FB voltage.
2	COMP	Error amplifier output pin. Connect a phase compensation circuit between this pin and FB.
3	EN	ON/OFF pin.
4	SW	Pin to connect with switching node. The source of NchMOSFET connects to this pin.
5	CBOOT	Bootstrap capacity connection pin. This pin becomes a GATE drive power supply of an external NchMOSFET. Connect a bypath capacitor between CBOOT and SW.
6	HDRV	An external the upper MOSFET gate drive pin.
7	LDRV	An external the lower MOSFET gate drive pin.
8	V <sub>DD</sub>	Power supply pin for an external the lower MOS-FET gate drive.
9	GND	Ground pin. Each reference voltage is based on the voltage of the ground pin.
10	VIN	Power supply pin. This pin is monitored by UVLO function. When the voltage of this pin becomes 7.8V or more by UVLO function, The IC starts and the soft start function operates.
11	ILIM	Reference current pin for current detection. The sink current of about $20\mu$ A flows to this pin. When a resistance is connected between this pin and V <sub>IN</sub> outside and the voltage applied to the SW pin is lower than the voltage of the terminal side of the resistance, the upper NchMOSFET is off by operating the current limiter comparator. This operation is reset with respect to each PWM pulse.
12	SS	Pin to connect a capacitor for soft start. A capacitor for soft start is charged by using the voltage of about 5µA. This pin ends the soft start period by using the voltage of about 1.1V and the frequency fold back function becomes active.

#### **Sample Application Circuit**



- SANYO Semiconductor Co.,Ltd. assumes no responsibility for equipment failures that result from using products at values that exceed, even momentarily, rated values (such as maximum ratings, operating condition ranges, or other parameters) listed in products specifications of any and all SANYO Semiconductor Co.,Ltd. products described or contained herein.
- SANYO Semiconductor Co.,Ltd. strives to supply high-quality high-reliability products, however, any and all semiconductor products fail or malfunction with some probability. It is possible that these probabilistic failures or malfunction could give rise to accidents or events that could endanger human lives, trouble that could give rise to smoke or fire, or accidents that could cause damage to other property. When designing equipment, adopt safety measures so that these kinds of accidents or events cannot occur. Such measures include but are not limited to protective circuits and error prevention circuits for safe design, redundant design, and structural design.
- In the event that any or all SANYO Semiconductor Co.,Ltd. products described or contained herein are controlled under any of applicable local export control laws and regulations, such products may require the export license from the authorities concerned in accordance with the above law.
- No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or any information storage or retrieval system, or otherwise, without the prior written consent of SANYO Semiconductor Co.,Ltd.
- Any and all information described or contained herein are subject to change without notice due to product/technology improvement, etc. When designing equipment, refer to the "Delivery Specification" for the SANYO Semiconductor Co.,Ltd. product that you intend to use.
- Information (including circuit diagrams and circuit parameters) herein is for example only; it is not guaranteed for volume production.
- Upon using the technical information or products described herein, neither warranty nor license shall be granted with regard to intellectual property rights or any other rights of SANYO Semiconductor Co.,Ltd. or any third party. SANYO Semiconductor Co.,Ltd. shall not be liable for any claim or suits with regard to a third party's intellectual property rights which has resulted from the use of the technical information and products mentioned above.

This catalog provides information as of June, 2010. Specifications and information herein are subject to change without notice.