


For LCD Monitor (PC + DVI) Interface Controller
For 640X480, 800X600, 1024X768, 1280X768, 1280X1024, 1366X768 Resolutions TFT LCD

DATA SHEET




TFT LCD Monitor Control Board

NCB310E2-DS-BA(A5)
(**ROHS** Compliant)

July 2006


CONTENT

• INTRODUCTION	-----	4
• GENERAL SPECIFICATION	-----	5
• SYSTEM DESIGN	-----	8
• BLOCK DIAGRAM	-----	9
• ASSEMBLY NOTES	-----	10
• CONNECTION & OPERATION	-----	13
• OSD	-----	14
• OSD FUNCTION	-----	15
• CONNECTOR, PINOUT & JUMPER	-----	18
• CONTROLLER DIMENSIONS	-----	27
• APPLICATION NOTES	-----	28
• TROUBLESHOOTING	-----	29
• APPLICABLE GRAPHIC MODE	-----	29
• ACCESSORY	-----	30
• APPENDIX	-----	31



Revision History

No	Data	Revision	Page
1	Preliminary Release	A1	
2	OSD update	A2	15
3	PCB Modification	A3/4	22
4	Video Mode (SXGA Panel) Setting added	A5	19,20
	XGA Mode (XGA~WXGA) Auto Setting added		



INTRODUCTION

Designed for LCD monitor and other flat panel display application the NCB310E2 controller provides an auto-input synchronization and easy to use interface controller for:

▶ TFT (active matrix) LCD panels of 640X480, 800X600, 1024X768, 1280X768, 1280x1024 and 1366X768

Resolutions

▶ Computer video signals of VGA, SVGA, XGA, WXGA and SXGA standard.

▶ Input Signal Support

- All VESA standard

HOW TO PROCEED

▶ Ensure that you have all parts & they are correct, refer to:

- Connection diagram
- Connector reference
- Assembly notes

▶ Check controller switch & jumper settings (errors may damage the panel)

▶ Prepare the PC

▶ Connect the parts

▶ Understand the operation & functions

IMPORTANT USAGE NOTE

This equipment is for use by developers and integrators. The manufacturer accepts no liability for damage or injury caused by the use of this product. It is the responsibility of the developer, integrators or other users of this product to:

- Ensure that all necessary and appropriate safety measures are taken.
- Obtain suitable regulatory approvals as may be required.
- Check power settings to all component parts before connection.

DISCLAIMER

There is no implied or expressed warranty regarding this material.

GENERAL SPECIFICATION

No.	Item	Description			
1	Model name	SVGA Panel	800X600	NCB310S4	Note 1)
		XGA Panel	1024X768	NCB310X4	
		WXGA Panel	1280X768	NCB310W4	
		WXGA Panel	1366X768	NCB310WZ4	
		SXGA Panel	1280X1024	NCB310E4	
2	LCD Module	SVGA, XGA, WXGA, SXGA			
3	Signal Input	Analog RGB. TMDS(DVI).			
4	Resolution Support	H: 31 ~ 80kHz			
		V: 55 ~ 76Hz			
5	OSD Control	Menu, Left, Right, Up, Down, Source, Power			5 keys
	Plug & Play	VESA DDC 2B Ver1.3			
6	Power Connector	Input	Type: IEC320 MALE 3Line Connector		
7.	Power Consumption	Supply Voltage	12Vdc/15Vdc/18Vdc or 24Vdc		
		Max Power	50W(With Back Light Inverter)		
8	Signal Connector	Analog	DSUB 15P(R, G, B Separate H, V Sync)		
		Digital	DVI-D(TMDS)		TMDS

Notes 1) Depends On Panel Resolution

- **V : VGA (640X480)**
- **S : SVGA (800X600)**
- **X : XGA (1024X768)**
- **W : WXGA (1280X768)**
- **WZ : WXGA (1366X768)**
- **E : SXGA (1280X1024)**

ELECTRICAL SPECIFICATION

Input characteristic


Description	Signal	Unit	Min	Typical	Max	Remarks
Power In (24V)						
	Input	Vdc	22.8	24.0	25.2	
	Consumption	Watt		TBD		Without INV
Power In (18V)						
	Input	Vdc	17.0	18.0	19.0	
	Consumption	Watt		TBD		Without INV
Power In (15V)						
	Input	Vdc	14.75	15.0	15.75	
	Consumption	Watt		TBD		Without INV
Power In (12V)						
	Input	Vdc	11.4	12.0	12.6	
	Consumption	Watt		TBD		Without INV
RGB Input						
	Analog RGB	Vp-p	0	0.7	-	
	Sync	Vdc	0	5	5.5	
	H Frequency	KHz	31		80	Depends on Mode
	V Frequency	Hz	55	60	75	
DVI Input						
	TMDS	mVp-p	450	500	900	

Output Characteristics


Description	Signal	Unit	Min	Typical	Max	Remarks
Panel Power						
	LCD Power (18V)	Vdc	17.1	18	18.9	Jumper option (Representative 12V)
	LCD Power (15V)	Vdc	14.25	15	15.75	
	LCD Power (12V)	Vdc	11.4	12	12.6	
	LCD Power(5V)	Vdc	4.75	5	5.25	Jumper option
	LCD Power(3.3V)	Vdc	3.13	3.3	3.46	Jumper option
LVDS Interface						
	Differential output	Vp-p (mV)	250	350	450	Different +/-
Inverter Interface						
	Power out	Vdc	22.8	24	25.2	Depends on Power Input and Spec.
			17.1	18	18.9	
			14.25	15	15.75	
			11.4	12	12.6	
	On/Off control	V	0		3.3	L=off, H=on
	Brightness control	V	3.3		0	Option
			0		3.3V	Option
			Step	0		100

SYSTEM DESIGN

A typical LCD based display system utilizing this controller is likely to comprise the following.



BLOCK DIAGRAM



ASSEMBLY NOTES

This controller is designed for monitors and custom display projects using 1280x1024 or 1366x768, resolution TFT LCD panels with a VGA, SVGA, XGA, WXGA, SXGA signal input. The following provides some guidelines for installation and preparation of a finished display solution.

Preparation: Before proceeding it is important to familiarize yourself with the parts making up the system and the various connectors, mounting holes and general layout of the controller. As much as possible connectors have been labeled. Guides to connectors and mounting holes are shown in the following relevant sections.

- 1. LCD Panel:** This controller has LVDS interface logic on the Board for different kind of TFT LCD panel. Due to the different signal timing and electrical characteristics from each LCD panel manufacturer, for selecting LCD interface type and resolution, put jumper marked J5 on the right position following LCD panel specification. For selecting DC power level, put jumper marked J19 on the right position. Supplied power level depends on LCD panel specification.
- 2. Controller:** Handle the controller with care as static charge may damage electronic components, Make sure correct jumper and switches settings to match the target LCD panel
- 3. LCD connector board:** Different makers and models of LCD panel require different panel signal connectors and different pin assignments.
- 4. LCD signal cables:** In order provide a clean signal it is recommended that LCD signal cables should not longer than 30cm. If loose wire cabling is utilized these can be a made into a harness with cable ties. Care should be taken when you place the cables to avoid signal interface. Additionally it may necessary in some systems to add ferrite cores to the cables to minimize signal noise.
- 5. Inverter:** This will be required for the backlight of an LCD, some LCD panel have an inverter built in. As LCD panels may have 1 or more backlight tubes and the power requirements for different panel backlights may vary it is important to match the inverter in order to obtain optimum performance. See application notes for more information on connection.
- 6. Inverter cable:** Different inverter models require different cables and different pin assignment. Make sure the correct cable pin out to match the inverter. Unsuitable cable pins out may damage the inverter..
- 8. OSD Button:** See Operational Function section.

9. 3 Color LED: This LED shows the state of controller.

- Green – Normal state
- Off – Off mode (Can't find video signals)
- Amber – DPMS mode

10. Power switch: This switch is located on OSD button board.

11. Power input: Proper power is required to supply power for the controller, the Inverter and the LCD panel

12. VGA Input Cable: As this may affect regulatory emission test result, a suitably shielded cable should be utilized.

EMI: Shielding will be required for passing certain regulatory emissions tests. Also the choice of video board and power supply can affect the test result.

Consideration should be given to:

- Electrical insulation.
- Grounding.
- EMI shielding.
- Heat & ventilation

Caution: Ensure that the adequate insulation is provided for all areas of the PCB with special attention to high voltage parts such as the inverter.

***** Remarks*****

For a specific panel use, One LCD panel sample and full technical specifications for the LCD panel from the manufacturer are required to test for tuning up screen image.

13. Setup for operation

Once the circuit has been connected, a setup procedure for optimal is requires a few minutes The following instructions are likely to form the basis of the finished product operation manual.

PC Settings

The PC needs to be set to an appropriate graphics mode that has the same resolution with the LCD panel to have clear screen image. And the vertical refresh rate should be set to one of 56~75Hz, non – interlaced signal.


LCD display System Settings

The OSD (On Screen Display) provides certain functions to have clear image and others. This board supports 4 buttons OSD operation as a standard. The control functions defined on OSD operation are as below.

Pc Graphics Output: A few guidelines:

- Signal quality is very important, if there is noise or instability in the PC graphics output this may result in visible noise on the display
- Refer to the graphic modes table in specification section for supported modes.
- Non-interlaced & interlaced video input is acceptable.

Important: please read the application notes section for more information.



CONNECTION & OPERATION

CAUTION: Never connect or disconnect parts of the display system when the system is powered up as this may cause serious damage.

CONNECTION

- 1. LCD panel & Inverter:** Connect the inverter (if it is not built- in the panel) to the CCFT lead connector of the LCD panel.
- 2. LVDS type panels:** Plug the signal cables direct to J100 of the controller board for Single Channel interface resolution Panel or J11 for dual channel interface panel. Plug the other end of cables to the LCD connector board.
- 3. Inverter & Controller:** Plug the inverter cable to J10/J16 of the controller board and another end to the connector on the inverter. Make sure J14 jumper position for Inverter Power
- 4. Function switch & Controller:** Plug the OSD switch mount cable to CN104 of the controller board and another end to the OSD board.
- 5. Jumpers & Switch:** Check all jumpers J23 (External power Setting), J19 (Target panel power is setting), J5 (Target Panel Option switch) and J14 (Inverter Power) are set correctly. Details referring the jumpers and switches setting table (in the following section)
- 6. VGA cable & Controller:** Plug the VGA cable to the connector J6 of the controller board.
- 7. DIV-D Cable & Controller:** Plug the DVI-D Cable to the connector J3 of the controller board.
- 8. Power supply & Controller:** Plug the DC 12V/15V/18V power in to the connector J2 and DC 24V power in to the connector J22 of controller board.
- 9. SMPS & Controller :** Plug the SMPS power in to the connector J13 of controller board
- 10. Power on:** Switch on the controller board and panel by using the OSD switch mount.

General:

- If you use supplied cables & accessories, ensure that they are correct for the model of the panel and the controller.
- If you make your own cables & connectors, refer carefully to both the panel & inverter specifications and the section in this manual, “Connectors, Pin outs & Jumpers” to ensure the correct pin to pin wiring.


PC Setting:

The controller has been designed to take a very wide range of input signals however to optimize the PC's graphic performance we recommend choosing 60Hz vertical refresh rate – this will not cause screen flicker.

OSD Control Board

The OSD (On Screen Display) provides certain functions to have clear image and others. This board supports 4 buttons OSD operation as a standard. The control functions defined on OSD operation are as below. (unit: mm)

Appearance



Button	Function	Status	HOT Key
Power	Power on/off	On/Off	
Menu	Activate menu		
Select	Menu Select		Auto setting
LED	Indicates operation status	Green/ Off/ Amber	
DOWN, UP ▼ ▲	Cursor control(Value Control) Down(Decrement)/Up(Increment)		UP : Source change

The chosen OSD settings will be stored in memory. The OSD menu can be cleared from the screen from the screen by moving the selection bar to the **EXIT MENU** icon pressing the **SEL** button otherwise it will be automatically cleared after a few second of non-use


OSD MAIN MENU




Picture



RGB MODE



Brightness / Contrast / Color / Sharpness



Tint

Picture

PSM			
Brightness			80
Contrast			80
Color			50
Sharpness			70
Tint			0

User

◀▶

R50 ~ 0 ~ G50

Exit: MENU ◀▶▶▼

Setup

Setup

Language
Transparency
Factory Reset

Exit: MENU ◀▶▶▼

Language

Setup

Language

Transparency
Factory Reset

English

50


To Start

◀▶

English
Deutsch
Francais
Italiano
Espanol

Prev: MENU ◀▶▶▼


Transparency



Factory Reset



Screen





Auto Configure

Screen

Auto configure	To set	
H position		50
V position		50
Clock		50
Phase		50
XGA Mode		

Exit : MENU ◀▶▲▼

H Position / V Position / Clock / Phase

Screen

Auto configure		
H position		50
V position		50
Clock		50
Phase		50
XGA Mode	AUTO	

Exit : MENU ◀▶▲▼

XGA Mode

Screen

Auto configure		
H position		50
V position		50
Clock		50
Phase		50
XGA Mode	AUTO	

◀▶

AUTO

1024x768

1280x768

1366x768


Exit : MENU ◀▶▲▼

*** XGA Mode : Setting of Auto configuration for XGA up to WXGA+ at Analog input**

OSD GUI Control Table

MAIN MENU	SUB MENU	CONTROL	
PICTURE	CSM	CSM/Brightness/Contrast	
		CSM	Normal/Warm/User
		User	Red/Green/Blue
SETUP	Language	English/Deutsch/François/Italiano/Espanol	
	Transparency	50 (1 ~100)	
	ISM Method	Normal, Orbit, White	
	Factory Reset	On/Off	
SCREEN	Auto Configure	On/Off	
	H Position	50(0 ~ 100)	
	V Position	50(0 ~ 100)	
	Clock	50(0 ~ 100)	
	Phase	50(0 ~ 100)	
	XGA Mode	AUTO / 1366*768 / 1280*768 / 1024*768	


* XGA Mode : Setting of Auto configuration for XGA up to WXGA+ at Analog input



Operation Message

OUT OF FREQUENCY

Input Signal is over the supporting range



POWER SAVER MODE

Input Signal is not present. This message is disappeared after 5 seconds.



SELF DIAGNOSTICS

Input Signal is not present after power on with power switch. This message is not disappeared before power off or activity of input signal.




AUTO CONFIGURATION

Execute AUTO Function.



CONNECTOR, PINOUT & JUMPERS

The various connectors are:



Summary

Reference	Item	Description	Type	Manufacture
J1	Jack	S-video Input	MJ373	MINIDIN 4PIN
J2	Jack	Input Dc power Jack	2.5Ø	-
J3	Connector	DVI-D Input(TMDS)	DVI-D 24P	
J4	Connector	Analog RGB Input Connector	20017WR-1210	YEONHO
J5	Switch	Panel Type Select Switch	HDR5X2	-
J6	Connector	Analog RGB Input	15P D-SUB	-
J7	Connector	24V Power Input	20017WR-0410	YEONHO
J10, J16	Connector	Inverter Connector	12505WR-1090	YEONHO
J11	Connector	LVDS Dual Interface	12507WR-30	YEONHO
J13	Connector	Internal SMPS Power Input	SMW200-1410	YEONHO
J14	Jumper	Inverter Power Jumper	HDR3X1	
J15	Block	24V Input Terminal Block	BR-500C	
J18	Connector	24V Power Input	20017WR-0910	YEONHO
J19	Jumper	Panel Power Jumper	HDR2X4	
J20	Connector	12V Power Input	20017WR-0410	YEONHO
J21	Block	12V Input Terminal Block		
J22	Connector	Input Dc power Jack	KPJ-4S-S	KYCON

J23	Connector	Output Power Jumper	HDR3X1	
J24	Connector	Output Power	20017WR-0310	YEONHO
J25	Connector	Power Selection	HDR3X1	
J26	Connect or	Inverter Dimming Selection	HDR3X1	
J100	Connector	LVDS Single Interface	12507WR-20	YEONHO
CN104	Connector	To OSD Board	20017WR-0710	YEONHO

J2: 12V DC power supply

Pin No.	Symbol	Description	Pin No.	Symbol	Description
Center	Vcc	12V	Shell	GND	Ground

J3: DVI-D Input Connector

Pin No.	Symbol	Description
1	TMDS DATA2-	TMDS DATA2 Differential Negative Signal
2	TMDS DATA2+	TMDS DATA2 Differential Positive Signal
3	TMDS DATA2 Shield	Shield for TMDS Channel #2
4	NC	No Connection
5	NC	No Connection
6	DDC Clock	The Data Line for the DDC Interface
7	DDC Data	The Clock Line for the DDC Interface
8	NC	No Connection
9	TMDS DATA1-	TMDS DATA1 Differential Negative Signal
10	TMDS DATA1+	TMDS DATA1 Differential Positive Signal
11	TMDS DATA1 Shield	Shield for TMDS Channel #1
Pin No.	Symbol	Description
12	NC	No Connection
13	NC	No Connection
14	+5V Power	+5 Volt signal for EDID (Un-powered Monitor)
15	GND(for +5V)	Ground for +5 Volt Power pin, Sync return
16	HPD	Identify the presence of a monitor
17	TMDS DATA0-	TMDS DATA0 Differential Negative Signal
18	TMDS DATA0+	TMDS DATA0 Differential Positive Signal
19	TMDS DATA0 Shield	Shield for TMDS Channel #0
20	NC	No Connection
21	NC	No Connection

22	TMDS CLOCK Shield	Shield for TMDS Clock differential Pair
23	TMDS CLOCK+	TMDS DATA0 Differential Positive Signal
24	TMDS CLOCK-	TMDS DATA0 Differential Negative Signal

J4: Analog RGB Input Connector

Pin No.	Symbol	Description
1	SCL	Serial Clock Line for DDC
2	SDA	Serial Data Line for DDC
3	NC	No Connection
4	VSYNC	Vertical Sync
5	HSYNC	Horizontal Sync
6	GND	Ground for HSYNC, VSNC, SCL, SDA
7	BLUE	BLUE analog input
8	BLUE GND	Ground for BLUE Input Signal
9	GREEN	GREEN analog input
10	GREEN GND	Ground for GREEN Input Signal
11	RED	RED analog input
12	RED GND	Ground for RED Input Signal

J5: Panel Type Select Switch

Pin No / Symbol		Description	
		OFF	ON
1	WXGA/WXGA Z	1280x768	1366x768
2	XGA/SXGA	1024x768	1280x1024
3	VGA/SVGA	640x480	800x600
4	MAP1/MAP2	LVDS MAP1	LVDS MAP2
5	DUAL/SINGLE	DUAL	SINGLE

*** See the appendix more information – 40 Page**

J6: ANALOG VGA INPUT

Pin No.	Symbol	Description
1	Red1	Red analog input
2	Green1	Green analog input
3	Blue1	Blue analog input
4	GND	Ground

5	GND	Ground
6	GND	Ground
7	GND	Ground
8	GND	Ground
9	NC	Not connected
10	GND	Ground
11	GND	Ground
12	DSDA	DDC-SDA
13	HSYNC	Horizontal Sync
14	VSYNC	Vertical Sync
15	DSCL	Serial Clock Input

J7: DC power Input Connector

Pin No.	Symbol	Description
1,2	Vcc	24V
3,4	GND	Ground

J10, 16: Backlight Inverter connector

Pin No.	Symbol	Description
1	DIM-ADJ	DIM-adjustment analog dimming control signal * make sure inverter specification
2	ON/OFF	Inverter digital ON(3.3V)/OFF(0V) signal
3,4,5,6	GND	Ground
7,8,9,10	B+	B+(24V or 12/18V)

J13: Internal SMPS Input Power Supply

Pin No.	Symbol	Description	I/O	Remarks
1	NC	No Connection		
2	GND	Ground		
3,4	12V	12V Logic Power Supply	I	Max 1.0A
5,6	GND	Ground		
7,8	5VP	5V Logic Power Supply	I	Max 1.0A
9	5VS	5V Standby Power Supply	I	
10,11	GND	Ground		
12	PWR_ON	SMPS Power On Control Signal	O	3.3V(High):On, 0.7V:OFF

13	INV_DIM	Inverter Dimming Control Signal	O	
14	INV_CTRL	Inverter ON/OFF Control Signal	O	

J14: On board +24V/+12V Inverter power select jumper

Pin No.	Symbol	Description
1	12V	representative 12V/18V, depends on power supply from J2
2	B+	Inverter power selected by J14' Jumper
3	24V	24V from J22

J15: +24V Power Input Block Terminal

Pin No.	Symbol	Description
1	24V	24V
2	GND	Ground

J18 : DC power Input Connector

Pin No.	Symbol	Description
1,2,3,4	GND	Ground
5,6,7,8	Vcc	24V

J19 : Panel Power Jumper

*** See the Summary: jumpers setting more information – 32 Page**

J20: DC power Input Connector

Pin No.	Symbol	Description
1,2	Vcc	12V
3,4	GND	Ground


J21: +12V Power Input Block Terminal

Pin No.	Symbol	Description
1	12V	12V
2	GND	Ground

J22: +24V DC power supply

Pin No.	Symbol	Description
1.3	GND	Ground

2.4	Vcc	24V
-----	-----	-----



EX) LSE0227B24130(4PIN) Li-shin Adapter / SLS0227B24118

J23: On board +12V/+5V logic power enable select jumper

Pin No.	Symbol	Description
1	12V	12V
2	Vcc	On board power enable
3	5V	5V

J24: Power out connector

Pin No.	Symbol	Description
1	Vcc	12V/5V from selected J23
2	GND	Ground
3	GND	Ground

J25 : Power Selection

*** See the Summary: jumpers setting more information – 32 Page**

J26 : Inverter Dimming Selection

*** See the Summary: jumpers setting more information – 33 Page**

CN104: OSD control connector

Pin No.	Symbol	Description
1	Vcc	+5V power for IR sensor
2	IRQ	Infrared rays signal line.
3	LED2	RED LED
4	LED1	GREEN LED
5	GND	Ground
6	KEY1	Up, Power
7	KEY0	Menu, Select, Down





J11: LCD Interface connector for 2 Ch LVDS type





Pin No.	Symbol	Description
1	MOD_PWR	Panel Power (12V/18V, 5V or 3.3V)
2	MOD_PWR	Panel Power (12V/18V, 5V or 3.3V)
3	MOD_PWR	Panel Power (12V/18V, 5V or 3.3V)
4	MOD_PWR	Panel Power (12V/18V, 5V or 3.3V)
5	GND	Ground
6	SELLDS	LVDS DATA ORDER SELECT(Depends on Panel)/ No Connection
7	GND	Ground
8	Y3P-EVEN	Positive(+) LVDS differential first 3 data(B port)
9	Y3M-EVEN	Negative(-) LVDS differential first 3 data(B port)
10	YCP-EVEN	Positive(+) LVDS differential first Clock(B port)
11	YCM-EVEN	Negative(-) LVDS differential first Clock(B port)
12	Y2P-EVEN	Positive(+) LVDS differential first 2 data(B port)
13	Y2M-EVEN	Negative(-) LVDS differential first 2 data(B port)
14	GND	Ground
15	Y1P-EVEN	Positive(+) LVDS differential first 1 data(B port)
16	Y1M-EVEN	Negative(-) LVDS differential first 1 data(B port)
17	YOP-EVEN	Positive(+) LVDS differential first 0 data(B port)
18	Y0M-EVEN	Negative(-) LVDS differential first 0 data(B port)
19	GND	Ground
20	Y3P-ODD	Positive(+) LVDS differential second 3 data(A port)
21	Y3M-ODD	Negative(-) LVDS differential second 3 data(A port)
22	YCP-ODD	Positive(+) LVDS differential second Clock(A port)
23	YCM-ODD	Negative(-) LVDS differential second Clock(A port)
24	Y2P-ODD	Positive(+) LVDS differential second 2 data(A port)
25	Y2M-ODD	Negative(-) LVDS differential second 2 data(A port)
26	GND	Ground
27	Y1P-ODD	Positive(+) LVDS differential second 1 data(A port)
28	Y1M-ODD	Negative(-) LVDS differential second 1 data(A port)
29	YOP-ODD	Positive(+) LVDS differential second 0 data(A port)
30	Y0M-ODD	Negative(-) LVDS differential second 0 data(A port)





J100: LCD Interface connector for 1 Ch LVDS type

Pin No.	Symbol	Description
1	GND	Ground
2	GND	Ground
3	Y3P	LVDS 3 Channel Positive Signal for LCD Module (6Bit Unused)
4	Y3M	LVDS 3 Channel Negative Signal for LCD Module (6Bit Unused)
5	GND	Ground
6	CLKOUTP	LVDS Clock Positive Signal of Channel for LCD Module
7	CLKOUTM	LVDS Clock Negative Signal of Channel for LCD Module
8	GND	Ground
9	Y2P	LVDS 2 Channel Positive Signal for LCD Module
10	Y2M	LVDS 2 Channel Negative Signal for LCD Module
11	GND	Ground
12	Y1P	LVDS 1 Channel Positive Signal for LCD Module
13	Y1M	LVDS 1 Channel Negative Signal for LCD Module
14	GND	Ground
15	Y0P	LVDS 0 Channel Positive Signal for LCD Module
16	Y0M	LVDS 0 Channel Negative Signal for LCD Module
17	GND	Ground
18	GND	Ground
19	MOD_PWR	VDD For LCD Module(12V/18V, 5V or 3.3V)
20	MOD_PWR	VDD For LCD Module(12V/18V, 5V or 3.3V)

Summary: jumpers setting

Reference	Description	Connector Type
J14	+12/15/18V inverter power enable	
	+24V inverter power enable	
J25	LCD External PSU Input	
	LCD Internal SMPS Input	




Reference	Description	Connector Type
J26	Inverter Brightness Max High	 <p>DIMADJ1 DIMADJ2</p>
	Inverter Brightness Max Low	 <p>DIMADJ1 DIMADJ2</p>
J23	For External Power 12V	 <p>12V 5V</p>
	For External Power 5V	 <p>12V 5V</p>

<p>J19</p>	<p>5.0V panel power Only Internal SMPS <i>(If Power come from J13)</i> CAUTION: Incorrect setting can damage panel</p>	 <p>12V 3.3V 5VS 5VP</p>
	<p>5.0V panel power Only PSU Input CAUTION: Incorrect setting can damage panel</p>	 <p>12V 3.3V 5VS 5VP</p>
	<p>3.3V panel power Only PSU Input CAUTION: Incorrect setting can damage panel</p>	 <p>12V 3.3V 5VS 5VP</p>
	<p>12V panel power - PSU & Internal SMPS CAUTION: Incorrect setting can damage panel</p>	 <p>12V 3.3V 5VS 5VP</p>

*** Power operation scheme :**

- 24V power supply from J22, 12V power generated by DC/DC converter so all 12V as marked 12V
- 12V, 15V or 18V from J2, marked 12V is representative 12V, 15V or 18V as well as power supply

CONTROLLER DIMENSIONS



APPLICATION NOTES

USING THE CONTROLLER WITHOUT BOTTONS ATTACHED

This is very straightforward:

- Firstly setup the controller/display system with the buttons. With the attached controllers and display system active make any settings for color, contrast and image position as required then switch everything off.
- Remove the control switches, the 7-way cable.
- Refer to inverter specifications for details as to fixing brightness to a desired level, this may require a resistor, an open circuit or closed circuit depending on inverter

INVERTER CONNECTION

There are 3 potential issues to consider with inverter connection:

- Power
- ON/OFF
- Brightness (DIM-ADJ)

Inverter power: This should be matched with the inverter specification.

Inverter ON/OFF: This is a pin provided on some inverter for ON/OFF function and is used by this panel controller for VESA DPMS compliance. If the inverter does not have on/off pin or the on/off pin is not used DPMS will not operate. Pin 5 should be matched to the inverter specification for the ON/OFF pin.

Brightness Dimming control: NCB310E Controller boards are analog dimming control method. And it is important to consider the specifications for the inverter to be used.

TROUBLESHOOTING

General

A general guide to troubleshooting of a flat panel display system it worth considering the system as separate elements, such as:

- ▶ Controller (jumpers, PC settings)
- ▶ Panel (controller, cabling, connection, panel, PC settings)
- ▶ Backlight (inverter, cabling, connection, panel, Pc settings)
- ▶ Cabling
- ▶ Computer system (display settings, operating system)

Through checking the system step by step cross with instruction manuals and a process of elimination to isolate the problem it is usually possible to clearly identify the problem area.

No image:

- ▶ If the panel backlight is not working it may still be possible to see just some image.
- ▶ A lack of image is most likely to be caused by incorrect connection, lack of power, failure to provide a signal or incorrect graphic card settings.

Image position:

If it is impossible to position the image correctly, the image adjustment controls will not move the image far enough, then test using another graphics card. This situation can occur when a graphic card is not close to standard timing or when something is in the graphics line that may affect the signal such as a signal splitter (please note that normally a signal splitter will not have any adverse effect).

Image appearance:

- ▶ A faulty panel can have blank lines, failed sections, flickering or flashing display.
- ▶ Incorrect graphic card refresh rate, resolution or interlaced mode will probably cause the image to be the wrong size, to scroll to, flicker badly or possibly even no image.
- ▶ Incorrect jumper settings on the controller may cause everything from incorrect image viewing to total failure.

CAUTION: Do not set the panel power input incorrectly.

- ▶ Sparkling on the display: faulty panel signal cable.

Backlight:

Items to check include: Power input, controls, inverter and Tubes generally in this order.

If half the screen is dimmer than the other half:

- ▶ Check cabling for the inverter.

Also:

- ▶ If system does not power down when there is a loss of signal.

APPLICABLE GRAPHIC MODE


The microprocessor measures the, H – sync V – sync and polarity for RGB Inputs, and uses this timing information to control all of the display operation to get the proper image on a screen. This board can detect all VESA standard Graphic modes shown on the table below and Provide more clear and stable image on a screen

Table 6.1) RGB input format

Spec Mode	Pixel Freq.	Horizontal Timing				Vertical Timing			
		Syn c Pola r	Freq.	Total	Activ e	Syn c Pola r	Freq.	Tota l	Active
	MHz	KHz	Pixel	Pixel	Hz	Line	Line	Line	
640*350@70Hz	25.144	P	31.430	800	640	N	70.000	449	350
640*400@70Hz	28.287	N	31.430	800	640	P	70.000	449	400
720*400@70Hz	28.287	N	31.430	900	720	P	70.000	449	400
640*480@60Hz	28.175	N	31.469	800	640	N	59.940	525	480
640*480@72Hz	31.500	N	37.861	832	640	N	72.809	520	480
640*480@75Hz	31.500	N	37.500	840	640	N	75.000	500	480
800*600@56Hz	36.000	P	35.156	1024	800	P	56.250	625	600
800*600@60Hz	40.000	P	37.879	1056	800	P	60.317	628	600
800*600@72Hz	50.000	P	48.077	1040	800	P	72.188	666	600
800*600@75Hz	49.500	P	46.875	1056	800	P	75.000	625	600
1024*768@60Hz	65.000	N	48.363	1344	1024	N	60.005	806	768
1024*768@70Hz	75.000	N	56.476	1328	1024	P	70.070	806	768

Data Sheet NCB310E2

1024*768@75 Hz	78.750	P	60.02 3	1312	102 4	P	75.03 0	800	768
1280*720@60 Hz	74.500	P	44.77 2	1664	128 0	P	59.85 5	748	720
1360*768@60 Hz	84.75	P	47.72	1776	136 0	P	59.79 9	798	768
1280*1024@6 0Hz	108.000	P	63.98 1	1688	128 0	P	60.02 0	106 6	1024
1280*1024@7 5Hz	135.000	P	79.97 6	1688	128 0	P	75.03 5	106 6	1024




ACCESSORY

This board requires several accessories to build a complete display unit. INNODISPLAY can provide standard accessory for this board as below.

No.	Items	Part No.	Ex) LG Philips LC320W01
1	LCD signal cable	VSC-Panel Part No.-mm	VSC-LC320W01-400mm
2	Inverter	Part no. of Manufacturer	
3	Inverter cable	VIC-Inverter Part No.- mm	VIC-LC320W01-300mm
4	OSD Board	NOB005P	NOB005P
5	OSD Cable	VOC- OSD Part No -mm	VOC-NOB005P-200mm

* mm : Cable length(unit: mm)



APPENDIX


A. Target panel jumper setting

1~2 : Output Resolution Selection

1	2	Resolution
		640 x 480
		800 X 600
OFF	ON	1024 X 768
ON	ON	1280 X 768
OFF	OFF	1366 X 768
ON	OFF	1280 X 1024

3 : LVDS Map Selection

* ON : LVDS MAP2(Shift) OFF : LVDS MAP1(Normal)



4 : Panel 6bit or 8bit Selection

* ON : 6bit OFF : 8bit

5 : LVDS Channel Selection

* ON : Single OFF : Dual

A. Tested panel

This board can support various LCD panels, which have VGA, SVGA, XGA, WXGA and SXGA resolution.

The table below shows the model names of LCD panel, Jumper setting for LCD power, LCD panel selection and the dedicated inverter for each LCD panel. All of the LCD Panels listed can work without changing the control program of the NCB310E board.

No.	LCD Model Name	LCD vendor	LCD VCC	Option	SW1	SW2	SW3	SW4	SW5	J25	J26
1	LM170E01-A5	LG	+5VS	ED8N	ON	OFF	OFF	OFF	OFF	5VSA	DIM1
2	LM190E01-C4	LG	+12V	ED8N	ON	OFF	OFF	OFF	OFF	5VSA	DIM1
3	M170EN05	AU	+5VS	ED8N	ON	OFF	OFF	OFF	OFF	5VSA	DIM1
4	M170EN07	AU	+5VS	ED8N	ON	OFF	OFF	OFF	OFF	5VSA	DIM1
5	CLAA170EA0 7	CPT	+5VS	ED8N	ON	OFF	OFF	OFF	OFF	5VSA	DIM1
6	CLAA190EA0 3	CPT	+5VS	ED8N	ON	OFF	OFF	OFF	OFF	5VSA	DIM1
7	CLAA150XP0 1	CPT	+3.3V	XS8N	OFF	ON	OFF	OFF	ON	5VSA	DIM1
8	LM150X08	LG	+3.3V	XS8N	OFF	ON	OFF	OFF	ON	5VSA	DIM1
9	LC171W03	LG	+12V	WXS8N	ON	ON	OFF	OFF	ON	5VSA	DIM1
9	LC230W01	LG	+12V	WXS8N	ON	ON	OFF	OFF	ON	5VSA	DIM2
10	LC230W02	LG	+12V	WX+S8N	OFF	OFF	OFF	OFF	ON	5VSA	DIM2
	LC260WX2	LG	+12.0V	WXN8S	OFF	OFF	ON	ON	ON	5VSA	DIM2
	LTA260WX2	SAMSUNG	+5.0V	WXS8S	OFF	OFF	ON	OFF	ON	5VSA	DIM1
	LC300W01-B5	LG									
	LC300W02-A5	LG									
11	LC320W01	LG	+12V	WX+S8N	OFF	OFF	OFF	OFF	ON	5VSA	DIM2
	LTA320W2-L03	SAMSUNG									
12	LC420W02	LG	+12V	WX+S8N	OFF	OFF	OFF	OFF	ON	5VSB	DIM2
13	M150XN07	AU	+3.3V	XS6S	OFF	ON	ON	ON	ON	5VSA	DIM1
14	G150XG01	AU	+3.3V	XS6S	OFF	ON	ON	ON	ON	5VSA	DIM1

* P/N : VPM-0057AA (F/W Ver 1.04)

Note1 : Abbreviated word : E[®]S[®]6[®]S[®]

- Ⓐ V/S/X/W/WZ/E : V VGA, S SVGA, X XGA, W WXGA, WZ WXGA, E SXGA
- Ⓑ S/N : S(SFT) SHIFT, N(NOR) NORMAL
- Ⓒ 6/8 : 6 6BITS 8 8BITS
- Ⓓ S/D : SINGLE PORT, D DUAL PORT

